



## leakSMART® PRO Valve

### Complete Home Water Protection

---

leakSMART® is an innovative, wireless system that eliminates the threat of water damage by keeping you in constant control of your home's water supply. It not only detects leaks in your home, but also immediately shuts off the water, stopping damage before it can start — all in less than 10 seconds (Smart system hub required).

#### It's innovative technology that is simple and easy to use:



- 1 Download the leakSMART® App on your mobile device from the Apple Store or Google Play
- 2 Activate your leakSMART® hub (or other compatible smart home system) with the leakSMART® app.
- 3 Pair your leakSMART® Valve and waterproof sensors to your leakSMART® hub.
- 4 Install your leakSMART® Valve to your main water supply. **PROFESSIONAL INSTALLATION IS STRONGLY RECOMMENDED.**
- 5 Easily monitor, detect and control your main water supply with your mobile device. Enjoy peace of mind knowing that the threat of water damage has been eliminated.

Once your leakSMART® system is up and running, please keep this manual for future reference.

**CAUTION:** Read installation instructions BEFORE installing batteries in your leakSMART® Valve.

# leakSMART® PRO

## TABLE OF CONTENTS

- **Homeowner Setup and Operation**
  - Valve ..... 5
  - Manual Operation Steps ..... 8
  - Professional Installation Steps ..... 9-10
- **Troubleshooting**
  - Valve ..... 11-14

# leakSMART®

## Package Contents


---



It's never been easier to stay in control of your home's water supply. Setting up your leakSMART® system is as simple as launching an app, pairing with your smart home system and getting your leakSMART® Valve installed.

**Unpack your leakSMART® box and check the contents. You should have the following:**

**Package Includes:**

**Tools Required:** (1) Phillips Head Screwdriver 

- (1) leakSMART® Valve
- (1) 9V Power supply for the leakSMART® Valve (1 with 18 ft. reach)
- (1) Instruction Manual
- (4) AA Batteries

**Required:**

leakSmart® or compatible home hub.

Download the leakSmart® app (or compatible smart home system app) from google play or app store and create an account.

Log into leakSmart® app (or compatible smart home system app) to begin the next steps in the set up process.

# leakSMART® PRO

## Valve Setup and Operation

---



### 1. Download leakSMART® app via google play store (Android) or iTunes (IOS). Pair your leakSMART® valve with your smart home system (Smart hub required)

- Place your leakSMART® Valve near your installation location, so you can verify that it is within range of your smart home leakSMART™ Hub. Verification will be done in pairing mode in APP.



- Connect leakSMART® Valve to the provided 9V Power Supply and verify that the AC power cord is long enough to reach the valve installation location. (An optional 9 ft. AC power adapter extension wire is also available. This, and other leakSMART® accessories, can be purchased at [leakSMART.com](http://leakSMART.com)) It is recommended to install 4 AA alkaline batteries (provided) as a source of battery backup. ( A flashing blue light on the front of the unit will indicate that it's ready to pair. If the blue light stops flashing, press the center button 5 times quickly to reset pairing mode.

### Now, open the leakSMART® App on your smart device.



- On the leakSMART® hub, press the blue button once to enter pairing mode, or use the add device tab found on the home page of the leakSMART® app. As a reminder, a steady-single green flashing light on the leakSMART® Hub indicates pairing mode and will last 3 minutes while in pairing mode.

**CAUTION:** Do not replace the 4 AA battery block with a 9v battery, this could damage the device and void warranty.



## leakSMART® PRO Valve Setup and Operation

---



- Once the hub is in pairing mode, press the center button once quickly on the valve controller. Check app for the valve to show up. **Note:** that it may take up to a minute for the valve to populate in the app.

- All leakSMART® Valve Lights should turn off once pairing mode has been successfully completed.
  - A new valve on your home screen will verify the valve has been added.



- leakSMART® App, should register 'New Valve' on the home screen.  
**Note:** You can manually open/close the leakSMART® Valve by pressing the 'Open' and 'Close' buttons located on the front of the valve Or use the toggle button to remotely open and close the valve in the app.

- It is recommended to test the valve by opening and closing using both, the local control buttons on the valve and in the app, prior to installation.
- Once communication has been tested between hub and valve, you will then be ready to plumb in the valve.

**Professional Installation Recommended. Contact a licensed plumber for professional installation of your leakSMART® Valve.**

- For fast, easy installation, provide your plumber with the details on pages 9-10





## leakSMART® PRO Valve Setup and Operation

---

### 2. Be protected, (Sensors required)



- A leakSMART® sensor provides an audible water detection alarm, even without connection to your leakSMART® Hub — but pairing a sensor means the system will signal your leakSMART® Valve to automatically shut off your water and send you instant notifications, preventing water damage within 10 seconds.
- To completely protect yourself from water damage, pair each leakSMART® sensor with your smart home system. Place the sensors in key locations you would like to monitor. This will assure that your main water supply shuts off in the event of a leak.

**Note:** Sense only option is available and will notify you of the presence of water in regions that does not require the shutting off of your main water supply (sensor required).

**Note:** The leakSMART® hub can support up to 32 individual leakSMART® devices. Additional sensors may be purchased separately for whole home monitoring.



## leakSMART<sup>®</sup> PRO Manual Operation Steps



### Manual Operation of your leakSMART<sup>®</sup> Valve:

In the event of repeated error messages from your smart home system that the valve is not automatically opening and closing, the valve may be manually opened or closed.



1. Unplug the AC power cord from the valve cover.




2. Remove the cover from the valve.



3. Use a marker to draw a line across one side where the upper and lower motor housing connects, so when the motor is removed, you'll know how to reposition it for assembly.



4. Remove the 4 screws using a Phillips head screwdriver.



Shown in closed position

5. Place your thumb and finger on the plastic gear and rotate **clockwise** to open the valve or **counter-clockwise** to close it; do not use tools to manually open or close the valve.





## leakSMART® Professional Installation Steps

The leakSMART® Valve is a patent-pending, wireless, motorized brass water ball valve that connects directly to a home's main water supply. Professional installation is strongly recommended to ensure proper operation and reliable water damage prevention.



### Please note:

- *The leakSMART® Valve may only be installed in homes with an existing main water shutoff*
- *To avoid any injury, never place your fingers inside the valve*
- *Do not grip plastic motor drive for leverage when installing the valve*
- *Do not install on fire suppression systems or fire sprinkler water lines*
- *Indoor use only*



1. Ensure that you have all necessary leakSMART® Valve components and fittings required for installation:
  - leakSMART® Valve (3/4" FIP x 3/4" MIP), (1" FIP x 1" MIP) or (1-1/4" FIP x 1-1/4" MIP)
  - AC power adapter with 18 ft. reach
  - 4 AA Alkaline batteries (provided)



2. To protect the valve cover from possible damage, remove it by sliding it away from the valve, and keep it off until you've completed installation.



3. Shut off the main water supply valve.




4. Open both hot and cold handles on the faucet nearest the valve to relieve water pressure.





## leakSMART® PRO Professional Installation




5. The valve will also need to reach an AC power source. It is recommended that the valve is kept operating on AC power (cord provided), with batteries used as a back-up power source.

**IMPORTANT:** *The valve must be installed after the water main manual shut-off and water meter. It is recommended that the valve be installed at least 8 inches away from water shut-off to avoid damage. Additional fittings may be required.*

- Do not solder fittings near the water meter or smart valve to avoid heat affecting the devices.
- Position the valve so that the arrow on the side points away from the water meter.

**Note:** The valve can be installed vertically or horizontally, do not install upside down.



6. Once installed, close the faucet, turn on the main water valve and check for leaks. Reattach the valve cover by sliding it over the motor housing, with the front facing you. **Caution:** When first opening the valve, air remaining in your plumbing lines from cutting in the valve will rapidly vent out of the open faucet, this may create water hammer effect on first time use. Once air has escaped, your system will go back to normal pressures.



7. Attach the AC power cord adapter to the valve cover and plug into the nearest 110 volt outlet.
- Using an extension cord is not recommended — please use the 18 ft. AC power adapter cord in this package.
  - An optional 9 ft. AC power adapter extension wire is also available.
- This, and other leakSMART® accessories, can be purchased at [leaksmart.com](http://leaksmart.com)



8. Check valve cover function by turning on a faucet and pressing the “Open” and “Close” buttons.
- When the valve is open, it will display a steady green light and water will run.
- Caution:** When first opening the valve, air remaining in your plumbing lines from cutting in the valve will rapidly vent out of the open faucet, this may create water hammer effect on first time use. Once air has escaped, your system will go back to normal pressures.
- When the valve is closed, it will display a steady red light and water will stop running.

Confirm the valve is functioning properly with the leakSMART® App. Sensor(s) and hub.









# leakSMART® PRO

## Troubleshooting



Your leakSMART® Valve works with your smart home system to keep you in control of your home’s water supply. The valve, which operates on AC power with battery back-up, will close automatically when paired with leakSMART® Hub and Sensors. Monitor your smart home system through your mobile device and detect a leak. The leakSMART® Hub will send a signal to your personal smart device providing you with more control and protection for your home. Plus you can easily turn your water supply on and off from anywhere using your smartphone, tablet.





Status	Operation	Lights	Notes
 Open Valve	Press left side “Open” button	Steady <b>green</b> light	
 Pairing Mode		<b>Blue</b> light blinks twice every two seconds	If the blue light stops flashing before pairing is successful, press the center button 5 time quickly, to reset Pairing Mode
 Pairing Successful	Press center button once	<b>Blue</b> light blinks three times, then stops	Check APP, Valve lights will go dark
 Reset to Factory Settings	Press center button five times, quickly	<b>Blue</b> light blinks every two seconds	Once the valve is reset, it can’t be controlled manually until it’s re-paired with your smart home system
 Close Valve	Press right side “Close” button	Steady <b>red</b> light	
 Error		Red & green alternating	Make sure controller is firmly engaged on valve body

**NOTE:** When not in use, lights will go dark.

# leakSMART® PRO

## Troubleshooting

---

Problem	What to Check
 <p>Status lights do not come on</p>	<ul style="list-style-type: none"><li>• Make sure there is power to the outlet</li><li>• Unplug AC power adapter cord from valve cover and plug back in</li><li>• If AC adapter extension wire was used, unplug both ends and reconnect</li><li>• Replace batteries</li></ul>
 <p>No water comes out of the faucet</p>	<ul style="list-style-type: none"><li>• Check that your leakSMART™ Valve is open by pressing the "Open" button on your Valve</li><li>• Make sure the main water supply valve is open</li><li>• Replace batteries</li><li>• Make sure valve cover or valve controller is firmly on valve assembly</li></ul>
 <p>leakSMART™ Valve does not operate</p>	<ul style="list-style-type: none"><li>• Check that the unit is powered from the AC power adapter</li><li>• Replace batteries</li><li>• Power down by removing both battery block and AC power cord, then plug back in</li></ul>
 <p>leakSMART™ Valve does not operate with your smart home system</p>	<ul style="list-style-type: none"><li>• Check your smart home system app to ensure the valve is connected</li><li>• Check Internet connection to your hub</li><li>• Close out then re-open app</li></ul>

**NOTE:** All lights go dark when not in use.

# leakSMART® PRO

## Device Reset Procedures




- To reset the valve controller, rapidly press the center button 5 times. The **Blue LED** light will begin to flash indicating it is reset and ready to join the system.

**Note 1:** Sometimes the device may require that it be power cycled in advance. This is done by removing the AC adapter cord connector and also removing a battery if any are installed. Then power back up and proceed by pressing the center button 5 times rapidly.

**Note 2:** If resetting the valve while connected to an existing leakSmart® system where the valve is visible in the App, the valve will drop off, in being removed from the system.


To pair the valve, Put the smart system hub in pairing mode, press the center button once on the valve, check app for the valve to show up. **Note:** Once joined, all lights will go dark.



# leakSMART® PRO

## Device Reset Procedures

---



Shown in  
closed position

### Sector Gear (Manual Operation)

#### **Manual operation:**

Accessing the sector gear, allows for manual operation of the valve. The sector gear is installed directly to the valve stem. Maintain position of the sector gear if removing, flipping the sector gear upside down reverses operation.