




ROOM AIR CONDITIONER

INDOOR
AQ24A1QE
AQ24B1QE
AQ18A1QE
AQ18B1QE

OUTDOOR
UQ24A1QE
UQ24B1QE
UQ18A1QE
UQ18B1QE


SERVICE Manual

AIR CONDITIONER



CONTENTS

1. Precautions
2. Product Specifications
3. Operating Instructions and Installation
4. Disassembly and Reassembly
5. Troubleshooting
5. Exploded Views and Parts List
6. Block Diagrams
7. PCB Diagrams
8. Wiring Diagrams
9. Schematic Diagrams



1. Precautions

1. **Warning:** Prior to repair, disconnect the power cord from the circuit breaker.
2. **Use proper parts:** Use only exact replacement parts. (Also, we recommend replacing parts rather than repairing them.)
3. **Use the proper tools:** Use the proper tools and test equipment, and know how to use them. Using defective tools or test equipment may cause problems later-intermittent contact, for example.
4. **Power Cord:** Prior to repair, check the power cord and replace it if necessary.
5. **Avoid using an extension cord,** and avoid tapping into a power cord. This practice may result in malfunction or fire.
6. **After completing repairs and reassembly,** check the insulation resistance. Procedure: Prior to applying power, measure the resistance between the power cord and the ground terminal. The resistance must be greater than 30 megohms.
7. **Make sure that the grounds are adequate.**
8. **Make sure that the installation conditions are satisfactory.** Relocate the unit if necessary.
9. **Keep children away from the unit while it is being repaired.**
10. **Be sure to clean the unit and its surrounding area.**




Fig. 1-1 Avoid Dangerous Contact




Fig. 1-2 No Tapping and No Extension Cords




Fig. 1-3 No Kids Nearby!




Fig. 1-4 Clean the Unit

MEMO

2. Product Specifications

2-1 Table

Item				Model		AQ24A1QE		AQ18A1QE		
						Cooling	Heating	Cooling	Heating	
Power Source				220/240V~,50Hz		220/240V~,50Hz				
Perfor- mance	Capacity	KW		7.03	7.03	5.27	5.86			
		BTU/h		24,000	24,000	18,000	20,000			
	Air circulation (High)		m²/min		14.5	15	13.5	14		
	Moisture removal (High)		Liters/h		2.7	-	2.2	-		
Electrical Rating	Available voltage range		V		198-264		198-264			
	Running amperes		A		11.8	12	8.3	8.8		
	Power input		KW		2.45	2.45	1.85	1.95		
	Power factor		%		86.5	85.1	92.9	92.3		
	Energy efficiency ratio		BTU/wh		9.8	9.8	9.7	10.2		
	Compressor locked rotor amperes		A		68		30			
Features	Controls/Temperature control			Microprocessor/I.C Thermostat			Microprocessor/I.C Thermostat			
	Control unit			Wireless remote control			Wireless remote control			
	Timer			Q-Timer/24-Hour On or Off			Q-Timer/24-Hour On or Off			
	Fanspeed		Indoor/Outdoor	3 Steps and Turbo/1 Step			3 Steps and Turbo/1 Step			
	Airflow direction(indoor)		Horizontal	Manual			Manual			
			Vertical	Auto			Auto			
	Comperssor			Reciprocating(Bristol)			Rotary(Samsung)			
	Refrigerant/Amount charged at rating		g	R22/1650			R22/1550			
	Refrigerant control			Capillary tube			Capillary tube			
	Operation sound	Indoor Hi/Me/Lc	dB-A	47/44/41			45/42/39			
		Outdoor-Hi	dB-A	59			55			
	Refrigerant tubing connections			Flare type			Flare type			
	Max. allowable tubing length at shippint		m	5			5			
	Refrigerant tube diameter	Narrow tube	(in.)	6.35(1/4")			6.35(1/4")			
		Wide tube	(in.)	15.88(5/8")			12.70(1/2")			
	Refrigerant tube kit/Accessories			Optional/Hanger-plate			Optional/Hanger-plate			
Dimensions & Weight				Indoor unit	Outdoor	Indoor unit	Outdoor			
	Unit dimensions	Height	mm	275	638	275	620			
		Width	mm	1080	880	1080	787			
		Depth	mm	204	310	204	320			
	Package dimensions	Height	mm	372	851	372	680			
		Width	mm	1153	1023	1153	926			
		Depth	mm	272	413	272	451			
	Weight	Net	kg	15	63.0	15	46.0			
Shipping		kg	18	67.0	18	50.0				

Remarks : Rating Conditions are :

Indoor air temperature 27°C DB/19°C WB

Outdoor air temperature 35°C DB/24°C WB

2-2 MAJOR COMPONENT SPECIFICATIONS

■ Indoor Unit


Model				AQ24A1QE	AQ18A1QE
PCB	Part No.			DB93-10545A	DB93-10555A
	Controls			Microprocessor	Microprocessor
	Control circuit fuse			250V, 3.15A	250V, 3.15A
FAN & FAN MOTOR	Type			Cross-Flow	Cross-Flow
	Dia. and lengthmm			ø95/L=842	ø95/L=842
	Fan motor model			IC-9430SKJ5A	IC-9430SKJ5A
	Pols,rpm(at 240V)			4P, 1350 RPM	4P, 1350 RPM
	Normal outputW			40 W	40 W
	Coil resistance(Ambient temp.20°C)			MAIN:162 SUB:216	MAIN:162 SUB:216
	Safety devices	Type		17AM034A5	17AM034A5
		Operating temp.	Open °C	135±5°C	135±5°C
			Close °C	-	-
Run capacitorµF x VAC			1.2µF X 450VAC	1.2µF X 450VAC	
S-MOTOR	Type			PM	PM
	Model			MP35EA, MSFCC20B02	MP35EA, MSFCC20B02
	Rating			DC 12V	DC 12V
	Coil resistance (Ambient temp. 25°C)			250	250
Heat Exch.	Coil			AL-FIN/Copper tube	AL-FIN/Copper tube
	Rows x Steps			2 X 15	2 X 15
	Fin pitchmm			1.5	1.5

■ Outdoor Unit

Model					UQ24A1QE/UQ24B1QE	UQ18A1QE/UQ18B1QE
Compressor	Type				Reciprocating	Rotary
	Compressor model				H25B30QABH	48B180JV1E7
	Normal output W				2430	1535
	Comperssor oil kind				SUNISO 3GS	SUNISO-4GSD-T
	Comperssor oil cc				1,030	600
	Oil Specific gravity				0.92	0.92
	Coil resistance(Ambient temp.25°C)				Start winding:	Common to Main : 1.84
					Run winding :	
	Safety devices		Type		Protector	Protector
			Overloal relay		Internal Line Break	MRA12016-12007
			Operating temp.	Open °C		
				Close °C	74	
		Operating amp(Ambient temp.)		120°C:10.7, 130°C:9.4		
Run capacitor μF x VAC				40MF X 400VAC	40MF X 400VAC	
FAN & FAN	Type				Propeller	Propeller
	Dia. and length mm				ø460	ø405
	Fan motor model				OSME-716SRC,IC-1640SOJ5A,ASS100AVEA	AMASS-035AVEB
	Pols, rpm(at240V)				6P, 870RPM	4P, 980RPM
	Normal output W				70W	35W
	Coil resistance(Ambient temp.20°C)				MAIN : 58 - 88	MAIN : 180
					SUB : 85 - 150	SUB : 225
	Safety devices		Type		17AM034A5	17AM037A5
			Operating temp.	Open °C	135±5°C	150±5°C
				Close °C	-	-
	Run capacitor μF x VAC				3μF X 450VAC	2.5μF X 450VAC
	Heat Exch.	Coil				AL-FIN/Copper tube
Rows x Steps				2 X 24	2 X 24	
Fin pitch mm				1.7	1.7	


2-3 Dimensions

2-3-1 Indoor Unit




2-3-2 Outdoor Unit

2-3-2(a) UQ24A1QE, UQ24B1QE




2-3-3(b) UQ18A1QE, UQ18B1QE



2-4 Pressure Graph


Indoor Unit : AQ24A1QE
AQ24B1QE

Outdoor Unit : UQ24A1QE
UQ24B1QE



Indoor Unit : AQ18A1QE
AQ18B1QE

Outdoor Unit : UQ18A1QE
UQ18B1QE























MEMO

3. Operating Instructions and Installation

3-1 Operating Instructions

3-1-1 Name & Function of Key in remote controller

NO		NAMED OF KEY	FUNCTION OF KEY	
1			On/Off Button. Use this button to start and stop air conditioner.	
2		<div></div> <div>▲ (UP)</div>	Temp. up button. If the ▲ button is pressed once, the setting temperature is increased by 1°C	
		<div></div> <div>▼ (DOWN)</div>	Temp. up button. If the ▼ button is pressed once, the setting temperature is decreased by 1°C	
3		MODE	Each time you press this button, MODE is changed in the following order. <div></div> <div> : Auto Mode  : Fan Only Mode  : Cool Mode  : Heat Mode  : Dry Mode</div>	
4		TURBO	Use this button to provide heavy duty cooling & Heating for 30 minutes.	
5	OFF 	Set up the reserve or cancel the timer on and timer off quickly		
6	COVER		Use this button for sleep operation. (The SLEEP mode can be selected at COOL and HEAT mode.)	
7			Adjusts air flow vertically.	
8			Each time you press this button, FAN SPEED is changed in the following order. <div></div>	
9		TIMER	ON TIMER	Set up the time that operation start.
10			OFF TIMER	Set up the time that operation stop.
11			SET	Use this button to reserve the timer on.
12			CANCEL	Use this button to reserve or cancel the timer on and timer off.
13			 (UP)	If the  button is pressed once, the time increase by one minute during the time set mode, and ten minutes during the timer set mode.
14			 (DOWN)	If the  button is pressed once, the time decrease by one minute during the time set mode, and ten minutes during the timer set mode.
15			TIME	Without regard to ON/OFF condition in remote controller, use this button to set current time. Adjust the current time using   button. (Data can be transmitted after setting up the time)

3-1-1 Name & Function of Key in remote controller

1. **AUTO MODE** : In this mode, operation mode(COOL, HEAT) is selected automatically by the room temperature of initial operation.

Room Temp	Operation Type
Tr 21°C+ T	Cool Operation (Set Temp:24°C+ T)
21°C + T>Tr	Heat Operation (Set Temp : 22°C+ T)

T= -2°, -1°C, 0°C+1°C+2°C

T is controlled by setting temperature up(▲)/down(▼) key of remote controller

2. **COOL MODE** : The unit operates according to the difference between the setting and room temperature. (18°C~30°C)
3. **HEAT MODE** : The unit operates according to the difference between the setting and room temperature.(16°C~30°C)
***Prevention against cold wind**: For about 3~5 minutes after initial operation, thermo control or “de-ice”, the indoor fan will either not operate or operate very slowly, then switch to the selected fan speed. This period is to allow the indoor unit's heat-exchanger to prewarm before emitting warm air.
***High temperature release function**: The outdoor unit for and compressor ON/OFF control for safety operation, when the over-heat is heat exchanger of indoor unit.
***De-ice**: Deicing operation is controlled by indoor unit's heat exchanger temperature and accumulating time of compressor's operation.
De-ice end by sensing of the processing time by de-ice Condition.




4. **DRY MODE** :
The unit operates in DRY mode.
***Compressor ON/OFF Time** is controlled compulsorily(can not set up the fan speed, always breeze).
***Protective function** : Low temperature release. (Prevention against freeze)
5. **TURBO MODE** : This mode is available in AUTO, COOL, HEAT, DRY, FAN MODE.
When this button is pressed at first, the air conditioner is operated “powerful” state for 30 minutes regardless of the set temperature, room temperature.
When this button is pressed again, or when the operating time is 30 minutes, turbo operation mode is canceled and returned to the previous mode.
***But**, if you press the TURBO button in DRY or FAN mode that is changed with AUTO mode automatically.
6. **SLEEP MODE** : Sleep mode is available only in COOL or HEAT mode.
The operation will stop after 6 hours.
***In COOL mode**: The setting temperature is automatically raised by 1°C each 1hour
When the temperature has been raised by total of 2°C, that temperature is maintained.
***In HEAT mode** : The setting temperature is automatically dropped by 1°C each 1hour.
When the temperature has been dropped by total of 2°C, that temperature is maintained.
7. **FAN SPEED** : Manual / Auto
Fan speed automatically varies depending on both the difference between setting and the room temperature.

8. COMPULSORY OPERATION :

For operating the air conditioner without the remote controller.

***AUTO** : The operating is the same function that AUTO MODE in the remote controller.

9. SWING : BLADE-H is rotated vertically by the stepping motor.

***Swing Set / Auto** : Press the  button under the remote control is displayed on LCD the  and the blades move up and down about 3°. If the one more time press the  button, blades location is stop.

10. Quick OFF TIMER: OFF timer (quick timer) allows reservation or cancel the timer on and timer off quickly

When OFF timer button is pressed at operating state, LCD displays the polling state sequentially.

The LCD also displays the time remaining.

















11. 24-Hour ON/OFF Real Setting Timer. : The air conditioner is turned ON at a specified time using **ON TIMER**.


OFF TIMER : The air Conditioner is turned OFF at a specified time using **OFF TIMER**.

***ON TIMER** : Only timer LED lights on.

***OFF TIMER** : Both timer and operation LED lights on.

12. SELF Diagnosis

LED DISPLAY				Check Point
operation	TIMER	FAN	Turbo	
				Interruption of electric power and Power on.
				Abnormal condition of the room sensor.
				Abnormal condition of the indoor unit's heat exchanger sensor.
				Indoor unit fan motor lock.

 : LED blinking  : LED off

13. BUZZER SOUND : Whenever the ON/OFF button is pressed or whenever change occurs to the condition which is set up or select, the compulsory operation mode, buzzer is sounded "beep"

3-2 Installation

3-2-1 Selecting Area for Installation

Select an area for installation that is suitable to the customer's needs.

3-2-1(a) Indoor Unit

1. Make sure that you install the indoor unit in an area providing good ventilation. It must not be blocked by an obstacle affecting the airflow near the air inlet and the air outlet.
2. Make sure that you install the indoor unit in an area allowing good air handling and endurance of vibration of the indoor unit.
3. Make sure that you install the indoor unit in an area where there is no source of heat or vapor nearby.
4. Make sure that you install the indoor unit in an area from which hot or cool air is spread evenly in a room.
5. Make sure that you install the indoor unit in an area away from TVs, audio units, cordless phones, fluorescent lighting fixtures and other electrical appliances (at least 1 meter).
6. Make sure that you install the indoor unit in an area which provides easy pipe connection with the outdoor unit, and easy drainage for condensed water.
7. Make sure that you install the indoor unit in an area which is large enough to accommodate the measurements shown in figure on the next page.

3-2-1(b) Outdoor Unit

1. Make sure that you install the outdoor unit in area not exposed to the rain or direct sun light.
(Install a separate sunblind if exposed to direct sun light.)
2. Make sure that you install the outdoor unit in area allowing good air moment, not amplifying noise or vibration, especially to avoid disturbing neighbours.

(Fix the unit firmly if it is mounted in a high place.)

3. Make sure that you install the outdoor unit in area providing good ventilation and which is not dusty. It must not be blocked by any obstacle affecting the airflow near the air inlet and the air outlet.
4. Make sure that you install the outdoor unit in area free from animals or plants.
5. Make sure that you install the outdoor unit in area not blocking the traffic.
6. Make sure that you install the outdoor unit in area easy to drain condensed water from the indoor unit.
7. Make sure that you install the outdoor unit in area which provides easy connection within the maximum allowable length of a coolant pipe(10 meters).

Note

1. Add (18XX:20g, 24XX:30g) of refrigerant (R-22) for every 1 meter if the pipe length exceeds the standard pipe length of 5 meters.
2. Maintain a height between the indoor and outdoor units of less than 3 meters.
8. Make sure that you install the outdoor unit in an area which is large enough to accommodate the measurements shown in figure on the next page.


3-2-1(c) Remote Control Unit

1. Make sure that you install the remote control unit in an area free from obstacles such as curtains etc, which may block signals from the remote control unit.
2. Make sure that you install the remote control unit in an area not exposed to direct sunlight, and where there is no source of heat.
3. Make sure that you install the remote control unit in an area away from TVs, audio units, cordless phones, fluorescent lighting fixtures and other electrical appliances (at least 1 meter).


Caution :

It is harmful to the air conditioner if it is used in the following environments: greasy areas (including areas near machines), salty areas such as coast areas, areas where sulfuric gas is present such as hot spring areas. Contact your dealer for advice.

3-2-2 Installation diagram of indoor unit and outdoor unit




3-2-2(a) Fixing the Installation Plate



1. Determine the position of the pipe and drain hose hole using the right figure and drill the hole with an inner diameter of 65mm so that it slants slightly downwards.


2. If you are fixing the indoor unit to a... Then follow Steps...

Wall	3.
Window frame	4 to 6.



3. Fix the installation plate to the wall in a manner appropriate to the weight of the indoor unit.

If you are mounting the plate on a concrete wall with anchor bolts, the anchor bolts must not project by more than 20mm.




4. Determine the positions of the wooden uprights to be attached to the window frame.

5. Attach the wooden uprights to the window frame in a manner appropriate to the weight of the indoor unit.

6. Using tapped screws, attach the installation plate to the wooden uprights, as illustrated in the last figure opposite.

3-2-2(b) Purging the Unit




On delivery, the indoor unit is loaded with an inert gas. All this gas must therefore be purged before connecting the assembly piping. To purge the inert gas, proceed as follows.

Unscrew the caps at the end of each pipe.

Result : All inert gas escapes from the indoor unit.

- To prevent dirt or foreign objects from getting into the pipes during installation, do NOT remove the caps completely until you are ready to connect the piping.

3-2-2(c) Connecting the Assembly Cable.




The indoor unit is powered from the outdoor unit via the assembly cable. If the outdoor unit is more than five metres away from the indoor unit, the cable must first be extended to a maximum of 15 metres.


1. Extend the assembly cable if necessary.
2. Open the front grille by pulling on the tabs on the lower right and left sides of the indoor unit.
3. Remove the screw securing the connector cover.
4. Pass the assembly cable through the rear of the indoor unit and connect the assembly cable to terminals 1 to 5.
 - Each wire is labelled with the corresponding terminal number.
5. Firmly fix the ass'y cable with clamp wire holder.
6. Pass the other end of the cable through the 65mm hole in the wall.
7. Replace the connector cover, carefully tightening the screw.
8. Close the front grille.
9. For further details on how to plug the other end of the assembly cable into the outdoor unit, refer to page 13.

3-2-2(d) Installing and Connecting the Indoor Unit Drain Hose


Care must be taken when installing the drain hose for the indoor unit to ensure that any condensation water is correctly drained outside. When passing the drain hose through the 65mm hole drilled in the wall, check that none of the following situations occur.




The hose must NOT slope upwards.




The end of the drain hose must NOT be placed in water.



Do NOT bend the hose in different directions.




Keep a clearance of at least 5cm between the end of the hose and the ground.



Do NOT place the end of the drain hose in a hollow.

To install the drain hose, proceed as follows.

1. If necessary, connect the 2-metre extension to the drain hose.
2. If you are using the extension, insulate the inside part of the extension drain hose with a shield.
3. Pass the drain hose under the refrigerant piping, taking care to keep the drain hose tight.
4. Pass the drain hose through the hole in the wall, making sure that it is sloping downwards, as shown in the illustrations above.




The hose will be fixed permanently into position once the whole installation has been tested for gas leaks; refer to page 16 for further details.

3-2-2(e) Outdoor unit installation


AUXILIARY POWER S/W

Auxiliary power S/W should be installed near indoor unit so that each access is possible. Main/Outdoor unit power cords are connected to upper/lower terminal of auxiliary power S/W.



WIRING CONNECTION


Indoor unit connector wire should be connected to both indoor unit connector and outdoor unit terminal board as shown in the figure below.



INSTALLATION OF DRAIN LINE


In heating and deice operation, condensed water may be generated. Install drain line as following procedure.

1. Insert the drain plug into base hole
2. And then connect drain hose to drain plug.



3-2-2(f) Flare Modification



• Tools used





Flare modification procedure

- 1) Cut the pipe using a pipe cutter.
- 2) Remove burrs at the tip of the pipe cut.

Caution : Burrs not removed may result in leakage of gas.




- 3) Insert a flare nut into the pipe and modify flare.






Outer diameter	A(mm)
ø6.35mm	1.3
ø9.52mm	1.8
ø12.7mm	2.0
ø15.8mm	2.2

* Unproper flaring





3-2-2(g) Air-Purge Procedure

- Use the refrigerant of the outdoor unit to purge air inside indoor unit and pipe.



3-2-2(h) Refrigerant Refill

- **Refill an air-conditioner with refrigerant when refrigerant has been leaked at installing or using**



3-2-2(i) Refrigerant Adjustment

Class	At installation		At service	
Connection Pipe Length	Air-Purge Method	Refrigerant Adjustment	Air-Purge Method	Refrigerant Quantity
5m Max.	Refer to the detailed Air-Purge Procedure	Unnecessary	Purge air using a vaccum pump or an additional refrigerant cylinder.	refer to specification sheet
5~10m		Add "A" of refrigerant (R-22) for every 1m.		Add "A" of refrigerant (R-22) for every 1m.



MODEL	"A"
AQ24A10E AQ24B10E	30g
AQ18A10E AQ18B10E	20g

3-2-2(j) Flare unt fixing torque

Outter diameter	Torque (kg-cm)	
	Fixing Torque	Final Torque
ø 6.35 mm (Liquid Side)	160	200
ø 9.52 mm (Gas Side)	300	350
ø 12.7 mm (Gas Side)	500	550
ø 15.8 mm (Gas Side)	700	750

3-2-2(k) "Pump down" Procedure

- **Pump down' shall be carried out when an evaporator is replaced or when the unit is relocated in another area.**






**Relocation of the air conditioner**






- Refer to this procedure when the unit is relocated.
- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Carry out the pump down procedure (refer to the details of 'pump down'). 2. Remove the power cord. 3. Disconnect the assembly cable from the indoor and outdoor units. 4. Remove the flare nut connecting the indoor unit and the pipe.
At this time, cover the pipe of the indoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering. | <ol style="list-style-type: none"> 5. Disconnect the pipe connected to the outdoor unit.
At this time, cover the valve of the outdoor unit and the other pipe using a cap or vinyl plug to avoid foreign material entering. 6. Make sure you do not bend the connection pipes in the middle and store together with the cables. 7. Move the indoor and outdoor units to a new location. 8. Remove the mounting plate for the indoor unit and move it to a new location. |
|--|---|

4. Disassembly and Reassembly


Stop operation of the air conditioner and remove the power cord before repairing the unit.

4-1 Indoor Unit



No	Parts	Procedure	Remark
1	Front Grille	<ol style="list-style-type: none"> 1) Stop the air conditioner operation and block the main power. 2) Seperate tape of front panel upper. 3) Contract the second finger to the left, and right handle and pull to open the inlet grille. 4) Take the left and right filter out. <div> <p>* Take the Deodorizing and Electrostatic filter out. (ONLY "1" and "5" Series models)</p> </div> 5) Loosen one of the right fixing screw and seperate the terminal cover. 6) Loosen two fixing screws of front grille. 7) Pull the upper left and right of discharge softly for the outside cover to be pulled out. 8) Pull softly the lower part of discharge and push it up. <p>Caution; Assemble the front panel and fix the hooks of left and right.</p>	    

No	Parts	Procedure	Remark
2	Ass'y Tray Drain.	<ol style="list-style-type: none"> 1) Do "1", above. Separate the drain hose from the extension drain hose. 2) Take the display PCB out. (Center of indoor unit) 3) Loosen two fixing screws of left and right 4) Pull tray drain out from the back body. 	 
3	Electrical Parts (Main PCB)	<ol style="list-style-type: none"> 1) Do "1", "2", above 2) Take all the connector of PCB upper side out. (Inclusion Power cord) 3) Separate the outdoor unit connection wire from the terminal block. 4) If pulling the Main PCB up. it will be taken out. (Separate the TRANS hook. it before). 	
4	Heat Exchanger	<ol style="list-style-type: none"> 1) Do "1" and "2", "3", above 2) Loosen two fixing earth screws of right side. 3) Separate the connection pipe. 4) Separate the bush body at the upper side and holder at the rearside. 5) Loosen the two fixing screws of left side. 6) Lifting the heat exchanger up a little to push the up side for separation from the indoor unit. 	 

Disassembly and Reassembly

No	Parts	Procedure	Remark
3	Fan Motor and Cross Fan	<ol style="list-style-type: none"> 1) Do "1" "2" "3" "4", above. 2) Loosen the fixing three screws and separate the motor holder. 3) Loosen the fixing screw of fan motor. (By use of M3 wrench) 4) Separate the fan motor from the fan. 5) Separate the fan from the left holder bearing. 	 




4-2 Outdoor Unit

No	Parts	Procedure	Remark
1	Cabinet	1) Turn off the unit and remove the power cable 2) Remove the top cover. 3) Remove the control box cover. 4) Unplug the ass'y cable. 5) Remove the cabi-side. 6) Remove the cabi-front. * When you assemble the parts, check if the each parts and electric connectors are fixed firmly.	
2	Fan Motor & Propeller Fan	1) Do Procedure 1 above. 2) Remove the nut flange. (Turn to the right to remove as it is a left turned screw) 3) Disassemble the propeller fan.	

5. Troubleshooting

5-1 Items to be checked first

- 1) **Is the voltage of the power correct?**
 The input voltage shall be rating voltage $\pm 10\%$.
 The airconditioner may not operate properly if the voltage is out of this range.
- 2) **Is the link cable linking the indoor unit and the outdoor unit linked properly?**
 The indoor unit and the outdoor unit shall be linked by 5 cables.
 Check the terminals if the indoor unit and outdoor unit are properly linked by the same number of cables.
 Otherwise the airconditioner may not operate properly.
- 3) **When a problem occurs due to the contents illustrated in the table below it is a symptom not related to the malfunction of the airconditioner.**

NO	Operation of air conditioner	Explanation
1	The COOL operation indication LED (Green) blinks when a power plug of the indoor unit is plugged in for the first time.	It indicates power is on. The LED stops blinking if the operation ON/OFF button on the remote control unit is pushed.
2	In a COOL operation mode, the compressor does not operate at a room temperature higher than the setting temperature that the IN DOOR FAN should operate. In a HEAT operation mode, the compressor does not operate at a room temperature lower than the setting temperature that indoor fan should operate.	It happens after a delay of 3 minutes when the compressor is reoperated. The same phenomenon occurs when a power is on. As a phenomenon that the compressor is reoperated after a delay of 3 minutes, the indoor fan is adjusted automatically with reference to a temperature of the air blew
3	Fan speed setting is not allowed in AUTO or DRY mode.  	The speed of the indoor fan is set to LL in DRY mode. Fan speed is 5 steps is selected automatically in AUTO mode.
4	Compressor stops operation intermittently in DRY mode. 	Compressor operation is controlled automatically in DRY mode depending on the room temperature and humidity.
5	Compressor of the outdoor unit is operating although it is turned off in a HEAT mode.	When the unit is turned off while de-ice is activated, the compressor continues operation for up to 9 minutes (maximum) until the deice is completed.
6	Timer LED only of the indoor unit lights up and the air conditioner does not operate.	Timer is being activated and the unit is in ready mode. The unit operates normally if the timer operation is cancelled.
7	The compressor and indoor fan stop intermittently in HEAT mode.	The compressor and indoor fan stop intermittently if room temperature exceeds a setting temperature in order to protect the compressor from overheated air in a HEAT mode.
8	Indoor fan and outdoor fan stop operation intermittently in a HEAT mode.	The compressor operates in a reverse cycle to remove exterior ice in a HEAT mode, and indoor fan and outdoor fan do not operate intermittently for within 20% of the total heater operation
9	The compressor stops intermittently in a COOL mode or DRY mode, and fan speed of the indoor unit decreases.	The compressor stops intermittently or the fan speed of the indoor unit decreases to prevent inside/outside air frozen depending on the inside/outside air temperature.

- 4) **Indoor unit observes operation condition of the air conditioner, and displays self diagnosis details on the display panel.**


NO	Display	Self Diagnosis
1	Operating LED blinking (1Hz)	Restore from power failure (input initial power)
2	TIMER LED blinking (1Hz)	Indoor unit Room sensor Error (open or short)
3	OPERATING and TIMER LED blinking (1Hz)	Indoor unit heat exchanger temperature sensor Error (open or short)
4	FAN LEA blinking (1Hz)	Indoor fan malfunctioning (for speed is Below 380rpm)

5-2 Fault Diagnosis by Symptom

5-2-1 No Power (completely dead)-Initial diagnosis

1) Checklist :

- (1) Is input voltage normal? (198-264A~)
- (2) Is AC power linked correctly?
- (3) Are connections between primary side, secondary side of the power transformer and PCB good.
- (4) Is output voltage of DC regulator IC KA7812 (IC01) normal? (11VDC-12.5VDC)
- (5) Is output voltage of DC regulator IC KA7805 (IC02) normal? (4.5VDC-5.5VDC)




5-2-2 When the Indoor Unit Fan Does Not Operate. (Initial Diagnosis)

1) Checklist :

- (1) Is the indoor unit fan motor properly connected with the connector (CN73)?
- (2) Is the AC voltage correct?
- (3) Is HALL IC in indoor fan motor properly connected with the connector (CN43)?
- (4) Is the running capacitor properly connected with the terminal?

2) Troubleshooting procedure




5-2-3 When the Outdoor Unit Does Not Operate. (Initial Diagnosis)

1) Checklist :

- (1) Is input voltage normal?(198-264VAC)
- (2) Is the set temperature of the remote control higher than room temperature in COOL mode?
- (3) Is the set temperature of the remote control lower than room temperature in HEAT mode?
- (4) Is the POWER IN connector (terminal-tab) linked correctly?
- (5) Is the outdoor unit properly connected with the TERMINAL BLOCK connector(5P)?

2) Troubleshooting procedure




5-2-4 When the UP/DOWN Louver Moter Does Not Operate. (Initial Diagnosis)

1) Checklist :

(1) Is input voltage normal? (198-264VAC)

(2) Is the UP/DOWN louver motor properly connected with the connector (CN61)?


2) Troubleshooting procedure



5-2-5 In the Heat mode, When there is no warm air current. Check this first;


(1) Is the set temperature of Remote Control lower than room temperature in Heat mode?

(2) Is the Indoor PCB properly connected with the CN71 and CN78 connector?



5-2-6 If Operation By Remote Control Unit Is Impossible. (Initial Diagnosis)

1) Troubleshooting procedure




5-3 PCB Inspection

5-3-1 Cautions for Part Replacement

1. The human body carries much static electricity. Before touching a part for repair, replacement or the similar purpose, be sure to touch a grounded metallic portion by hand to let the static electricity go through the metallic portion to the earth. Especially when handling any micro computer or IC, carefully remove such static electricity before touching them.
2. When repairing any part on a work bench, be sure to place an insulative sheet on the bench and always keep the sheet surface neat without any metal fragments. If any such fragment touches a part, a secondary trouble will possibly be caused in the part.
3. Before replacing any parts, be sure to turn off the power supply. If such replacement is done with the power supply kept on, an electric shock, short circuit or destruction of a part may result.
4. During replacement or repair of a part, carefully handle it : The printed circuit board has fine lead wires (jumper wires) and glass-made parts (diode) on its substrate. So if a circuit board is roughly handled, such lead wires and parts will be easily broken or damaged by bending or shock.
5. When soldering the lead wires of any new part, be sure to polish them using an emery paper or the like before soldering them. Since the lead wires of any new part are covered with an oxide film, solder cannot adhere to the lead wires if not polished.
6. When soldering any part, care should be exercised not to apply any high-wattage soldering iron to the part for a long time. Some parts are of so low a heat resistance that they may be broken or have the properties changed if a soldering iron is so applied (Otherwise, the pattern may possibly be separated and raised).
7. The heat of the soldering iron should be transferred to the entire object to be soldered. If the solder pieces are not well fused due to insufficient transfer of the heat from the soldering iron, no satisfactory electrical continuity can be assured even if the soldered objects appear well connected to each other.
8. The solder used should be limited to a minimum. If excessive solder is used, it will cause inter-pattern contact, which may cause malfunction of the circuit.

5-3-2 Procedure

The parts should be replaced in the following procedure.



5-3-3 Detailed Procedure


No.	Malfunction	Checking point (symptoms)	Causes
1	Pull out the power plug from the AC terminal and confirm the fuse on the PCB assembly	1. Is the broken?	1. Voltage over 2. Indoor unit fan motor short-circuit.
2	Turn the power on. If lamp blinks trouble is not related to the items 1 through 4 on the right.	Voltage check	
		1. AC voltage at both end of transformer Primary? 198 - 264V~	1. Irregular power code or power fuse, or poor wiring.
		2. AC voltage at both end of transformer secondary? 14- 18Vac	2. Transformer is faulty.
		3. DC voltage at OUT and GND of IC01 (KA7812)? 12VDC	3. Power circuit is faulty.
		4. DC voltage at OUT and GND of IC02? 5VDC	4. Power circuit is faulty.
		5. DC voltage at Q201 Base and GND change? squarewave	5. Q201 is faulty. D101~D104 (IN4007)
3	Set operating mode when RMC switch pushed. Except for [FAN]mode and [TIMER] mode.	Voltage check	
		1. Voltage of relay (RY71) coil Voltage at PIN#11, PIN#12, PIN#15 of IC07 : 12VDC	1. Relay(RY 71) coil is open. IC07 is faulty.
		2. Voltage at Terminal Tap (TB71 or 72) and RY71 Terminal NO④. 198- 264V~	2. Relay(RY 71) contactor is faulty.
4	Set operating mode when RMC switch pushed. 1. COOL mode 2. Fan speed [AUTO] 3. Set temperature lower than room temperature 4. Continuously operation.	1. Compressor does not operate.	1. Temperature of Heat exchange is lower. 2. PCB is faulty. 3. Room sensor or Heat exchanger temperature sensor is faulty
5	Set operating mode when RMC switch pushed. 1. HEAT mode 2. Fan speed [AUTO] 3. Set temperature higher than room temperature 4. Continuously operation	1. Compressor does not operate	1. Temperature of Heat exchange is higher. 2. PCB is faulty. 3. Room sensor or Heat exchanger temperature sensor is faulty
6	Set operating mode when RMC switch pushed. 1. [FAN] mode 2. Fan speed [Hi] 3. Continuously operation	1. Voltage at ③⑤ both ends of CN73 : above 180V~	1. Indoor unit fan motor is faulty.
		2. Indoor unit fan motor does not operate.	2. Poor connection of indoor fan motor and connector of RPM sensing (CN43)

5-4 Fault Diagnosis of Major Parts

Parts	Diagnosis		
Temp.Sensor Heat ex. Sensor Indoor Fan Motor Outdoor Fan Motor	Measure resistance with a tester.		
	Normal	8K ~27K at ambient temperature (+0°C ~ +30°C)	
	Abnormal	, 0 ... open or short	
	Measure resistance between terminals (CN72) with a tester		
	Normal	At ambient temperature (10°C ~ 30°C)	
		between	Resistance
		Red, Yellow	190±10
		Red, Blue	170±10
	Abnormal		
	Measure the voltage between ground and signal wire of the fan motor		
Normal	between	Voltage	
	Gray, Orange	05V~4.5V	
	Yellow, Orange	5V	
	Abnormal	Abnormal if voltage does not change from 0V to 5V.	
Normal	At ambient temperature (10°C ~ 30°C)		
	between	Resistance	
	Black, White	350±10	
	Black, Red	270±10	
Abnormal	, 0 ... open or short		
Stepping Motor (UP/DOWN swing motor)	Measure resistance between red wire and each terminal.		
	Normal	Approx. 380 at ambient temperature (20°C ~30°C)	
	Abnormal	, 0 ... open or short	

6. Exploded Views and Parts List

6-1 Indoor Unit




■ Parts List

No.	CODE NO	Description	Specification	Q'TY			
				AQ24A1QE	AQ24B1QE	AQ18A2QE	AQ18B1QE
1	DB64-10151A	GRILLE AIR INLET	HIPS	-	1	-	1
	DB64-10173A	GRILLE AIR INLET	HIPS	1	-	1	-
2	DB64-70077A	PANEL CENTER DISPLAY	PC	1	1	1	1
3	DB63-30150A	GUARD AIR FILTER	PP	2	2	2	2
4	DB74-10101A	CLEANER FILTER ASS'Y	ASS'Y	1	1	1	1
4-1	DB61-10164A	CASE-CLEANER FILTER	PP	2	2	2	2
4-2	DB74-10082A	DEODORIZING FILTER	POLYESTER/CARBON	1	1	1	1
4-3	DB74-10081A	CLEANER FILTER	POLYESTER/COTTON	1	1	1	1
5	DB63-10466A	COVER TERMINAL	ABS(V0)	1	1	1	1
6	DB92-70092E	ASS'Y FRONT PANEL	HIPS	1	1	1	1
7	DB93-10600A	ASS'Y PCB DISPLAY	AQ24B1QE/B	-	1	-	1
	DB93-10599A	ASS'Y PCB DISPLAY	AS24A1QE/B	1	-	1	-
8	DB94-10083B	ASS'Y TRAY DRAIN	ASS'Y	1	1	1	1
8-1	DB31-10144A	ASS'Y STEPING MOTOR	MP35EA	1	1	1	1
8-2	DB66-30181A	BLADE-H	ABS	1	1	1	1
9	DB75-40088A	ASS'Y EVAP	PLATE1.2(5/8")	1	1	-	-
	DB75-40087C	ASS'Y EVAP	SLIT1.5(1/2")	-	-	1	1
10	DB72-10235A	SEAL SPACER	FOAM-LEX	1	1	1	1
11	DB90-40162A	ASS'Y HOLDER MOTOR	ASS'Y	1	1	1	1
11-1	DB61-40264A	HOLDER MOTOR	PP(Vo)	1	1	1	1
11-2	DB65-10108A	CLIP EARTH WIRE	SECC	1	1	1	1
11-3	DB65-40063A	TERMINAL BLOCK ASS'Y	5P,25A	1	1	1	1
12	DB31-10151A	MOTOR FAN IN	IC-9430SKJ5A	1	1	1	1
13	DB94-30162A	ASS'Y-C-F-FAN	ø95 x L	1	1	1	1
14	DB90-40135A	ASS'Y HOLDER BEARING	ASS'Y	1	1	1	1
14-1	DB94-40003A	RUBBER BEARING	CR	1	1	1	1
14-2	DB61-40244A	HOLDER BEARING	PP	1	1	1	1
14-3	DB94-40007A	BEARING	PG5	1	1	1	1
15	DB93-10545A	ASS'Y MAIN PCB	AQ24B1QE/B	1	1	-	-
	DB93-10555A	ASS'Y MAIN PCB	AQ18B1QE/B	-	-	1	1
16	DB32-10008E	ASS'Y-TERMISTOR	103AT	1	1	1	1
17	DB61-10163A	CASE CONTROL	ABS(V0)	1	1	1	1
18	DB94-20037A	ASS'Y BACK BODY	HIPS	1	1	1	1
19	DB61-40246A	HOLDER PIPE	PP	1	1	1	1
20	DB70-10663A	PLATE HANGER	SGCC-M	1	1	1	1
21	DB26-10065B	TRANSFORMER	AC230V / DC17V	1	1	1	1

6-2 Outdoor Unit


6-2-1 UQ18A1QE/UQ18B1QE



■ Parts List(18K)

No.	CODE NO	Description	Specification	Q'TY
				UQ18A1QE/UQ18B1QE
1	DB90-10153J	ASS'Y-WELD FRONT	SC-90073T	1
2	DB90-20160D	ASS'Y-BASE OUT	SC-90073T	1
3	DB67-50063A	ASS'Y-FAN	AS+G/F20%	1
4	DB60-30020A	NET FLANGE	M6LF	1
5	DB31-10119C	MOTOR FAN OUT	AMASS-035AVEB	1
6	DB61-20008C	BASE-MOTOR	SGCC-M	1
7	DB94-50034A	PARTITION	SGCC-M	1
8	DB75-30103A	ASS'Y-CONDENSER	ASS'Y	1
9	DB90-40168A	COVER-CONTROL	ABS	1
10	DB90-10583A	CABI SIDE OUT	SC-90073T	1
11	DB90-40124A	TOP COVER	SC-90073T	1
12	DB95-10263B	COMPRESSOR	48B180JVIE7	1
12-1	DB73-10004A	GROMMET ISOLATOR	EPDM	3
12-2	DB60-30028A	NUT WASHER	M8	3
12-3	DB60-30018A	NUT FLANGE	PIO.8	1
12-4	DB63-10165A	COVER TERMINAL	NORYL	1
13	DB99-10134A	ASS'Y-4WAY V/V	ASS'Y	1
13-1	DB62-40074C	PACKED V/V 1/2"	10LT/MIN	1
13-2	DB62-40036A	4WAY V/V	CHV-0201	1
14	DB99-10136A	ASS'Y-CHECK V/V	ASS'Y	1
14-1	DB62-31800B	TUBE CAPI(C)	C1220T-0	1
14-2	DB62-40039B	PACKED V/V 1/4"	1/4 INCH	1
14-3	DB62-31802B	TUBE CAPI(H)	C1220T-0	1
15	DB93-40736A	ASS'Y CONTROL OUT	ASS'Y	1
15-1	DB34-90057C	SWITCH MAGNET	45CG20ALB	1
15-2	2501-001139	CAPACITOR DUAL	40/2.5, 450V	1
15-3	DB65-40022D	TERMINAL BLOCK	7P/20A	1
15-4	DB95-90026B	SPARK KILLER		1
15-5	3601-000236	FUSE	2A,250V	1
16	DB72-50537A	CLOTH SOUND	-	1
17	DB72-50544A	CLOTH SOUND UP	-	1
18-1	DB39-20546A	CONNECTOR POWER	3G,2.5mm2	1
18-2	DB39-10058A	CONNECTOR WIRE	4G,1.00mm2	1
18-3	DB39-20235A	CONNECTOR WIRE	2G,0.75mm2	1
18-4	DB67-20011A	DRAIN PLUG OUT	PP	1
18-5	DB63-10355C	CAP DRAIN	CR	1
18-6	DB60-30010A	NUT FLANGE 1/4"	C3771BD	1
18-7	DB60-30010C	NUT FLANGE 1/2"	C3771BD	1
19	DB63-30130C	SCREEN-GUARD	PHF 100Y	1
20	DB63-30025D	GUARD-COND	SC-90073T	1

6-2-2 UQ24A1QE/UQ24B1QE




■ Parts List(24K)

No.	CODE NO	Description	Specification	Q'TY
				UQ24A1QE/UQ24B1QE
1	DB90-10634B	ASS'Y WELD FRONT	SC-90073T	1
2	DB90-20210A	ASS'Y-BASE OUT	SC-90073T	1
3	DB67-50074A	ASS'Y-FAN	AS+G/F20%	1
4	DB60-20020A	BOLT SPECIAL	M8 L25	1
5	DB31-10110E	MOTOR FAN OUT	OSME-716SRC	1
6	DB95-20147A	ASS'Y-MOTOR B/K	SGCC-M	1
7	DB67-30081A	PARTITION	SGCC-M	1
8	DB75-30102A	ASS'Y-CONDENSER	ASS'Y	1
9	DB90-40168A	COVER-CONTROL	ASS'Y	1
10	DB90-10674A	CABI SIDE OUT	SC-90073T	1
11	DB90-10616A	TOP COVER	SC-90073T	1
12	DB95-10347A	COMPRESSOR	H25B30QABH	1
13	DB99-10149A	ASS'Y-4WAY V/V	ASS'Y	1
13-1	DB62-40055F	PACKED V/V5/8"	20LT/MIN	1
13-2	DB62-40036A	4WAY V/V	CHV-0201	1
14	DB99-10138A	ASS'Y-CHECK V/V	ASS'Y	1
14-1	DB62-31798C	TUBE CAPI(C)	C1220T-0	1
14-2	DB62-40039C	PACKED V/V 1/4"	1/4 INCH	1
14-3	DB62-31802A	TUBE CAPI(H)	C1220T-0	1
15	DB93-40735A	ASS'Y CONTROL OUT	ASS'Y	1
15-1	DB34-90054A	SWITCH MAGNET	41NB21AL	1
15-2	2501-001155	CAPACITOR DUAL	3.0/40μFx450VAC	1
15-3	DB65-40022D	TERMINAL BLOCK	7P	1
15-4	DB95-90026B	SPARK KILLER	-	1
15-5	3601-000236	FUSE	2A,250V	1
16	DB72-50615A	CLOTH SOUND COMP	-	1
17	DB72-50614A	CLOTH SOUND UP	-	1
18-1	DB39-20546A	CONNECTOR POWER	3G,2.5mm ²	1
18-2	DB39-10058A	CONNECTOR WIRE	4G,1.0mm ²	1
18-3	DB39-20235A	CONNECTOR WIRE	2G,0.75mm ²	1
18-4	DB67-20011A	DRAIN PLUG OUT	PP	1
18-5	DB60-30010A	NUT FLANGE 1/4"	C3771BD	1
18-6	DB60-30010D	NUT FLANGE 5/8"	C3771BD	1

6-3 Remote Control & PCB Box


6-3-1 Remote Control (DB93-30052E)



■ Parts List

No	CODE NO	Description	Specification	Q'TY	Remark
1	DB61-10144A	CASE UP	ABS	1	
2	DB61-10145A	CASE LOW	ABS	1	
3	DB64-20054A	DOOR REMOCON	ABS	1	
4	DB63-10477A	COVER BATTERY	ABS	1	
5	DB74-10084A	FILTER REMOCON	PC	1	
6	DB73-20110C	RUBBER REMOCON	SILICON	1	
7	DB64-40167A	INLAY LCD	PC	1	
8	DB64-40166B	INLAY REMOCON	PC	1	
9	DB68-10789B	LABEL REMOCON	ART 90	1	
10	DB68-10790B	LABEL DOOR	ART 90	1	
11	PH-M2	SCREW TAP	PH-M2	6	
12	DB67-60061A	SPRING BATTERY	SUS 304	1	
13	DB67-60062A	SPRING BATTERY	SUS 304	1	
14	DB67-60063A	SPRING BATTERY	SUS 304	1	
15	90 X 250	PE BAG	90 X 250	1	
16	DB93-40179C	ASS'Y PCB REMOCON		1	
17	DB61-40243A	HOLDER REMOCON	ABS	1	

6-3-2 PCB Box




■ Parts List

No	CODE NO	Description	Specification	Q'TY		Remark
				AQ24A1QE AQ24B1QE	AQ18A1QE AQ18B1QE	
1	DB61-10151A	CASE-CONTROL		1	1	
2	DB93-10545A	ASS'Y MAIN PCB	AQ24B1QE/B	1	-	
	DB93-10555A	ASS'Y MAIN PCB	AQ18B1QE/B	-	1	
3	DB32-10008E	ASS'Y THERMISTOR	103AT 240/240	1	1	
4	DB93-10600A	ASS'Y PCB DISPLAY	AQ24B1QE/B	1(B1)	1(B1)	
	DB93-10599A	ASS'Y PCB DISPLAY	AQ24A1QE/B	1(A1)	1(A1)	
5	DB26-10065B	TRANSFORMER	AC230V/DC17	1	1	

MEMO


7. Block Diagrams

7-1 Refrigerating Cycle Block Diagram



8. PCB Diagrams

8-1 Main PCB(DB93-10545B) : 24K BTU
(DB93-10555B) : 18K BTU




■ Parts List


No	DESIGN LOCATION	PART CODE NO	Description	Specification
1	F701	DE32-10037A	FUSE	FST 250V 3.15A
2	F701,F101	DE47-40024A	HOLDER-FUSE	FH-51H 7.5A
3	IC01	DE13-20008A	IC-VOLT REGU	KA7812A
4	IC01	DE62-30032A	HEAT-SINK	AL H25
5	IC01	DE60-10100A	SCREW-PH	M3*6 FeFzY
6	IC02	DE13-10016A	IC-VOLT REGU	KA7805A
7	CR71		C-FILM	COS 450V 1.2μF
8	FT71		FILTER NOISE	LSAO5230P 250V-2A 23mH*2
9	R903,904,905,906	2001-000776	R-CARBON	RD 1/2 T(S) 621-J
10	R203	2001-000588	R-CARBON	RD 1/4 TP 332-J
11	R202,301,409,501-509,513,519-525,601,604,606,902	2001-000065	R-CARBON	RD 1/4 TP 103-J
12	R405,407	2001-000036	R-CARBON	RD 1/4 TP 331-J
13	R201,204,405,401,402,404,603,606,608	2001-000042	R-CARBON	RD 1/4 TP 102-J
14	R607	2001-000855	R-CARBON	RD 1/4 TP 560-J
15	R602	2001-001088	R-CARBON	RD 1/2 T(S) 102-J
16	R403	2001-000890	R-CARBON	RD 1/4 TP 682-J
17	R910,912,913	A1000-0244	R-CARBON	RD 1/8 TP 332-J
18	R406,408	2004-001137	R-METAL FILM	RD 1/4 TP 682-F
19	D101-105	0402-000137	DIODE-RECT	1N4007
20	SS71	B4190-0016	THYRISTOR	G3MB-202PL
21	BZ61	DE30-20016A	BUZZER	CBE 2220BA STICK
22	C202,402	2202-000783	C-CERAMIC	CA OA 50V 103Z
23	C301,401	2202-000796	C-CERAMIC	CA OA 50V 102Z
24	C102,104,201,203,403,404,501,502,902	2202-000780	C-CERAMIC	CA OA 50V 104Z
25	C103	2401-000710	C-ELEC	CE04 25V 222-M
26	C105	2401-001397	C-ELEC	CE 04 25V 471-M
27	C101	2401-000180	C-ELEC	CE 04 35V 102-M
28	C601	2401-001573	C-ELEC	47/50V
29	IC04	DE09-10149A	IC-MCU	MB89635R-466
30	IC03	DE13-20009A	IC	KA7533Z
31	X501	2802-000103	RSONATOR-CERAMIC	10MHz
32	IC05,IC06,IC07	DE13-20024A	IC-DRIVE	KID65003AP
33	Q201,401,601,602	A4050-0168	TR-GENERAL	KSC945Y
34	Q603	0501-000292	TRANSISTOR	A708Y
35	Q902, Q901	0504-000144	TRANSISTOR	R2002
36	SW91	3404-001013	SWITCH-TACT	KPT-1115V
37	CN73	3711-000262	CONNECTOR WAFER	YW396-05AV WHT
38	CN43	3711-000879	CONNECTOR WAFER	SMW250-03 BLU
39	CN41	3711-000940	CONNECTOR WAFER	SMW250-04 WHT
40	CN61	3711-001038	CONNECTOR WAFER	SMW250-06 WHT
41	CN62	3711-001036	CONNECTOR WAFER	SMW250-06 BLUE
42	CN71		CONNECTOR WAFER	YW396-03AV BLK
43	CN92	3711-001154	CONNECTOR WAFER	SMW250-09 WHT
44	RY72,RY72,RY71	B3068-0092	RELAY	JQ1a-12V
45	J1-J35, HR01-HR04, LR01-LR04, OPJ1, OPJ2, OPJ3	DE39-60001A	WIRE SO COPER	PI0.6 SN T 52MM
46	CN72		CONNECTOR WAFER	YW396-03AV WHT
47	CN11		"	SMW250-03 RED
48	F101	DB47-90053A	FUSE	FST 250V-2A
49	IC08		EEORIM	93C5L
50	R903		R-CARBON	RD 1/2T(S) 471-J
51	C701	2305-001027	C-FILM, MPEF	224K
52	C702		"	104K

8-2 ASS'Y DISPLAY & Module

• Round/Semi-Round/Lip-Type (DB93-10600A)



• Edge Type (DB93-10599A)




■ Parts List

TYPE	NO	CODE-NO	Description	Specification	Q'TY
"Round" "Semi-Round" "Lip" Type (DB93-10600A)	1	DB41-10207A	PCB-DISPLAY	FR-1 T1.6 W16.5 L142.5	1
	2	DB07-10022A	LED - LAMP	LTL-52EG-002(ORG/GRN)	1
	3	0601-001059	LED - LAMP	SY5511(YEL)	1
	4	0601-001060	LED - LAMP	SM5511(GRN)	1
	5	0601-001196	LED - LAMP	SO5511(ORG)	1
	6		JUMP WIRE	6mm	5
	7	DB32-50021A	MODULE REMOCON	TSOP-1238UU1	1
	8	2001-000429	R-CARBON	RD 1/8TP 102-J	1
	9	2202-000780	C-CERAMIC	CA OA 50V 104Z	1
	10	2001-000034	R-CARBON	RD 1/8TP 221-J	1
	11		CONNECTOR-WAFER	YWLA200-09P	1
	12	2201-000283	C-CERAMIC	CA OA 50V 102Z	1
	13	0401-000005	DIODE SWITCHING	IN4148	1
	14	DB39-20520A	C/W DIS & MODULE	UL1007 AWG#26/9	1
	15	DB61-10194A	(R) CASE-CENTER PCB UP	PC(BLU)	1
	16	DB61-10195A	(R) CASE-CENTER PCB LOW	ABS(BLK)	1
	17	DB72-10238A	SEAL C/T PCB UP	30FOAM-PE, T=3	1
	18	DB72-10239A	SEAL C/T PCB LOW	30FOAM-PE, T=3	1
"Edge" Type (DB93-10599A)	1	DB41-10206A	PCB-DISPLAY	FR-1 T1.6 W13 L141	1
	2	DB07-10022A	LED - LAMP	LTL-52EG-002(ORG/GRN)	1
	3	0601-001059	LED - LAMP	SY5511(YEL)	1
	4	0601-001060	LED - LAMP	SM5511(GRN)	1
	5	0601-001196	LED - LAMP	SO5511(ORG)	1
	6		JUMP WIRE	6mm	3
	7	DB32-50021A	MODULE REMOCON	TSOP-1238UU1	1
	8	2001-000429	R-CARBON	RD 1/8TP 102-J	1
	9	2202-000780	C-CERAMIC	CA OA 50V 104Z	1
	10	2001-000034	R-CARBON	RD 1/8TP 221-J	1
	11		CONNECTOR-WAFER	YWLA200-09P	1
	12	2201-000283	C-CERAMIC	CA OA 50V 102Z	1
	13	0401-000005	DIODE SWITCHING	IN4148	1
	14	DB39-20520A	C/W DIS & MODULE	UL1007 AWG#26/9	1
	15	DB61-10192A	(R) CASE-CENTER PCB UP	PC(BLU)	1
	16	DB61-10193A	(R) CASE-CENTER PCB LOW	ABS(BLK)	1
	17	DB72-10240A	SEAL C/T PCB UP (L)	30FOAM-PE, T=3	1
	18	DB72-10240B	SEAL C/T PCB UP (R)	30FOAM-PE, T=3	1
	19	DB72-10239A	SEAL C/T PCB LOW	30FOAM-PE, T=3	1


9. Wiring Diagrams

9-1 Indoor Unit




9-2 Outdoor Unit

■ UQ24A1QE/UQ24B1QE



MARK	NAME	MARK	NAME
52C	MAGNETIC CONTACTOR	TB 1,2	TERMINAL BLOCK
20S	SOLENOID COIL	CH	CRANK CASE HEATER
C1	CAPACITOR	FM1	FAN MOTOR
F	FUSE(2A, 250V-)	S	SPARK KILLER
CAPACITOR		3.0/40MF X 450VAC	

■ UQ18A1QE/UQ18B1QE



MARK	NAME	MARK	NAME
52C	MAGNETIC CONTACTOR	TB 1, 2	TERMINAL BLOCK
20S	SOLENOID COIL	FM1	FAN MOTOR
F	FUSE(2A, 250V-)	S	SPARK KILLER
CAPACITOR		3.0/40MF X 450VAC	

UPDA TE LOG SHEET				
Application date	Page	Part#	Note(Cause & Solution)	S/Bulletin#

Use this page to keep any special servicing information. (Service Bulletin, etc.)

If only parts number changes, Just change parts number directly on parts list.

And if you need more information, please see the service bulletin

Copyright

© 1995 by Samsung Electronics Co., Ltd.

All rights reserved.

This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, or converted to any electronic or machine readable form without prior written permission of Samsung Electronics Co., Ltd.

SyncMaster 17GLi/CMG7387L Service Manual
First edition June 1995.

Printed in Korea.

Trademarks

Samsung is a registered trademark and SyncMaster 17GLi/CMG7387L and MacMaster Cable Adapter are trademark of Samsung Electronics Co., Ltd.

Macintosh, Centris, Quadra, Duo Dock, and Power Macintosh are trademark of Apple computer, Inc.

All other trademarks are the property of their respective owners.

10. Schematic Diagrams

10-1 Indoor Unit

