



## SERVICE PARTS LIST

PAGE 1 OF 2  
BULLETIN NO.  
54-24-5000

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS

### 1-1/8" ROTARY HAMMER

CATALOG NO. 5359-21

SERIAL  
NUMBER

409A

REVISED BULLETIN


DATE

July 2003

WIRING INSTRUCTION

58-01-1860

EXAMPLE:  
Component Parts (Small #)  
Are Included When Ordering  
The Assembly (Large #).



SEE PAGE 3 AND 4 OF THIS  
BULLETIN FOR SERVICE  
AND LUBRICATION NOTES

REFER TO 'TO INFORM  
YOU' BULLETIN #402 FOR  
INFORMATION REGARDING  
THE DISASSEMBLY OF THE  
SPINDLE AND THE ASSEM-  
BLY OF THE GEAR  
REDUCTION SHAFT.

REFER TO 'TO INFORM  
YOU' BULLETIN #403 FOR  
INSTRUCTIONS ON HOW TO  
CHECK THE STATIC SLIP OF  
THE CLUTCH MECHANISM.

FIG.	PART NO.	DESCRIPTION OF PART	QTY.
3	12-20-5359	SERVICE NAMEPLATE KIT	1
8	45-88-1245	WASHER	1
9	44-90-0340	SNAP RING (EXT.)	1
10	31-15-0257	CRANKCASE COVER	1
102	31-15-0255	BRUSH COVER	2
119	05-78-0745	TAPTITE SCREW	5
127	05-78-0715	SCREW	7
200	31-40-0042	GEARCASE	1
204	44-86-0625	SPLINED RETAINER	1
206	31-15-0307	CRANKCASE	1
208	45-88-8825	WASHER (ADD AS REQUIRED)	1
209	34-40-4440	O-RING	1
210	02-80-6025	THRUST BEARING SET	1
211	14-73-0247	WOBBLE SHAFT ASSEMBLY	1
212	36-66-3162	REDUCTION GEAR SHAFT	1
214	45-88-1250	WASHER	1
215	40-50-8897	SPRING	1
216	45-22-0302	COUPLING SLEEVE	1
218	36-92-0747	WOBBLE PLATE	1
219	32-60-2622	REDUCTION GEAR	1
220	32-60-2157	OFFSET GEAR	1
221	32-60-2165	INTERNAL GEAR	1
222	44-82-0192	RAM	1
223	44-62-0157	PISTON	1
224	44-60-1405	WRIST PIN	1
225	45-88-1180	WASHER	2
226	44-90-4500	SHIFT RING	1
228	44-60-1485	PIN	1
229	44-66-6055	RETAINING PLATE	1
232	38-50-0038	SDS SPINDLE	1
233	40-50-7977	BELLEVILLE SPRING	5
234	45-88-7767	STOP WASHER	1
235	22-75-1207	SPINDLE GEAR	1
236	44-90-4510	RETAINING RING (EXT.)	1
237	45-88-1255	WASHER	1
238	02-80-0150	THRUST BEARING	1
239	45-88-0775	RETAINING RING	1
241	44-82-0089	RAM CATCHER	1
243	42-76-0727	THRUST COLLAR	1
245	45-56-2537	STRIKER	1
248	45-88-1265	WASHER	1


FIG.	PART NO.	DESCRIPTION OF PART	QTY.
249	45-88-1264	STOPWASHER	1
251	02-50-2185	NEEDLE BEARING	2
253	31-86-0102	SPACER	1
255	40-50-8045	SPRING	1
256	02-02-0275	BALL	1
257	42-36-1755	SUPPORT PLATE	1
258	44-90-4285	HOLDING RING	1
259	45-88-1270	WASHER	2
261	44-10-0077	SHIFT LEVER	1
262	44-66-0101	PLATE	1
264	45-88-1181	WASHER	1
265	44-96-0101	ROLLER	4
266	02-02-0110	BALL	4
267	05-77-0030	BOLT	1
268	45-88-1182	WASHER	1
269	45-88-1183	WASHER	1
270	44-90-0115	RING	1
271	45-88-1184	WASHER	1
272	45-88-1185	WASHER	1
273	45-88-1186	WASHER	1
275	05-74-0700	SCREW	2
276	05-74-0717	SCREW	2
415	45-60-0511	BEARING ASSY	1
420	36-66-4267	INTERMEDIATE GEAR SET	1
426	45-88-1170	RETAINING RING	1
427	45-88-1280	WASHER	1
600	43-46-0172	DEPTH GAGE (NOT SHOWN)	1
701	49-15-5300	SIDE HANDLE (NOT SHOWN)	1
1100	31-44-5359	HANDLE SET	1
1204	34-40-4454	O-RING	1
1207	43-44-0375	GASKET	1
1209	34-40-5359	O-RING	1
1210	34-40-4452	O-RING	1
1211	34-40-4451	O-RING	1
1212	34-40-4459	O-RING	1
1213	34-40-4456	O-RING	1
1214	42-76-0275	COLLAR	1
1215	43-87-0080	ISOLATION BLOCK	1
1218	44-90-4415	RETAINING RING	1
1219	34-40-0130	O-RING	1
1220	05-74-0685	SOCKET HEAD SCREW	4
1222	05-74-0695	SOCKET HEAD SCREW	2
1223	05-74-0697	SCREW	2
1224	34-40-0132	O-RING	1
1225	45-06-0215	FELT WASHER	1
1226	44-90-0375	SNAP RING	1
1227	42-52-0065	DUST CAP	1

MILWAUKEE ELECTRIC TOOL CORPORATION  
13135 W. LISBON RD., BROOKFIELD, WI 53005

Drwg. 3

FIG.	PART NO.	DESCRIPTION OF PART	QTY.
3	12-20-5359	SERVICE NAMEPLATE KIT	1
4	22-64-0506	CORD SET	1
7	44-60-0015	GROOVED DOWEL PIN	1
100	31-50-0955	MOTOR HOUSING	1
105	18-07-0121	FIELD -SERVICE	1
116	31-05-0220	AIR DEFLECTOR RING	1
117	45-30-0210	SLUG	4
120	22-20-0232	BRUSH HOLDER	2
121	31-17-0184	WIRE CLAMP	1
122	23-94-1034	WIRE	1
123	42-70-1100	FIELD CENTERING CLIP	2
124	05-78-0747	SCREW	1
125	31-17-0240	CORD CLAMP	1
126	05-78-0720	SCREW	2
127	05-78-0715	SCREW	7
128	23-94-1037	WIRE	1
129	23-94-1042	WIRE	1
130	42-92-0015	BEARING COVER	1
131	45-88-1340	WASHER	1
135	23-66-1687	SWITCH	1
401	31-15-0442	MOTOR COVER	1
406	16-07-0123	ARMATURE - SERVICE	1
407	22-84-0940	FAN	1
408	02-04-1800	BALL BEARING	1
409	02-04-1817	BALL BEARING	1
410	43-06-0135	INSULATING DISC	1
413	45-22-0465	SLEEVE	1
414	45-36-1595	SPACER	1
420	36-66-4267	INTERMEDIATE GEAR SET	1
1100	31-44-5359	HANDLE SET	1
1201	22-18-0942	BRUSH (2) SERVICE KIT	1
1205	42-96-0170	BEARING CUP	1
1208	44-76-0285	STRAIN RELIEF	1
1216	45-30-0220	SLUG	2
1221	05-74-0705	SOCKET HEAD SCREW	4

**SEE BACK PAGE OF THIS BULLETIN  
FOR ADDITIONAL LUBRICATION  
AND SERVICE NOTES**




**Service Kit 14-46-5359 Contains:**

Qty.	Cat. No.	Description	Qty.	Cat. No.	Description
4	05-74-0685	Socket Head Screw	1	42-52-0065	Dust Cap
2	05-74-0695	Socket Head Screw	1	42-76-0275	Collar
2	05-74-0697	Screw	2	42-96-0170	Bearing Cup
4	05-74-0705	Socket Head Screw	1	43-44-0375	Gasket
1	22-18-0942	Brush Service Kit (2)	1	43-87-0080	Isolation Block
1	34-40-0130	O-Ring	1	44-76-0285	Strain Relief
1	34-40-0132	O-Ring	1	44-90-0375	Snap Ring
1	34-40-4451	O-Ring	1	44-90-4415	Retaining Ring
1	34-40-4452	O-Ring	1	45-06-0215	Felt Washer
1	34-40-4454	O-Ring	2	45-30-0220	Slug
1	34-40-4456	O-Ring	2	45-88-1180	Washers
1	34-40-4459	O-Ring	1	49-08-4250	Type "P" Grease (1.5 oz.)
			1	49-08-4255	Type "Q" Grease (1.5 oz.)

## 5359-21

1. To remove the gearcase (200), remove the retaining ring (1226), shift lever (261), plate (262) and screws (1223).
2. To remove the spindle (232), the two mounting bolts (275) must be removed with a metric allen wrench.
3. To remove the ram (222), tap the end of the striker (245) with a hammer, this frees the ram from the ram catcher. Ram may be found in piston rather than in ram catcher.
4. To remove the ram catcher (241), striker (245) and stop washer (249) from the spindle (232), remove the internal retaining ring (1218) with a small screwdriver by pushing on the ring through the two small ports in the spindle where the ring is visible. Push the ring in and towards the open end of the spindle, use service tool 61-10-0185 if necessary. Press out all internal parts.
5. To remove the rear thrust bearing (238), remove the spiral lock retaining ring (239) with a screwdriver and then remove the thrust bearing.
6. To remove the spindle gear/clutch (235), press the spindle gear against the disk springs (233) and remove the retaining ring (236) that fits into the gear counter bore.
7. To remove the wobble shaft assembly (211), turn the shaft so the wobble finger of the wobble plate (218) leans toward the motor housing (100). Pull out on the shaft, tilt and wiggle it to get it to clear the crankcase (206).
8. To disassemble the wobble shaft assembly (211), press the reduction gear (219) off, remove all remaining parts.
9. To remove the bearing housing (415), try turning it by twisting on the lugs by hand. If it can be moved, continue to twist and pull to remove. If it will not move, it must be removed with an internal bearing puller.
10. When removing the intermediate shaft assembly (420), note the number of shim washers (427) that are between the snap ring (426) and the bearing of the assembly. Be sure to return them all when reassembling the tool.
11. To remove the handle (1100), push out dowel pin (7), open handle, remove snap ring (9) and washer (8) from the isolation block (1215), disconnect field leads under motor cover (401) and remove handle.
12. To remove motor, remove two screws (1222) from the top of the crankcase (206) and 4 screws (127) from deep pockets in motor cover (401). Slide motor and motor housing out of crankcase.
13. To remove armature (406) from motor assembly, pull brushes (1201) off of commutator, push back brush holders (120) to provide clearance for insulating disc (410), slide bearing cover (130) from under insulating disc (410) and slide armature out.
14. When reassembling bearing housing (415) to crankcase (206) do not press it completely into place before the piston (223) and wobble shaft (211) are in place.
15. Shim washers (427) as required, maximum of 2.

16. When reassembling the wobble shaft assembly (211), a clearance of .001 to .003 inch must be maintained between the reduction gear (219) and the inner race of the wobble plate (218). The ground side of the gear must face the wobble plate.
17. Before assembling wobble shaft assembly (211) to crankcase (206), assemble the loose rollers that support the drive gear end of the wobble shaft in their shell in the crankcase. Hold the rollers in place with grease.  
(Tool may not have loose rollers)
18. When reassembling the clutch be sure to stack the disk springs (233), as shown.
19. Thrust bearing (238) on the spindle (232) must be assembled as shown.
20. To push the internal retaining ring (1218) into the spindle (232) that retains the striker (245), stop washer (249) and ram catcher (241), use an old, used piston. The position of the ring can be visually checked by looking in the removal ports.
21. Seal of sleeve (413) to face bearing (409).
22. Check slugs (117 and 1216), replace if worn or missing.
23. Bearing Cup (1205) to be placed in motor cover (401) before assembly.



**SEE BACK PAGE OF THIS BULLETIN  
FOR ADDITIONAL LUBRICATION  
AND SERVICE NOTES**

**GREASING INSTRUCTIONS:**  
**5359-21**

**Type "P" Grease (Cat. No. 49-08-4250)**


- 1. Place 1/2 oz. at needle bearing / splined retainer area of gearcase (200).
- 2. Grease assembled wobble shaft (211) with 1/2 oz. of grease.
- 3. Place 1/8 oz. in armature pinion / intermediate shaft assembly (420) cavity.
- 4. Place 1/4 oz. of grease in wobble shaft drive gear cavity of crankcase (206).
- 5. Grease clutch (235) and clutch springs (233) on spindle (232) with 1/8 oz. of grease.

NOTE: Total amount used; 1 1/2 oz. (one complete tube)

**Type "Q" Grease (Cat. No. 49-08-4255)**

- 1. Coat the spindle (232) inside and out.
- 2. Coat all parts assembled on or in spindle except for clutch.
- 3. Coat piston (223) (inside and out), ram (222), wrist pin (224) and wrist pin washers (225). DO NOT coat the flat face of the ram.

NOTE: Total amount used; 3/4 oz. (1/2 of a full tube)



Torque (in lb.)	Description	Thread Locking Sealant
22	Motor/armature bolts (2)	None
22	Motor housing bolts (4)	None
9	Cord Clamp screws (2)	None
85	Anti-vibration post (1)	None
10	Handle screws (3)	None
16	Motor cover screws (4)	None
50	Spindle retaining bolts (2)	Blue
22-26	Gearcase screws (4)	None