

INSTALLATION INSTRUCTIONS

MIR289705999

Winter Haven & Bridgehurst 1/2" Pressure Balanced Mixing Valve Rough Less Diverter



THANK YOU FOR CHOOSING MIRABELLE

We appreciate your commitment to Mirabelle quality. To ensure that your installation proceeds smoothly, please read these instructions before you begin.


Carefully unpack and examine all of the package contents.


Thanks again for choosing Mirabelle.


ALL INSTALLATION PROCEDURES MUST COMPLY IN STRICT ACCORDANCE WITH APPLICABLE LOCAL PLUMBING AND BUILDING CODES.



TP 050 A051







BEFORE YOU BEGIN

READ ALL DIRECTIONS PRIOR TO INSTALLATION. ANY ALTERATIONS MADE TO THE VALVE OR CARTRIDGE OR FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE DAMAGE OR IMPROPER INSTALLATION AND WILL NULLIFY THE WARRANTY AS WELL AS INCREASE THE RISK OF SCALDING.

Observe and adhere to all local plumhing codes.

Pressure-balancing valves are designed for use with hot water supplied from pressurized storage heaters and gamen in orginardion with low-pressure storage heaters (displacement water heaters).

Refer to the protective cover (mud gard) markings for proper installation depth. This cover <u>must</u> remain in place for plastering and/or tiling etc.

If PEX (plastic) pipes are to be used, do not use PEX with a diameter of less than 3/4" between the valve and the tub spout (4-Port valves only). Smaller diameter pipes and fittings will cause stacking in the shower outlet, it is not necessary to remove the pressure-balancing cartiridge from the valve during normal soldering of connections, someocitons using propane-butane gas. **DO NOT USE OXYGEN-ACETYLENE**. When soldering connections,

do not use excessive heat.

Ensure that the stop ring is correctly installed per the instructions below, otherwise a user could potentially diseasoage the carridge with minimal force to the external handle. This would cause the valve to fall and the user would be unable to turn the water on/off or control the temperature. It is recommended that the pipes be flushed clean prior to installation, in order to avoid any problems later

SPECIFICATIONS

20psi[140KPa] 125psi[860KPa] 500psi[3450KPa] 180°F[80°C] Max. Operating pressure: Max. Burst pressure: Max. Hot water temp.: Min. Operating pressure:

Flow rate in USGPM [I/min] @ 50 psi [345 KPa]:

3-Port: 6 4-Port(S): 5.5 4-Port(T): 6 Diverter(S): 5.5				[23] 7.5		
	司	3-Port: 6	4-Port (S): 5.5	4-Port (T): 6	Diverter (S): 5.5	Diverter (T): 6

ROUGH-IN NOTES

When installing 4-Port (4P) and Diverter (ID) valves, please ensure that the "S" is up and "T" is down.

Open the valve counterclockwise to verify the changes in outlet water temperature. The cartridge driver can be used to turn the cartridge stem.

To test pipe joints, and to inspect for any other possible leaks, pressurize both the hot and cold inlets before attaching the outer trim components.

For installations where the hot and cold water supplies are reversed, turn off the hot/cold water supplies and then simply take out the cartridge, rotate it 180° and re-insert as shown below.



STOP RING INSTALLATION

Ensure that the stop ring (3) is correctly installed as follows:

 Rotate the cartridge stem (11) fully <u>clockwise</u>.
 Position the stop ring on the stem such that it rests against the stop post (12). The stop ring must be correctly installed **before** the outer trim is installed.



See the trim installation instructions included with the trim components to properly install the hot limit stop.

INSTALLATION PROBLEMS

If water continuously drips from the spout or showerhead and/or there is reduced water flow:

 Remove the cartridge and inserts. Turn off the water supplies.

- Check for debris in the valve body, inserts &
 - Inspect all o-rings for damage.
- Re-grease with silicone-based grease only.
 Re-install the inserts and the cartridge.

For additional troubleshooting help, please go to www.tempressltd.com or call 1-866-853-8725. We reserve the right to charge specifications without notice. Some waskes may not appear exactly as schown. Valence and carridges are warranted to be frow from manufacturing objects for a period of 13 months from the date of manufacture. Additional warrantees may apply. All warranty concerns must be directed inough the original opini of purchase.