

# Installation/Operation

*Applies to:*

**Standard Power Vent Unit Heaters:**

**Separated Combustion Unit Heaters:**

**NOTE:**

Accessories referenced in this installation manual may not apply to all models.



## **WARNING:**

### **FIRE OR EXPLOSION HAZARD**

Failure to follow safety warnings exactly could result in serious injury, death, or property damage.

Be sure to read and understand the installation, operation, and service instructions in this manual.

Improper installation, adjustment, alteration, service, or maintenance can cause serious injury, death, or property damage.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Leave the building immediately.
  - Immediately call your gas supplier from a phone remote from the building. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

# Table of Contents

<b>1. General</b> .....	<b>2–4</b>	<b>7. Electrical Supply and Wiring</b> .....	<b>16–22</b>
1.1 Hazard Labels and Notices .....	2	7.1 General .....	16
1.2 General Installation Information.....	3	7.2 Supply Wiring.....	17
1.3 Warranty .....	4	7.3 24V Control Wiring Connections.....	17
1.4 Installation Codes .....	4	7.4 Wiring Diagrams .....	18
<b>2. Unit Heater Location</b> .....	<b>4–6</b>	7.5 Electrical Operating Components.....	21
2.1 Heater Throw .....	4	<b>8. Controls and Operation</b> .....	<b>22–26</b>
2.2 Location Recommendations.....	5	8.1 Thermostat .....	22
<b>3. Uncrating and Preparation</b> .....	<b>6–7</b>	8.2 DDC Controls, Options D10 and D14 .....	23
3.1 Uncrating and Inspecting.....	6	8.3 Ignition System .....	24
3.2 Preparing for Installation .....	6	<b>9. Commissioning and Startup</b> .....	<b>27–28</b>
<b>4. Clearances and Dimensions</b> .....	<b>7–9</b>	9.1 Check the installation prior to startup:.....	27
4.1 Clearances.....	7	9.2 Heater Startup:.....	27
4.2 Dimensions .....	8	9.3 Check installation after startup:.....	28
<b>5. Hanging the Heater</b> .....	<b>10–11</b>	<b>10. Maintenance and Service</b> .....	<b>29–36</b>
5.1 Weights .....	10	10.1 Maintenance Schedule .....	30
5.2 Lifting and Suspending.....	10	10.2 Maintenance Procedures .....	31
<b>6. Mechanical</b> .....	<b>11–16</b>	10.3 Troubleshooting .....	36
6.1 Gas Piping and Pressures .....	11	<b>APPENDIX</b> .....	<b>38</b>
6.2 Combustion Air—Standard Power Vent and Standard Power Vent with CV Option Models	16	<b>Index</b> .....	<b>39</b>
		<b>INSTALLATION RECORD</b> .....	<b>40</b>

## 1.0 General

### 1.1 Hazard Labels and Notices

There are warning labels on the unit and throughout this manual. For your safety, read the definitions below and comply with all boxes labeled CAUTION, WARNING, and DANGER during installation, operation, maintenance, and service of this heater.

#### Definitions of Hazard Intensity Levels in this Manual

##### HAZARD INTENSITY LEVELS

- 1. DANGER:** Failure to comply will result in severe personal injury or death and/or property damage.
- 2. WARNING:** Failure to comply could result in severe personal injury or death and/or property damage.
- 3. CAUTION:** Failure to comply could result in minor personal injury and/or property damage.

##### WARNING

Gas-fired appliances are not designed for use in hazardous atmospheres containing flammable vapors or combustible dust, in atmospheres containing chlorinated or halogenated hydrocarbons, or in applications with airborne silicone substances (see Hazard Levels, above).

##### WARNING

Should overheating occur, or the gas supply control system fail to shut off the flow of gas, shut off the manual gas valve to the utility heater before shutting off the electrical supply.

## 1.2 General Installation Information

**BOTH this manual and the correct venting manual are REQUIRED for installation of this heater.**

### Venting Manual by Model Type

#### WARNING

**Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and replace any gas control that has been under water.**

#### CAUTION

**Unit heaters should not be installed in an environment where the ambient temperature is below 50°F. The low space temperature may result in condensate forming in the heat exchanger.**

#### 1.2.1 Certification




Models 30, 45, 60, 75, 100, and 125 are design certified by the Canadian Standards Association for use in residential, industrial, and commercial installations. Utility heaters certified for “residential use” are intended for heating of non-living spaces that are attached to, or part of a structure that contains space for family living quarters. They are not intended to be the primary source of heat in residential applications or to be used in sleeping quarters.

Models 150, 175, 200, 225, 250, 300, 350, and 400 are design certified by the Canadian Standards Association for use in industrial and commercial installations only.

All models and sizes are available for use with either natural or propane gas. The type of gas, the gas input rate, and the electrical supply requirement are shown on the heater rating plate. Check the rating plate to verify that the heater is appropriate for the installation site.

#### 1.2.2 Venting Manual

Installation requires both this manual **AND** the venting manual.

Venting Instruction Manuals	Look for Matching Label on Venting Manual and Heater
<b>for Indoor Power Vent Units:</b> Standard Power Vent Installation (each heater has its own dedicated vent)	Label with a <b>RED SQUARE</b> 
<b>for Indoor Fan Assist Units:</b> (Sizes 30, 45, 60, 75 & 100 only) Common Vent Installation (with Option AV6)	Label with a <b>BLUE TRIANGLE</b> 
<b>for Combustion Air Inlet Units:</b> Separated Combustion (with field installed Option CC2, CC6, or CC14 Vent/Combustion Air Kit)	Label with a <b>GREEN CIRCLE</b> 

**Both this installation manual and the appropriate venting manual are shipped with the heater. Verify that the literature is correct for the heater being installed. If either manual is missing or incorrect, contact your distributor before beginning installation.**

The instructions in this manual apply **only** to the models listed.

Installation should be done by a qualified agency in accordance with these instructions. The qualified service agency installing this heater is responsible for the installation.

## 1.0 General (cont'd)

## 1.4 Installation Codes

### Special Installations (Aircraft Hangars/ Repair Garages/ Parking Garages)

### California Warning Label

### Massachusetts Requirement

## 2.0 Unit Heater Location

### 2.1 Heater Throw

FIGURE 1 - Throw for  
Fan Models

## 1.3 Warranty

Refer to the limited warranty information on the Warranty Card in the "Literature Bag".

### Warranty is void if ...

- Wiring is not in accordance with the diagram furnished with the heater.
- The unit is installed without proper clearance to combustible materials.
- A fan model is connected to a duct system or if the air delivery system is modified.

These units must be installed in accordance with local building codes. In the absence of local codes, in the United States, the unit must be installed in accordance with the National Fuel Gas Code, ANSI Z223.1. A Canadian installation must be in accordance with the CSA B149 Installation Codes. These codes are available from CSA Information Services, 1-800-463-6727. Local authorities having jurisdiction should be consulted before installation is made to verify local codes and installation procedure requirements.

Installations in aircraft hangars should be in accordance with ANSI/NFPA No. 409 (latest edition), Standard for Aircraft Hangars; in public garages in accordance with ANSI/NFPA No. 88A (latest edition), Standard for Parking Structures; and for repair garages in accordance with ANSI/NFPA No. 88B (latest edition), Standard for Repair Garages. In Canada, installations in aircraft hangars should be in accordance with the requirements of the enforcing authorities, and in public garages in accordance with CSA B149 codes.

If the heater is being installed in the state of California, the installer **MUST** attach a warning label on the outside of the access door. The California Warning label is shipped in the literature bag along with this manual, the warranty form, and any other paperwork that applies.


If installation is in California, select a location on the heater access panel. Be sure the surface is clean and dry and adhere the label.

If the heater is being installed in the Commonwealth of Massachusetts, these units must be installed by a licensed plumber or licensed gas fitter.

Use the sound data in Technical Data table in the APPENDIX (page 38), clearances in Paragraph 4.1; the combustion air requirements in Paragraph 6.2; the throw tables, mounting height requirements, and location recommendations in Paragraphs 2.1 and 2.2; the weights in Paragraph 5.1; and the venting requirements in the Venting Manual to determine where to suspend the heater.

### CAUTION

Unit heaters should not be used in an application where the heated space temperature is below 50°F. Operating under low ambient conditions may cause condensation to form in the heat exchanger.



**NOTE:** Throws listed are with standard adjustable horizontal louvers at the angles listed (angle is relative to the top of the heater). Throw pattern changes with the addition of optional vertical louvers and/or downturn nozzles.

Dimensions X, Y, and Z (feet) Models with Standard Horizontal Louvers at Mounting Heights of 5–18 ft																																
H	30				45				60				75				100				125											
	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*								
5 ft	6	14	30	−21°	7	16	40	−20°	8	18	45	−16°	9	20	57	−14°	9	20	59	−18°	10	22	65	−14°								
8 ft	7	13	26	−39°	9	16	37	−34°	10	18	42	−29°	12	22	54	−25°	11	21	56	−28°	12	23	63	−24°								
10 ft	6	11	22	−52°	9	15	33	−43°	10	17	39	−37°	12	22	52	−32°	12	20	52	−36°	13	24	60	−30°								
12 ft	—	—	—	—	8	12	27	−55°	10	16	34	−46°	12	21	48	−39°	11	19	47	−44°	14	23	57	−36°								
14 ft	—	—	—	—	—	—	—	—	9	14	29	−56°	12	19	44	−46°	11	17	42	−51°	14	22	53	−43°								
16 ft	—	—	—	—	—	—	—	—	—	—	—	—	11	17	38	−54°	10	14	34	−58°	13	20	47	−50°								
18 ft	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	11	17	40	−57°								
H	150				175				200				225				250				300				350				400			
	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*	X	Y	Z	Louver Angle*
8 ft	13	24	73	−26°	15	28	90	−22°	16	30	93	−20°	14	27	86	−24°	16	29	93	−21°	15	28	94	−24°	17	31	105	−20°	18	34	113	−17°
10 ft	14	24	69	−32°	17	29	87	−27°	17	31	91	−25°	15	27	82	−30°	17	30	90	−26°	16	28	89	−29°	18	32	103	−25°	20	35	110	−21°
12 ft	14	24	64	−39°	18	29	84	−32°	18	31	88	−30°	16	27	78	−35°	18	30	87	−31°	17	28	85	−34°	19	32	98	−30°	21	36	108	−25°
14 ft	14	22	59	−45°	18	28	79	−37°	19	30	84	−34°	16	26	73	−41°	18	30	83	−36°	17	27	80	−40°	20	32	95	−34°	23	35	105	−29°
16 ft	13	20	53	−51°	18	27	74	−42°	19	29	79	−39°	16	24	67	−47°	19	28	78	−41°	17	25	74	−45°	21	31	90	−38°	23	35	101	−33°
18 ft	11	17	44	−58°	17	26	68	−48°	19	28	74	−44°	14	22	60	−53°	18	27	72	−46°	16	24	66	−51°	20	30	85	−43°	23	35	97	−37°

Dimensions X, Y, and Z (meters) Models with Standard Horizontal Louvers at Mounting Heights of 1.5–5.5M																																
H	30				45				60				75				100				125											
	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°								
1.5 M	1.8	4.3	9.1	−21°	2.1	4.9	12.2	−20°	2.4	5.5	13.8	−16°	2.7	6.1	17.4	−14°	2.7	6.1	18.0	−18°	3.0	6.7	19.9	−14°								
2.4 M	2.1	4.0	7.9	−39°	2.7	4.9	11.3	−34°	3.0	5.5	12.8	−29°	3.7	6.7	16.5	−25°	3.4	6.4	17.1	−28°	3.7	7.0	19.2	−24°								
3.0 M	1.8	3.4	6.7	−52°	2.7	4.6	10.0	−43°	3.0	5.2	11.9	−37°	3.7	6.7	15.8	−32°	3.7	6.1	15.8	−36°	4.0	7.3	18.3	−30°								
3.7 M	—	—	—	—	2.4	3.7	8.2	−55°	3.0	4.9	10.4	−46°	3.7	6.4	14.6	−39°	3.4	5.8	14.3	−44°	4.3	7.0	17.4	−36°								
4.3 M	—	—	—	—	—	—	—	—	2.7	4.3	8.8	−56°	3.7	5.8	13.4	−46°	3.4	5.2	12.8	−51°	4.3	6.7	16.1	−43°								
4.9 M	—	—	—	—	—	—	—	—	—	—	—	—	3.4	5.2	11.6	−54°	3.0	4.3	10.4	−58°	4.0	6.1	14.3	−50°								
5.5 M	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	3.4	5.2	12.2	−57°								
H	150				175				200				225				250				300				350				400			
	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°	X	Y	Z	Louver Angle°
2.4 M	4.0	7.3	22.3	−26°	4.6	8.5	27.4	−22°	4.9	9.1	28.0	−20°	4.3	8.2	26.2	−24°	4.9	8.8	28.3	−21°	4.6	8.5	28.7	−24°	5.2	9.4	32.0	−20°	5.5	11.3	34.4	−17°
3.0 M	4.3	7.3	21.0	−32°	5.2	8.8	26.6	−27°	5.2	9.4	27.7	−25°	4.6	8.2	25.0	−30°	5.2	9.1	27.4	−26°	4.9	8.5	27.1	−29°	5.5	9.8	31.4	−25°	6.1	10.7	33.5	−21°
3.7 M	4.3	7.3	19.5	−39°	5.5	8.8	25.6	−32°	5.5	9.4	26.8	−30°	4.9	8.2	23.8	−35°	5.5	9.1	26.5	−31°	5.2	8.5	25.9	−34°	5.8	9.8	29.9	−30°	6.4	11.0	32.9	−25°
4.3 M	4.3	6.7	18.0	−45°	5.5	8.5	24.1	−37°	5.8	9.1	25.6	−34°	4.9	7.9	22.3	−41°	5.5	9.1	25.3	−36°	5.2	8.2	24.4	−40°	6.1	9.8	29.0	−34°	7.0	10.7	32.0	−29°
4.9 M	4.0	6.1	16.2	−51°	5.5	8.2	22.6	−42°	5.8	8.8	24.1	−39°	4.9	7.3	20.4	−47°	5.8	8.5	23.8	−41°	5.2	7.6	22.6	−45°	6.4	9.4	27.4	−38°	7.0	10.7	30.8	−33°
5.5 M	3.4	5.2	13.4	−58°	5.2	7.9	20.7	−48°	5.8	8.5	22.6	−44°	4.3	6.7	18.3	−53°	5.5	8.2	21.9	−46°	4.9	7.3	20.1	−51°	6.1	9.1	25.9	−43°	7.0	10.7	26.9	−37°

## 2.2 Location Recommendations

**NOTE: Venting requirements may affect location. Consult the Venting Manual for this heater before making final determination.**

Locate the heater so that it is a minimum of five feet (1.5M) above the floor and in compliance with the clearances in Paragraph 4.1.

### WARNING

**If touched, the vent pipe and internal heater surfaces that are accessible from outside the heater will cause burns. Suspend the heater a minimum of 5 feet (1.5M) above the floor.**

For best results, the heater should be placed with certain rules in mind. In general, a unit should be located from 8 to 12 feet (2.4–3.7M) above the floor. Units should always be arranged to blow toward or along exposed wall surfaces, if possible. Where two or more units are installed in the same room, a general scheme of air circulation should be maintained for best results.

Suspended heaters are most effective when located as close to the working zone as possible, and this fact should be kept in mind when determining the mounting heights to be used. However, care should be exercised to avoid directing the discharged air directly on the room occupants.

Partitions, columns, counters, or other obstructions should be taken into consideration when locating the unit heater so that a minimum quantity of airflow will be deflected by such obstacles.

## 2.0 Unit Heater Location (cont'd)

### 2.2 Location Recommendations (cont'd)

**Hazards of Chlorine -  
applies to Separated  
Combustion Heaters  
location with regard to  
the combustion air inlet**

## 3.0 Uncrating and Preparation

### 3.2 Preparing for Installation

#### 3.2.1 Field-Installed Parts

When units are located in the center of the space to be heated, the air should be discharged toward the exposed walls. In large areas, units should be located to discharge air along exposed walls with extra units provided to discharge air in toward the center of the area.

At those points where infiltration of cold air is excessive, such as at entrance doors and shipping doors, it is desirable to locate the unit so that it will discharge directly toward the source of cold air from a distance of 15 to 20 feet (4.6–6.1M).

---

**CAUTION: Do not locate the heater where it may be exposed to water spray, rain, or dripping water.**

---

For a location where dirt, dust, or other airborne contaminants are present in the indoor environment, it is recommended to install a separated-combustion unit, Separated Combustion model, that uses outside air for combustion. Using a separated-combustion unit will reduce the build-up of contaminants on the burner. Any buildup on the burner will adversely affect the combustion process.

The presence of chlorine vapors in the combustion air of gas-fired heating equipment presents a potential corrosion hazard. Chlorine found usually in the form of freon or degreaser vapors, when exposed to flame will precipitate from the compound, and go into solution with any condensation that is present in the heat exchanger or associated parts. The result is hydrochloric acid which readily attacks all metals including 300 grade stainless steel. Care should be taken to separate these vapors from the combustion process. This may be done by wise location of the unit vent and combustion air terminals with regard to exhausters or prevailing wind directions. Chlorine is heavier than air. Keep these facts in mind when determining installation location of the heater in relation to building exhaust systems.

### 3.1 Uncrating and Inspecting

This unit was test operated and inspected at the factory prior to crating and was in operating condition. If the heater has incurred any damage in shipment, document the damage with the transporting agency and contact an authorized Distributor. If you are an authorized Distributor, follow the FOB freight policy procedures.

Check the rating plate for the gas specifications and electrical characteristics of the heater to be sure that they are compatible with the gas and electric supplies at the installation site.

Read this booklet and become familiar with the installation requirements of your particular heater. If you do not have knowledge of local requirements, check with the local gas company or any other local agencies who might have requirements concerning this installation. Before beginning, make preparations for necessary supplies, tools, and manpower.

**IMPORTANT: Shipping brackets are attached with cabinet screws. When removing shipping brackets, re-insert ALL screws into the cabinet.**

Models with Separated Combustion: In the literature bag, find three cap screws, **PN 203311**, and three sealing washers, **PN 61658**. After attaching the hanging hardware (Paragraph 5.2), these screws and washers must be used to seal the unused holes in the top of the heater.

Models with Standard Power Vent: If the installation includes optional vertical louvers, downturn nozzle, ceiling mounting bracket, hanger kit, high altitude kit, multiple heater control, sensor for DDC control, and/or stepdown transformer, **install these options before the heater is suspended**. Complete instructions are in this form or in the option package; option packages are shipped separately.

Other shipped separate items: Could include a vent cap (Standard Power Vent heaters with Option CC1); a vent/combustion air kit (Separated Combustion heaters with Option CC2 or CC6); a manual gas valve; a thermostat bracket kit; a thermostat; and/or a thermostat guard. Be sure all options ordered are at the installation site.

### High Altitude Kit, Option DJ20 or DJ21

If the heater is being installed at an elevation above 2000 ft (610M), the input rate will have to be derated. This is done by adjusting the valve outlet pressure.

In addition, if the heater is being installed at an altitude above 6000 ft (1830M), the pressure switch will have to be changed. If ordered with the unit as Option DJ20 or DJ21, the pressure switch is shipped separately for field installation.

**Gas valve adjustment for high altitude can only be done after heater is operating (see Paragraph 6.1)**

Adjusting the valve outlet pressure is done after the heater is in operation; follow the instructions in Paragraph 6.1. Capacities and inputs for derated units are also listed in Paragraph 6.1.

If the pressure switch needs to be changed, do that before the heater is operated; follow the instructions in **FIGURE 2**.

**FIGURE 2 - Installing High Altitude Pressure Switch required above 6000 ft (1830M) elevation**



**Pressure Switch**

Standard Power Vent Models														
Size	30	45	60	75	100	125	150	175	200	225	250	300	350	400
High Altitude Switch PN	197031		197032		197031		201160							
Negative Pressure OFF Setpoint "w.c.	0.35		0.45		0.35		1.05							
Label color	Purple		Pink		Purple		Brown							
Standard Power Vent Models with Option AV6 for Common Venting														
Size	30	45	60	75	100									
High Altitude Switch PN	197029	197032	196362	196388										
Negative Pressure OFF Setpoint "w.c.	0.60	0.45	0.55	0.50										
Label color	Lt Blue	Pink	White	Orange										
Separated Combustion Models														
Size	30	45	60	75	100	125	150	175	200	225	250	300	350	400
High Altitude Switch PN	197029				196388	197030	197031	201160						
Differential Pressure OFF Setpoint "w.c.	0.60				0.50	0.40	0.35	1.05						
Label color	Lt. Blue				Orange	Green	Purple	Brown						

#### Instructions for Changing Pressure Switch

1. In the control compartment, locate the pressure switch.
2. Mark and disconnect the two wires attached to the pressure switch.
3. Disconnect the sensing tubes from the pressure switch.
4. Locate the two screws holding the switch mounting bracket. Remove the screws and the pressure switch. Save the screws.
5. Using the same screws, install the high altitude pressure switch. Attach the sensing tubes and wires.

**Downturn Nozzle Kits, Option CD 2, 3, or 4**  
(NOTE: Application specific)

Follow the instructions with the kit to install. Additional length beyond the front of the unit is shown in **FIGURE 3**.

**FIGURE 3 - With Optional Downturn Nozzle Dimension "U"—Applies to Standard Power Vent (except as specified) and Separated Combustion Models**

Downturn nozzles require 4-pt suspension.				
Size	Options CD2 and CD4		Option CD3	
	inches	mm	inches	mm
30, 45	7-1/8	181	12-3/8	314
60, 75	8-5/8	219	15	381
100, 125	12-5/8	321	21-7/8	556
150, 175, 200	11-1/2	292	19-7/8	505
225, 250	14-1/2	368	25-1/8	638
300, 350, 400	18-1/2	470	32	813

## 4.0 Clearances and Dimensions

### 4.1 Clearances

Units must be installed so that the clearances in the table are provided for combustion air space, inspection and service, and for proper spacing from combustible construction. Clearance to combustibles is defined as the minimum distance from the heater to a surface or object that is necessary to ensure that a surface temperature of 90°F (50°C) above the surrounding ambient temperature is not exceeded.

#### Clearances

Size	Top		Flue Connector		Access Panel		Non-Access Side		Bottom*		Rear**	
	inches	mm	inches	mm	inches	mm	inches	mm	inches	mm	inches	mm
30–125	1	25	6	152	18	457	1	25	1	25	18	457
150–400	4	102	6	152	18	457	2	51	1	25	18	457

\*Suspend the heater so that the bottom is a minimum of 5 feet (1.5M) above the floor.


\*\*Measure rear clearance from the fan motor.



## 4.0 Clearances and Dimensions (cont'd)

### 4.2 Dimensions

**FIGURE 4 - Standard Power Vent Models**



**Standard Power Vent Model Dimensions (inches ±1/16)**


Size	A	B	C	D	E	F	G	H	J	K	M	N	P	Q	R
30, 45	12-1/8	26-5/8	10	13-13/16	26	21-9/16	5-3/16	6-1/2	2-11/16	3-7/8	17-3/8	11/16	4-5/16	13	9-9/16
60	15-1/8	26-5/8	13	13-13/16	27	21-9/16	7-7/8	6-1/2	5-1/2	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2
75	15-1/8	26-5/8	13	13-13/16	27-5/8	21-9/16	7-7/8	6-1/2	5-1/2	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2
100	23-1/8	26-5/8	21	13-13/16	28-5/8	21-9/16	14-1/2	6-1/2	8-3/4	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2
125	23-1/8	26-5/8	21	13-13/16	29-3/8	21-9/16	14-1/2	6-1/2	8-3/4	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2
150, 175, 200	20-1/8	38-3/16	16	23	42	35-3/8	8-1/2	8-1/4	5-7/16	6-1/2	25-11/16	1-3/8	8-3/16	22-3/16	16-3/8
225, 250	26-1/8	38-3/16	22	23	42	35-3/8	13-1/16	8-13/16	9	6-1/2	25-11/16	1-3/8	8-3/16	22-3/16	15-5/8
300, 350, 400	34-1/8	41	30	23	42	35-3/8	17-1/16	9	11-13/16	7-5/16	27-11/16	1-3/8	8-3/16	22-3/16	16-3/16

**Standard Power Vent Model Dimensions (mm ±2)**

Size	A	B	C	D	E	F	G	H	J	K	M	N	P	Q	R
30, 45	308	676	254	351	660	548	132	165	68	98	441	17	110	330	243
60	384	676	330	351	686	548	200	165	140	98	441	17	110	330	267
75	384	676	330	351	702	548	200	165	140	98	441	17	110	330	267
100	587	676	533	351	727	548	368	165	222	98	441	17	110	330	267
125	587	676	533	351	746	548	368	165	222	98	441	17	110	330	267
150, 175, 200	511	970	406	584	1067	899	216	210	138	165	652	35	208	564	416
225, 250	664	970	559	584	1067	899	332	224	229	165	652	35	208	564	397
300, 350, 400	867	1041	762	584	1067	899	433	229	300	186	703	35	208	564	411



**FIGURE 5 - Separated Combustion Models**



**Separated Combustion Model Dimensions (inches  $\pm 1/16$ )**

Size	A	B	C	D	E	F	G	H	J	K	M	N	P	Q	R	S	T
30, 45	12-1/8	26-5/8	10	13-13/16	26	21-9/16	5-3/16	6-1/2	2-11/16	3-7/8	17-3/8	11/16	4-5/16	13	9-9/16	2-15/16	2-15/16
60	15-1/8	26-5/8	13	13-13/16	27	21-9/16	7-7/8	6-1/2	5-1/2	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2	3-1/4	2-15/16
75	15-1/8	26-5/8	13	13-13/16	27-5/8	21-9/16	7-7/8	6-1/2	5-1/2	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2	3-1/4	2-15/16
100	23-1/8	26-5/8	21	13-13/16	28-5/8	21-9/16	14-1/2	6-1/2	8-3/4	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2	4-5/8	2-15/16
125	23-1/8	26-5/8	21	13-13/16	29-3/8	21-9/16	14-1/2	6-1/2	8-3/4	3-7/8	17-3/8	11/16	4-5/16	13	10-1/2	4-5/8	2-15/16
150, 175, 200	20-1/8	38-3/16	16	23	42	35-3/8	8-1/2	8-1/4	5-7/16	6-1/2	25-11/16	1-3/8	8-3/16	22-3/16	16-3/8	4-1/8	8-5/16
225, 250	26-1/8	38-3/16	22	23	42	35-3/8	13-1/16	8-13/16	9	6-1/2	25-11/16	1-3/8	8-3/16	22-3/16	15-5/8	5-9/16	8-5/16
300, 350, 400	34-1/8	41	30	23	42	35-3/8	17-1/16	9	11-13/16	7-5/16	27-11/16	1-3/8	8-3/16	22-3/16	16-3/16	9-1/16	8-9/16

**Separated Combustion Model Dimensions (mm  $\pm 2$ )**

Size	A	B	C	D	E	F	G	H	J	K	M	N	P	Q	R	S	T
30, 45	308	676	254	351	660	548	132	165	68	98	441	17	110	330	243	75	75
60	384	676	330	351	686	548	200	165	140	98	441	17	110	330	267	89	75
75	384	676	330	351	702	548	200	165	140	98	441	17	110	330	267	89	75
100	587	676	533	351	727	548	368	165	222	98	441	17	110	330	267	117	75
125	587	676	533	351	746	548	368	165	222	98	441	17	110	330	267	117	75
150, 175, 200	511	970	406	584	1067	899	216	210	138	165	652	35	208	564	416	105	211
225, 250	664	970	559	584	1067	899	332	224	229	165	652	35	208	564	397	141	211
300, 350, 400	867	1041	762	584	1067	899	433	229	300	186	703	35	208	564	411	230	217

## 5.0 Hanging the Heater

### 5.1 Weights

Before suspending the heater, check the supporting structure to be used to verify that it has sufficient load-carrying capacity to support the weight of the unit.

#### Standard Power Vent Model

Size	30	45	60	75	100	125	150	175, 200	225	250	300	350	400
lb	54	59	67	72	96	101	172	187	203	215	269	294	306
kg	24	27	30	33	44	46	78	85	92	98	122	133	139

#### Separated Combustion Model

Size	30	45	60	75	100	125	150	175, 200	225	250	300	350	400
lb	55	60	68	73	97	102	173	188	204	216	270	295	307
kg	25	27	31	33	44	46	78	85	93	98	122	134	138

### WARNINGS

**Check the supporting structure to be used to verify that it has sufficient load carrying capacity to support the weight of the unit. Suspend the heater only from the threaded nut retainers or with a manufacturer provided kit. Do NOT suspend from the heater cabinet.**

#### 5.1.1 Field-Removal of Heat Exchanger Tube Support—Model Sizes 30–125 (Optional)

In some cases, the heat exchanger tubes could shift during shipment, causing vibration noise against the support during unit operation. The primary function of the heat exchanger tube support is to support the heat exchanger tubes during shipment. This support can be removed without affecting the operation of the unit. ***It is recommended that the support be removed prior to installing the unit.***

Listed below is the steps needed to remove this support:


- Remove the discharge air louvers. Be careful not to lose the springs.
- Remove and discard the two screws located on top of the unit that secure the heat exchanger support.
- Remove the heat exchanger support through the discharge opening and discard the support.
- Reinstall the discharge air louvers.

### 5.2 Lifting and Suspending

When the heater is lifted for suspension, support the bottom of the heater with plywood or other appropriately placed material. If the bottom is not supported, damage could occur. Before hanging, verify that any screws used for holding shipping brackets were re-installed in the cabinet.

**Separated Combustion Models:** Whether using the suspension points or a hanger kit, when installing a Separated Combustion Model, any **unused suspension points on the control side of the heater MUST be plugged**. Plug these holes with the 1/2" long cap screws and flat washers shipped in the bag with the heater (see **FIGURE 6**).

**FIGURE 6 - Separated Combustion Models—Plug the unused suspension points on the control side of the heater with the three 1/2" long screws, PN 203311, and the three sealing washers, PN 61658. Find the screws and washers in the literature bag shipped inside the heater.**




### WARNING

**Unit must be level for proper operation. Do not place or add additional weight to the suspended heater (see Hazard Levels, page 2).**

### 5.2.1 Two-Point or Four-Point Suspension

The heater is equipped for either two-point or four-point suspension. A 3/8"-16 threaded nut retainer is located at each suspension point. **NOTE:** Four-point suspension is **required** when installing an optional downturn nozzle (see Dimensions in Paragraph 4.2 and the illustration in **FIGURE 7A**).


**FIGURE 7A -**  
Suspending the  
Heater with Rods from  
the Threaded Nut  
Retainers (either two or  
four point suspension)



### 5.2.2 Hanger Kits, Option CK8, CK10, and CK22


If ordered with swivel connectors for 1" pipe, Option CK8 or CK10, attach the swivels at the threaded nut retainers. Suspend with 1" pipe (see **FIGURE 7B**).

**FIGURE 7B - Swivel**  
Connectors to Suspend  
the Heater from 1"  
Pipe, Option CK8 (2-pt)  
or CK10 (4-pt)



If ordered with a ceiling suspension kit, Option CK22, follow the illustrated instructions in the kit (see **FIGURE 8**).

**FIGURE 8 - Suspending**  
the Heater using  
Option CK22, Ceiling  
Suspension Kit (no  
hanger rods)



## 6.0 Mechanical

### 6.1 Gas Piping and Pressures

#### 6.1.1 Gas Supply and Connections

#### **WARNING**

This appliance is equipped for a maximum gas supply pressure of 1/2 psi, 3.5 kPa, or 14 inches water column. Supply pressure greater than 1/2 psi requires installation of an additional lockup-type service regulator external to the unit.

#### **WARNING: PRESSURE TESTING SUPPLY PIPING**

**Test Pressures Above 1/2 PSI:** Disconnect the heater and manual valve from the gas supply line which is to be tested. Cap or plug the supply line.

**Test Pressures Below 1/2 PSI:** Before testing, close the manual valve on the heater.

## 6.0 Mechanical (cont'd)

## 6.1 Gas Piping and Pressures (cont'd)

### 6.1.1 Gas Supply and Connections (cont'd)

#### Sizing Gas Supply Line

Capacity of Piping												
Cubic Feet per Hour based on 0.3" w.c. Pressure Drop												
Specific Gravity for Natural Gas: 0.6 (Natural Gas: 1000 BTU/Cubic Ft)												
Specific Gravity for Propane Gas: 1.6 (Propane Gas: 2550 BTU/Cubic Ft)												
Length of Pipe	Diameter of Pipe											
	1/2"		3/4"		1"		1-1/4"		1-1/2"		2"	
	Natural	Propane	Natural	Propane	Natural	Propane	Natural	Propane	Natural	Propane	Natural	Propane
20'	92	56	190	116	350	214	730	445	1100	671	2100	1281
30'	73	45	152	93	285	174	590	360	890	543	1650	1007
40'	63	38	130	79	245	149	500	305	760	464	1450	885
50'	56	34	115	70	215	131	440	268	670	409	1270	775
60'	50	31	105	64	195	119	400	244	610	372	1105	674
70'	46	28	96	59	180	110	370	226	560	342	1050	641
80'	43	26	90	55	170	104	350	214	530	323	990	604
90'	40	24	84	51	160	98	320	195	490	299	930	567
100'	38	23	79	48	150	92	305	186	460	281	870	531
125'	34	21	72	44	130	79	275	168	410	250	780	476
150'	31	19	64	39	120	73	250	153	380	232	710	433
175'	28	17	59	36	110	67	225	137	350	214	650	397
200'	26	16	55	34	100	61	210	128	320	195	610	372
Note: When sizing supply lines, consider possibilities of future expansion and increased requirements.												
Refer to National Fuel Gas Code for additional information on line sizing.												

All piping must be in accordance with requirements outlined in the National Fuel Gas Code ANSI/Z223.1a (latest edition) or CSA-B149.1 and B149.2 (see Paragraph 2). Gas supply piping installation should conform with good practice and with local codes. Support gas piping with pipe hangers, metal strapping, or other suitable material; do not rely on the heater to support the gas pipe.

The heater is orificed for operation with natural gas having a heating value of 1000 ( $\pm$  50) BTU per cubic ft or propane gas with a heating value of 2500 ( $\pm$ 100) BTU per cubic ft. If the gas at the installation does not meet these specifications, consult the factory for proper orificing.

Pipe joint compounds (pipe dope) shall be resistant to the action of liquefied petroleum gas or any other chemical constituents of the gas being supplied.

Install a ground joint union and manual shutoff valve upstream of the unit control system, as shown in **FIGURE 9**. Installation of a trap with a minimum 3" (76 mm) drip leg is required.

The unit is equipped with a nipple that extends outside the cabinet. The gas connection is either 1/2" or 3/4".

Leak-test all connections by brushing on a leak-detecting solution.

#### WARNING


**All components of a gas supply system must be leak tested prior to placing equipment in service. NEVER TEST FOR LEAKS WITH AN OPEN FLAME. Failure to comply could result in personal injury, property damage or death.**

#### Gas Connection Size

Gas Connection (inches)		
Size	Natural	Propane
30, 45, 60, 75, 100, 125, 150, 175, 200	1/2	1/2
225, 250, 300, 350, 400	3/4	3/4

**FIGURE 9 - Gas connection is at the pipe nipple that extends outside the cabinet.**

Illustration shows both a vertical and horizontal gas supply; requirements are the same.



Measuring valve outlet gas pressure cannot be done until the heater is in operation. It is included in the steps of the "Check-Test-Start" procedure in Paragraph 9. The following warnings and instructions apply.

### WARNING

**Valve outlet gas pressure must never exceed 3.5" w.c. for natural gas and 10" w.c. for propane gas. Maximum inlet supply pressure for natural gas or propane is 14" w.c. Maximum gas pressure can never be exceeded either during operation or static (lock up regulator).**

**For Natural Gas:** When the heater leaves the factory, the combination gas valve is set so that the valve outlet gas pressure for a single-stage valve or high fire of a two-stage valve is regulated to 3.5" w.c. Low fire on a two-stage valve is set to 1.8" w.c. Inlet supply pressure to the valve for natural gas must be a minimum of 5" w.c. or as noted on the rating plate and a maximum of 14" w.c.

**For Propane Gas:** When the heater leaves the factory, the combination gas valve is set so that the valve outlet gas pressure for a single-stage valve or high fire of a two-stage valve is regulated to 10" w.c. Low fire on a two-stage valve is set to 5.0" w.c. Inlet supply pressure to the valve for propane gas must be a minimum of 11" w.c. and a maximum of 14" w.c.

Before attempting to measure or adjust valve outlet gas pressure, the inlet supply pressure *must* be within the specified range both when the heater is in operation and on standby. Incorrect inlet pressure could cause excessive valve outlet gas pressure immediately or at some future time. If natural gas supply pressure is too high, install a regulator in the supply line before it reaches the heater. If natural gas supply pressure is too low, contact your gas supplier.


### Instructions

**NOTE:** If operating at high altitude, outlet pressure requires adjustment. Follow instructions on page 14.

- 1) Locate the 1/8" output pressure tap on the valve (see **FIGURE 10**). With the manual valve turned off to prevent flow to the gas valve, connect a manometer to the 1/8" pipe outlet pressure tap in the valve. **NOTE:** A manometer (fluid-filled gauge)

**Check Valve Outlet Pressure (can only be done after heater is operating)**

**FIGURE 10 - Top View of Valves showing Outlet Pressure Tap and Adjustment Locations**



## 6.0 Mechanical (cont'd)

### 6.1 Gas Piping and Pressures (cont'd)

#### 6.1.2 Valve Outlet or Orifice Pressure Setting (cont'd)

#### 6.1.3 Derate by Valve Outlet Pressure Adjustment for High Altitude Operation

This adjustment can only be done after the heater is in operation. High altitude adjustment is included in the startup Steps.

**NOTE:** If elevation is above 6000 ft (1830M), a high altitude pressure switch is required (see Paragraph 3.2.1).

is recommended rather than a spring type gauge due to the difficulty of maintaining calibration of a spring type gauge.

- 2) Open the manual valve and operate the heater. (NOTE: On a Separated Combustion Model, depress and hold the door safety switch.) Measure the outlet pressure of the gas valve. To measure low-stage pressure on a unit equipped with a two-stage valve, disconnect the wire from the "HI" terminal on the valve. (Be sure to reconnect the wire.)

Normally when operating at sea level, adjustments should not be necessary to the factory setting (for high altitude settings, see next paragraph).

If adjustment is necessary, remove the cap from the adjustment screw(s). Set pressure to correct settings by turning the regulator screw IN (clockwise) to increase pressure. Turn regulator screw OUT (counterclockwise) to decrease pressure.

**CAUTION: DO NOT bottom out the gas valve regulator adjusting screw. This can result in unregulated manifold pressure causing excess overfire and heat exchanger failure.**

#### Instructions for High Altitude Derate

1. Determine the required valve outlet pressure for the elevation where the heater will be operating. If unsure of the elevation, contact the local gas supplier.

#### Valve Outlet Pressure Settings by Elevation

Manifold Pressure Settings by Altitude for the UNITED STATES					
Altitude		Natural Gas (inches w.c.)		Propane Gas (inches w.c.)	
Feet	Meters	Single-Stage and Two-Stage High Fire	Two-Stage Low Fire	Single-Stage and Two-Stage High Fire	Two-Stage Low Fire
0-2000	0-610	3.5	1.8	10.0	5.0
2001-3000	611-915	3.1	1.6	8.8	4.4
3001-4000	916-1220	3.0	1.5	8.5	4.2
4001-5000	1221-1525	2.8	1.5	8.1	4.1
5001-6000	1526-1830	2.7	1.4	7.7	3.9
6001-7000	1831-2135	2.6	1.3	7.4	3.7
7001-8000	2136-2440	2.5	1.3	7.1	3.5
8001-9000	2441-2745	2.4	1.2	6.7	3.4
9001-10000	2746-3045	2.3	1.2	6.7	3.4

Manifold Pressure Settings by Altitude for CANADA					
Altitude		Natural Gas (inches w.c.)		Propane Gas (inches w.c.)	
Feet	Meters	Single-Stage and Two-Stage High Fire	Two-Stage Low Fire	Single-Stage and Two-Stage High Fire	Two-Stage Low Fire
0-2000	0-610	3.5	1.8	10.0	5.0
2001-4500	611-1373	2.8	1.5	8.1	4.1

2. Locate the 1/8" output pressure tap on the valve (see **FIGURE 10**, page 13). Turn the knob or switch on the top of the valve to "OFF". Connect a manometer to the 1/8" pipe outlet pressure tap in the valve. Use a water column manometer that is readable to the nearest tenth of an inch.
3. **Single-Stage and Two-Stage High Fire:** Turn the knob or switch on the top of the valve to "ON". Remove the cap from the pressure adjusting screw and adjust the gas train pressure to the pressure selected from the table above. Adjust pressure by turning the regulator screw IN (clockwise) to increase pressure or OUT (counterclockwise) to decrease pressure.

**Two-Stage Low Fire:** Disconnect the wire from the "HI" terminal on the gas valve and check the low fire pressure. Turn the regulator screw to adjust the low fire outlet pressure to the "Low Fire" pressure selected from the table. Re-connect the wire to the gas valve.

4. Turn up the thermostat. (**NOTE:** On a Separated Combustion model, depress and hold the door safety switch.) Cycle the burner once or twice to properly seat the adjustment spring in the valve.

Re-check the pressure(s). When the outlet pressure is right for the installation, remove the manometer and replace the cap.

Check for leak at the pressure tap fitting.

- With the heater operating determine that the inlet pressure to the heater for natural gas is between 5 and 13.5 inches w.c. and for propane between 11 and 13.5 inches w.c. Take this reading as close as possible to the heater (Heaters are equipped with gas valves that have an inlet pressure tap.) If the inlet pressure is not within the specified range, the inlet pressure must be corrected and Steps 3 and 4 repeated.
- Find the High Altitude Adjustment label in the plastic bag that contained these instructions. Using a permanent marker, fill-in the appropriate information from the tables below. Select a location for the label on the outside of the heater access panel so that it will be conspicuous to anyone operating or servicing the unit. Be sure the surface is clean and dry and adhere the label.

## High Altitude Capacity Changes

The input and/or the capacity of the heater changes with the derate. The tables below list inputs and capacities at altitudes from sea level to 10,000 ft (3045M).

BTUH Inputs and Capacities by Altitude in the UNITED STATES for all Models														
ALTITUDE		Normal Input	Thermal Output Capacity	Minimum Input	Normal Input	Thermal Output Capacity	Minimum Input	Normal Input	Thermal Output Capacity	Minimum Input	Normal Input	Thermal Output Capacity	Minimum Input	
Feet	Meters	Size 30			Size 45			Size 60			Size 75			
0-2000	0-610	30000	24600	30000	45000	37350	45000	60000	49800	42000	75000	62250	52500	
2001-3000	611-915	28200	23124	28200	42300	35109	42300	56400	46812	39480	70500	58515	49350	
3001-4000	916-1220	27600	22632	27600	41400	34362	41400	55200	45816	38640	69000	57270	48300	
4001-5000	1221-1525	27000	22140	27000	40500	33615	40500	54000	44820	37800	67500	56025	47250	
5001-6000	1526-1830	26400	21648	26400	39600	32868	39600	52800	43824	36960	66000	54780	46200	
6001-7000	1831-2135	25800	21156	25800	38700	32121	38700	51600	42828	36120	64500	53535	45150	
7001-8000	2136-2440	25200	20664	25200	37800	31374	37800	50400	41832	35280	63000	52290	44100	
8001-9000	2441-2745	24600	20172	24600	36900	30627	36900	49200	40836	34440	61500	51045	43050	
9001-10000	2746-3045	24000	19680	24000	36000	29880	36000	48000	39840	33600	60000	49800	42000	
Feet	Meters	Size 100			Size 125			Size 150			Size 175			
0-2000	0-610	105000	87150	73500	120000	99600	84000	150000	124500	105000	175000	145250	122500	
2001-3000	611-915	98700	82908	69090	112800	94752	78960	141000	117030	98700	164500	136535	115150	
3001-4000	916-1220	96600	81144	67620	110400	92736	77280	138000	114540	96600	161000	133630	112700	
4001-5000	1221-1525	94500	79380	66150	108000	90720	75600	135000	112050	94500	157500	130725	110250	
5001-6000	1526-1830	92400	77616	64680	105600	88704	73920	132000	109560	92400	154000	127820	107800	
6001-7000	1831-2135	90300	75852	63210	103200	86688	72240	129000	107070	90300	150500	124915	105350	
7001-8000	2136-2440	88200	74088	61740	100800	84672	70560	126000	104580	88200	147000	122010	102900	
8001-9000	2441-2745	86100	72324	60270	98400	82656	68880	123000	102090	86100	143500	119105	100450	
9001-10000	2746-3045	84000	70560	58800	96000	80640	67200	120000	99600	84000	140000	116200	98000	
Feet	Meters	Size 200			Size 225			Size 250			Size 300			
0-2000	0-610	200000	166000	140000	225000	186750	157500	250000	207500	175000	300000	249000	210000	
2001-3000	611-915	188000	156040	131600	211500	175545	148050	235000	195050	164500	282000	234060	197400	
3001-4000	916-1220	184000	152720	128800	207000	171810	144900	230000	190900	161000	276000	229080	193200	
4001-5000	1221-1525	180000	149400	126000	202500	168075	141750	225000	186750	157500	270000	224100	189000	
5001-6000	1526-1830	176000	146080	123200	198000	164340	138600	220000	182600	154000	264000	219120	184800	
6001-7000	1831-2135	172000	142760	120400	193500	160605	135450	215000	178450	150500	258000	214140	180600	
7001-8000	2136-2440	168000	139440	117600	189000	156870	132300	210000	174300	147000	252000	209160	176400	
8001-9000	2441-2745	164000	136120	114800	184500	153135	129150	205000	170150	143500	246000	204180	172200	
9001-10000	2746-3045	160000	132800	112000	180000	149400	126000	200000	166000	140000	240000	199200	168000	
Feet	Meters	Size 350			Size 400									
0-2000	0-610	350000	290500	245000	400000	332000	280000							
2001-3000	611-915	329000	273070	230300	376000	312080	263200							
3001-4000	916-1220	322000	267260	225400	368000	305440	257600							
4001-5000	1221-1525	315000	261450	220500	360000	298800	252000							
5001-6000	1526-1830	308000	255640	215600	352000	292160	246400							
6001-7000	1831-2135	301000	249830	210700	344000	285520	240800							
7001-8000	2136-2440	294000	244020	205800	336000	278880	235200							
8001-9000	2441-2745	287000	238210	200900	328000	272240	229600							
9001-10000	2746-3045	280000	232400	196000	320000	265600	224000							

BTUH Inputs and Capacities by Altitude in CANADA for all Models													
ALTITUDE		Normal Input	Thermal Output Capacity	Minimum Input	Normal Input	Thermal Output Capacity	Minimum Input	Normal Input	Thermal Output Capacity	Minimum Input	Normal Input	Thermal Output Capacity	Minimum Input
Feet	Meters	Size 30			Size 45			Size 60			Size 75		
0–2000	0–610	30000	24600	30000	45000	37350	45000	60000	49800	42000	75000	62250	52500
2001–4500	611–1373	27000	22140	27000	40500	33615	40500	54000	44820	37800	67500	56025	47250
Feet	Meters	Size 100			Size 125			Size 150			Size 175		
0–2000	0–610	105000	87150	73500	120000	99600	84000	150000	124500	105000	175000	145250	122500
2001–4500	611–1373	94500	79380	66150	108000	90720	75600	135000	113400	94500	157500	132300	110250
Feet	Meters	Size 200			Size 225			Size 250			Size 300		
0–2000	0–610	200000	166000	140000	225000	186750	157500	250000	207500	175000	300000	249000	210000
2001–4500	611–1373	180000	151200	126000	202500	170100	141750	225000	189000	157500	270000	226800	189000
Feet	Meters	Size 350			Size 400								
0–2000	0–610	350000	290500	245000	400000	332000	280000						
2001–4500	611–1373	315000	264600	220500	360000	302400	252000						



## 6.0 Mechanical (cont'd)

**Note: For Separated Combustion Model, see Venting Manual for combustion air requirements.**

### **Combustion Air Requirements for a Heater Located in a Confined Space—applies to Standard Power Vent Models and Standard Power Vent Models with CV Option**

**FIGURE 11 - Definition of Confined Space and Required Openings for Combustion Air**

## 6.2 Combustion Air—Standard Power Vent Models

This heater must be supplied with the air that enters into the combustion process and is then vented to the outdoors. Sufficient air must enter the equipment location to replace that exhausted through the heater vent system. In the past, the infiltration of outside air assumed in heat loss calculations (one air change per hour) was assumed to be sufficient. However, current construction methods using more insulation, vapor barriers, tighter fitting and gasketed doors and windows, weather-stripping, and/or mechanical exhaust fans may now require the introduction of outside air through wall openings or ducts.

The requirements for combustion and ventilation air depend upon whether the unit is located in a confined or unconfined space. An “unconfined space” is defined as a space whose volume is not less than 50 cubic feet per 1000 BTUH of the installed appliance. **Under ALL conditions**, enough air must be provided to ensure there will not be a negative pressure condition within the equipment room or space.

### **WARNING**


**Standard Power Vent Model unit heaters are designed to take combustion air from the space in which the unit is installed and are not designed for connection to outside combustion air intake ducts. Connecting outside air ducts voids the warranty and could cause hazardous operation (see Hazard Levels, page 2).**

**Do not** install a unit in a confined space without providing wall openings leading to and from the space. Provide openings near the floor and ceiling for ventilation and air for combustion as shown in **FIGURE 11**, depending on the combustion air source as noted in Items 1, 2, and 3 below.

Add total BTUH of all appliances in the confined space and divide by figures below for square inch free area size of each (top and bottom) opening.

#### **Confined Space:**

**A space whose volume is less than 50 cubic feet per 1000 BTUH of the installed appliance input rating**



- 1. Air from inside the building:** openings 1 square inch free area per 1000 BTUH. Never less than 100 square inches of free area for each opening (see (1) in **FIGURE 11**).
- 2. Air from outside through duct:** openings 1 square inch free area per 2000 BTUH (see (2) in **FIGURE 11**).
- 3. Air direct from outside:** openings 1 square inch free area per 4000 BTUH (see (3) in **FIGURE 11**).

**NOTE:** For further details on supplying combustion air to a confined space, see the National Fuel Gas Code ANSI Z223.1a (latest edition).

### **7.1 General**

All electrical wiring and connections, including electrical grounding **MUST** be made in accordance with the National Electric Code ANSI/NFPA No. 70 (latest edition) or, in Canada, with CSA Standard C22.1. In addition, the installer should be aware of any local ordinances or gas company requirements that might apply.

**CAUTION:** If any of the original wire as supplied with the appliance must be replaced, it must be replaced with wiring material having a temperature rating of at least 105°C, except for limit control, flame rollout, and sensor lead wires which must be 150°C (see Hazard Levels, page 2).

## 7.0 Electrical Supply and Wiring

**CAUTION:** Route wires so that they do not contact the flue wrapper or venter housing.


## 7.2 Supply Wiring

Check the rating plate on the heater for the supply voltage and current requirements. A dedicated line voltage supply with disconnect switch should be run directly from the main electrical panel to the heater. All external wiring must be within approved conduit and have a minimum temperature rise rating of 60°C. Conduit must be run so as not to interfere with the heater access panel. If the installation requires a stepdown transformer (Option CG on some models), follow the instructions shipped with the option package for attaching the transformer to the heater.

The electrical supply enters at the rear of the heater (see **FIGURE 13**). Separated Combustion Models include a built-in disconnect switch (20A @ 115V; 10A @ 230V Rating). The Separated Combustion Model supply wiring connects to leads located inside a sealed electrical box. To maintain the sealing feature of the electrical box, always replace the cover plate. The Standard Power Vent Model supply wiring connects directly to leads on the integrated circuit board.

The circuit board (see **FIGURE 12**) is located inside on the bottom of the control compartment. The circuit board is polarity sensitive. It is advisable to check the electrical supply to be certain that the black wire is the “hot” wire and that the white wire is the neutral wire. The supply connection made to “L1” on the circuit board must be the “hot” wire.

**FIGURE 12 - Supply Wiring Connections at the Circuit Board (DSI Integrated Control Module)**




## 7.3 24V Control Wiring Connections

For all models, the terminal strip for 24 volt thermostat connections is located on the outside of the cabinet at the back of the heater (see **FIGURE 13**). Wires from the terminal strip are factory wired to the circuit board.

**FIGURE 13 - Terminal Strip for 24-volt wiring is on the outside rear of the heater.**


**NOTE:** The size of heater illustrated has a vertical terminal strip. Some sizes have a horizontal terminal strip.



## 7.0 Electrical Supply and Wiring (cont'd)

## 7.4 Wiring Diagrams

FIGURE 14A - Typical Wiring Diagram for all Single Stage Model or Recirculation Models




TOTAL WIRE LENGTH	FIELD CONTROL WIRING DISTANCE FROM UNIT TO CONTROL	MIN. RECOMMENDED WIRE GAUGE
150'	75'	#18 GA. WIRE
250'	125'	#16 GA. WIRE
350'	175'	#14 GA. WIRE

**WIRING CODE**  
 BLACK - BK  
 BROWN - BR  
 RED - R  
 ORANGE - O  
 YELLOW - Y  
 GREEN - G  
 BLUE - BL  
 PURPLE - PR  
 WHITE - W

**ALL SINGLE STAGE OR  
RECIRCULATION MODELS**  
 WD# 185139 REV #5  
 AG1-CL1 or CL22

(NOTE: Two Stage Valve circuit is NOT available on all models)



## 7.0 Electrical Supply and Wiring (cont'd)

## 7.5 Electrical Operating Components

### 7.5.1 Combustion Air Proving (Pressure) Switch

The combustion air proving switch is a pressure sensitive switch that monitors air pressure to ensure that proper combustion airflow is available. On Standard Power Vent models, the switch is a single pole/normally open device which closes when a negative pressure is sensed in the venter housing. On Separated Combustion models, the switch senses the differential pressure between the negative pressure in the venter housing and the pressure in the cabinet (for switch location, see **FIGURE 18**, page 30).

On startup when the heater is cold, the sensing pressure is at the most negative level, and as the heater and flue system warm up, the sensing pressure becomes less negative. After the system has reached equilibrium (about 20 minutes), the sensing pressure levels off.

If a restriction or excessive flue length or turns cause the sensing pressure to be outside the switch setpoint, the pressure switch will function to shutoff the main burner. The main burner will remain off until the system has cooled and/or the flue system resistance is reduced.

The Tables on the left below list the approximate water column negative pressure readings and switch setpoints for sea level operating conditions for Standard Power Vent and Model heaters. The Table on the right lists the approximate water column differential pressure readings and switch setpoints for sea level operating conditions for Separated Combustion Model heaters.

### DANGER

**Safe operation of this unit requires proper venting flow. NEVER bypass combustion air proving switch or attempt to operate the unit without the venter running and the proper flow in the vent system. Hazardous conditions could result (see Hazard Intensity Levels, page 2).**

### Pressure Switch Settings

Std Power Vent Models	Startup Cold	Equilibrium Hot	Setpoint OFF	Setpoint ON	Label Color	Switch PN	Std Power Vent Models	Startup Cold	Equilibrium Hot	Setpoint OFF	Setpoint ON	Label Color	Switch PN
	Negative Pressure (" w.c.)							Differential Pressure (" w.c.)					
30	1.0	0.8	0.4	0.6	Green	197030	30	1.0	0.8	0.65	0.8	Yellow	197028
45	1.0	0.8	0.4	0.6	Green	197030	45	1.1	0.8	0.65	0.8	Yellow	197028
60	1.0	0.8	0.5	0.7	Orange	196388	60	1.1	0.9	0.65	0.8	Yellow	197028
75	1.0	0.9	0.5	0.7	Orange	196388	75	1.1	0.9	0.65	0.8	Yellow	197028
100	0.9	0.7	0.5	0.7	Orange	196388	100	0.9	0.7	0.55	0.7	White	196362
125	0.8	0.6	0.4	0.6	Green	197030	125	0.8	0.6	0.45	0.6	Pink	197032
150, 175	0.8	0.7	0.4	0.6	Green	197030	150, 175	0.8	0.6	0.40	0.6	Green	197030
200, 225	2.2	1.5	1.1	1.3	Blue	201158	200, 225	2.2	1.5	1.10	1.3	Blue	201158
250, 300	2.3	1.6	1.1	1.3	Blue	201158	250, 300	2.3	1.6	1.10	1.3	Blue	201158
350, 400	2.6	1.8	1.1	1.6	Red	201159	350, 400	2.6	1.8	1.10	1.6	Blue	201158

Std Power Vent Model with Opt AV6	Startup Cold	Equilibrium Hot	Setpoint OFF	Setpoint ON	Label Color	Switch PN
	Negative Pressure (" w.c.)					
30	1.1	0.8	0.65	0.8	Yellow	197028
45	1.1	0.8	0.50	0.7	Orange	196388
60	0.9	0.8	0.60	0.8	Lt Blue	197029
75	1.0	0.8	0.60	0.8	Lt Blue	197029
100	0.9	0.7	0.55	0.7	White	196362

### 7.5.2 Limit Control

All units are equipped with a temperature activated auto reset limit control. The control is factory set and is non-adjustable. If the setpoint is reached, the limit control will interrupt the electric supply to the gas valve. This safety device provides protection in the case of motor failure or lack of airflow due to a restriction at the inlet or outlet (for location, see **FIGURE 18**, page 30).

**CAUTION: The auto reset limit control will continue to shut down the heater until the cause is corrected. Never bypass the limit control; hazardous conditions could result (see Hazard Intensity Levels, page 2).**

Sizes 30–125 are equipped with a temperature activated manually reset flame rollout switch. The flame rollout switch is located at the top of the burner assembly. It is factory set and is non-adjustable. If the setpoint is reached, the flame rollout acts to interrupt the electric supply to the gas valve. If the flame rollout switch activates, identify and correct the cause before resetting the switch. Refer to the Maintenance Section, Paragraph 10.2.10, for information on probable causes and instructions on resetting the flame rollout switch (for location, see **FIGURE 18**, page 30).

#### **DANGER**

**If the manual reset flame rollout switch activates, identify and correct the cause before resetting the switch. Never bypass the flame rollout switch; hazardous conditions could result (see Hazard Intensity Levels, page 2).**

### **7.5.3 Door Switch for Separated Combustion Models only**

All sizes of Separated Combustion Model heaters are equipped with a door switch which prevents the heater from operating when the service door panel is open. The service panel of a Separated Combustion Models are equipped with a pliable gasket material that fully seals the door to provide added protection from building air entering the combustion zone of the heater (for switch location, see **FIGURE 18**, page 30).

### **7.5.4 Gas Valve**

The main operating gas valve is powered by the 24-volt control circuit through the thermostat and safety controls. The main control valve is of the diaphragm type providing regulated gas flow preset at the factory (for location, see **FIGURE 18**, page 30).

#### **WARNING**

**The operating valve is the prime safety shutoff. All gas supply lines must be free of dirt or scale before connecting the unit to ensure positive closure (see Hazard Levels, page 2).**

### **7.5.5 Fan Motor**

The fan motor is equipped with thermal overload protection of the automatic reset type. Should the motor refuse to run, it may be because of improper current characteristics. Make certain that the correct voltage is available at the motor.

**NOTE:** If the unit is equipped with an optional totally enclosed motor or optional voltage, the horsepower may be larger than the standard motor. Refer to the motor nameplate to verify horsepower.

### **7.5.6 Venter Motor**

The venter motor is assembled to the venter wheel and operates to provide combustion airflow. Operation is controlled by the ignition control module (circuit board); refer to ignition system in Paragraph 8.3.

## **8.0 Controls and Operation**

### **8.1 Thermostat**

Use either an optional thermostat available with the heater or a field-supplied 24-volt thermostat. Install according to the thermostat manufacturer's instructions, paying particular attention to the requirements regarding the location of the thermostat.

Make sure that if there is a heat anticipator setting on the thermostat, it is set at 0.6 amps (or in accordance with the amperage value noted on the heater wiring diagram).

Make thermostat connections at the terminal strip on the back of the heater. The strip has four terminals, R, G, W1, and W2; refer to the wiring diagram.

**IMPORTANT:** All units **MUST** be operated by a 24-volt thermostat. Never use a line voltage disconnect switch as a means of operating the heater. Operating Model Sizes 30–125 by means other than a 24-volt thermostat may result in the flame rollout switch tripping.

**Multiple Heater Control, Option CL31 and Option CL32:** If the heater was ordered with a multiple heater control option, one thermostat can be used to control up to six heaters. The option includes a 40VA transformer that replaces the standard transformer in the "controlling" unit and a relay assembly that attaches to the additional unit. Option CL31 provides for control of two heaters. If control of additional heaters is desired (up to six total), Option CL32 which is the relay assembly only must be added to each additional heater.

The option packages are shipped separately and include complete instructions on installation and wiring.

## 8.0 Controls and Operation (cont'd)

### 8.2 DDC Controls, Options D10 and D14 (ONLY for sizes 150–400)


**FIGURE 15A -**  
DDC Control with Transformer and Relays is Mounted on a Specially Designed Bracket in the Control Compartment



Control **Option D10** includes the controller and the sensor to be field mounted at the heater discharge. **Option D14** requires a field-supplied sensor that is compatible with the control. For regulatory compliance specifications, and safety precautions, review the control manufacturer's installation instructions in the owner's envelope.

The recommended location for mounting the sensor is on the side of a field-installed optional downturn nozzle. See **FIGURE 15B** for an illustration of the sensor included with Option D10 and dimensions for mounting it on the nozzle side.

**FIGURE 15B -**  
Recommended Location for Mounting the Sensor is on the Side Panel of a Discharge Nozzle (Option CD 2, 3, or 4)



Mount the sensor on the nozzle side.


Drill a 7/8" hole in the cabinet top above the controller and install the bushing supplied with the unit for running the sensor wire. Wire the sensor to the controller as illustrated on the wiring diagram on the heater. Sensor wire is field-supplied.



## 8.3 Ignition System

This heater is equipped with a direct spark integrated control module (circuit board). The module monitors the safety devices and controls the operation of the fan and venter motors and the gas valve between heat cycles.

**FIGURE 16 - DSI Integrated Control Module (circuit board)**



### Normal Heat Cycle Operating Sequence

LED lights are visible through viewport on Separated Combustion Models. Remove door panel to view LED lights on Standard Power Vent Models.

**1) Call for Heat:** The thermostat calls for heat by energizing the “W” terminal. The control checks to see that the limit switch is closed and the pressure switch is open. If the limit switch is open, the control responds as defined in the “Abnormal Heat Cycle, Limit Switch Operation”. If the pressure switch is closed, the control will do four flashes on the green LED and wait indefinitely for the pressure switch to open. If the pressure switch is open, the control proceeds to prepurge.

**2) Prepurge:** The control energizes the venter motor and waits for the pressure switch to close. If the pressure switch does not close within 30 seconds of the venter motor energizing, the control will do two flashes on the green LED. The control will leave the venter motor energized indefinitely as long as the call for heat remains and the pressure switch is open.

When the pressure switch is proven closed, the control begins the prepurge time. If flame is present any time while in prepurge, the prepurge time is restarted. If flame is present long enough to cause lockout, the control responds as defined in “Fault Modes, Undesired Flame”.

The control runs the venter motor for a 20 second prepurge time, then proceeds to the ignition trial period.

**3) Ignition Trial Period:** The control energizes the spark and main gas valve. The venter remains energized. If flame is sensed during the first 16 seconds, the spark is de-energized and the control proceeds to heat fan/blower on delay. If flame has not been sensed during the first 16 seconds, the control de-energizes the spark output and keeps the gas valve energized for an additional one second flame proving period. If flame is not present after the flame proving period, the control de-energizes the gas valve and proceeds with ignition re-tries as specified in “Abnormal Heat Cycle, Ignition Retry”. If flame is present, the control proceeds to the fan/blower on delay.

**4) Fan/Blower On Delay:** The control waits for 30 seconds from the time the gas valve opened and then energizes the fan/blower motor. The gas valve and venter motor remain energized. The control proceeds to steady heat mode.

**5) Steady Heat:** Control inputs are continuously monitored to ensure limit and pressure switches are closed, flame is established, and the thermostat call for heat remains. When the thermostat call for heat is removed, the control de-energizes the gas valve and begins post-purge and fan/blower off delay timing.

## 8.0 Controls and Operation (cont'd)

### 8.3 Ignition System (cont'd)

#### Abnormal Heat Cycle Functions

#### Normal Heat Cycle Operating Sequence (cont'd)

**6) Post Purge:** The venter motor output remains on for a 45-second post-purge period after the thermostat is satisfied.

**7) Fan/Blower Off Delay:** The fan/blower motor is de-energized after a fan/blower off delay (120 seconds). Timing begins when the thermostat is satisfied.

**Interrupted Thermostat Call for Heat:** If the thermostat demand for heat is removed before the flame is recognized, the control will run the venter motor for the post purge period and de-energize all outputs.

If the thermostat demand for heat is removed after successful ignition, the control will de-energize the gas valve, run the venter motor through post purge, and run the fan/blower motor on heat speed for the selected delay off time.

**Ignition Retry:** If flame is not established on the first trial for ignition period, the control de-energizes the gas valve and the venter motor remains energized for an inter-purge period of 10 seconds. The spark and gas valve are then re-energized, and the control initiates another trial for ignition.

If flame is not established on the second trial for ignition, the control de-energizes the gas valve, energizes the fan/blower motor on heat speed, and venter motor remains energized. The fan/blower motor is shut off after 120 seconds. When the fan/blower motor de-energizes, the spark and gas valve are re-energized and the control initiates another trial for ignition. (This fan delay is self-healing feature for an open auxiliary limit switch).

If flame is not established on the third trial for ignition period, the control de-energizes the gas valve, and the venter motor remains energized for an inter-purge period of 10 seconds. The control then re-energizes the gas valve and spark and initiates another trial for ignition.

If flame is not established on the fourth trial for ignition (initial try plus 3 re-tries), the control de-energizes the gas valve and goes into lockout. The control goes to one flash on the green LED to indicate ignition failure lockout.

**Limit Switch Operation:** The limit switch is ignored unless a call for heat is present (W energized). If the limit switch is open and a call for heat is present, the control de-energizes the gas valve and turns the fan/blower motor on heat speed and runs the venter motor. The control will be in soft lockout and flashing fault code "3" before returning to normal operation.

When the switch re-closes or the call for heat is lost, the control runs the venter motor through post purge and runs the blower/fan motor through the selected fan off delay.

**Pressure Switch:** If the pressure switch opens before the trial for ignition period, the venter motor will run through the pressure switch recognition delay (2 seconds), the gas valve will be de-energized, and the venter motor will run through the postpurge time. The control will re-start the heat cycle at the pressure switch proving state if the call for heat still exists.

Pressure switch opening for less than 2 seconds during the trial for ignition period shall not interrupt the heat cycle. (Gas valve will de-energize while the pressure switch is open.)

If the pressure switch opens after a successful ignition, the control will de-energize the gas valve. If flame is lost before the end of the 2 second pressure switch recognition delay, the control will respond to the loss of flame. If the pressure switch remains open for 2 seconds and the flame remains, the control de-energizes the gas valve, the venter motor runs through post-purge, and the fan/blower motor runs on heat speed through the selected fan off delay. When the fan off delay is over, the fan/blower motor is de-energized, and a heat cycle is begun if the call for heat still exists.

When the thermostat calls for continuous fan (G) without a call for heat, the fan motor is energized after a .25 second delay. NOTE: This brief on delay is to allow the "G" terminal to energize slightly before "Y" and an external changeover relay to switch from "G" to "W" without causing momentary glitches in the fan/blower output. The fan remains energized as long as the call for fan remains without a call for heat.

If a call for heat (W) occurs during continuous fan, the fan/blower will de-energize. A call for fan is ignored while in lockout.

## **Continuous Fan Operation**

**Undesired Flame:** If flame is sensed longer than 20 seconds while the gas valve is de-energized, the control shall energize the venter motor and fan/blower motor on heat speed. When flame is no longer sensed, the venter motor will run through postpurge, and the fan/blower motor will run through the selected heat fan off delay time. The control will do a soft lockout, but will still respond to open limit and flame. The FLAME (yellow) LED shall flash rapidly when lockout is due to undesired flame.

## **Fault Modes**

**Gas Valve Relay Fault:** If the control senses the gas valve as energized for more than one second when the control is not attempting to energize the gas valve, or the gas valve is sensed as not energized when it is supposed to be energized, then the control will lockout with green LED off. The control assumes either the contacts of the relay driving the gas valve have welded shut, or the sensing circuit has failed. The venter motor is forced off to open the pressure switch to stop gas flow unless flame is present. If the gas valve was sensed as closed when it should be open, and has not de-energized after the venter motor was shutoff for 15 seconds, then the venter motor is re-energized to vent the unburned gas.

**Soft Lockout:** The control shall not initiate a call for heat or call for continuous fan while in lockout. The control will still respond to an open limit and undesired flame. Lockout shall automatically reset after one hour. Lockout may be manually reset by removing power from the control for more than one second or removing the thermostat call for heat for more than one and less than 20 seconds.

**Hard Lockout:** If the control detects a fault on the control board, the status LED will be de-energized, and the control will lockout as long as the fault remains. A hard lockout will automatically reset if the hardware fault clears.

## **Lockout**

**Power Interruption:** During a momentary power interruption or at voltage levels below the minimum operating voltage (line voltage or low voltage) the system will self-recover without lockout when voltage returns to the operating range.

Power interruptions of less than 80mS shall not cause the control to change operating states. Power interruptions greater than 80mS may cause the control to interrupt the current operating cycle and re-start.

## 9.0 Commissioning and Startup

### 9.1 Check the installation prior to startup:

- ☐ Check to be sure that all screws used to hold shipping brackets were re-installed in the heater cabinet.
- ☐ Check suspension. Unit must be secure and level.
- ☐ Check clearances from combustibles. Requirements are in Paragraph 4.1.
- ☐ Check vent system to be sure that it is installed according to the instructions in the appropriate Vent Installation Manual as listed in Paragraph 2.2.
- ☐ Check piping for leaks and proper gas line pressure. Bleed gas lines of trapped air (see Paragraph 6.1).
- ☐ Check electrical wiring. Be sure all wire gauges are as recommended. A service disconnect switch should be used. Verify that fusing or circuit breakers are adequate for the load use.
- ☐ Check polarity. Verify that line voltage exists between the black "L1" and earth ground.
- ☐ If installed in California, verify that California Warning Label is displayed.

### 9.2 Heater Startup:

#### WARNINGS


**For your safety, read before operating. If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.**

- This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- Before operating, smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

#### WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Leave the building immediately.
  - Immediately call your gas supplier from a phone remote from the building. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call your fire department.
- Use only your hand to turn the gas control ON/OFF knob on the gas valve. Never use tools. If the valve ON/OFF knob will not turn by hand, do not try to repair it. Call a qualified service technician. Force or attempted repair may result in a fire or explosion.
  - Should overheating occur, or the gas supply control system fail to shut off the flow of gas, turn off the manual gas valve to the appliance before shutting off the electrical supply.
  - Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

**FIGURE 17 - Gas Valve**



### Operating Sequence

1. Set thermostat at lowest setting.
2. Turn off all electric power to the appliance.
3. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand. Open the access door and locate the gas control (ON/OFF) knob or switch on the gas valve (see **FIGURE 17**).
4. Turn the gas control switch to "OFF" or the knob clockwise to "OFF".
5. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. **If you smell gas, STOP!** and follow the steps in the **WARNINGS** printed above or on the Operating Label on the heater. If you do not smell gas, proceed to the next step.
6. Turn the gas control switch to "ON" or the knob counterclockwise to "ON".
7. Close the access door.
8. Turn on the electric power to the heater.
9. Set the thermostat to the desired setting.

**NOTE:** If the appliance does not operate, follow the instructions "To Turn Off Gas to Appliance" printed below (and on the Operating Label on the heater) and call your service technician.

10. Thermostat calls for heat, energizing the venter motor.
11. Venter pressure switch closes, firing the unit.
12. Burner flame is sensed and in 30 seconds after the gas valve is energized, the fan motor is energized.
13. If the flame is extinguished during the main burner operation, the integrated control system closes the main valve and must be reset by interrupting power to the control circuit (see lighting instructions on the heater).

#### TO TURN OFF GAS TO THE APPLIANCE

- 1) Set thermostat to lowest setting
- 2) If service is to be performed, turn off all electric power to the appliance.
- 3) Open the access door.
- 4) Turn the gas control switch to "OFF" or turn knob clockwise to "OFF" (Do not force).
- 5) Close the access door.

### 9.3 Check installation after startup:

#### ☐ Vent System Testing Procedure

The steps below shall be followed with each heater or utility heater connected to the venting system placed in operation while any other appliance(s) connected to the venting system(s) is not in operation.

1. Seal unused openings(s) in the venting system.
2. Inspect the venting system for proper size and horizontal pitch as required in the National Flue Gas Code, ANSI Z223.1/NFPA 54, or the Natural Gas and Propane Installation Code, CSA B149.1, and the venting manual instructions. Verify that there is no blockage or restriction, leakage, corrosion, and/or other deficiencies that could cause an unsafe condition.
3. In so far as is practical, close all doors, windows, other open spaces within the building, and all doors between the space in which the appliance(s) connected to the venting system is located. Turn on clothes dryers and any exhaust fans (such as range hoods and bathroom exhausts) so they operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
4. Following the lighting instructions, place the utility heater being inspected in operation. Adjust the thermostat so that the utility heater will operate continuously.
5. After it has been determined that each utility heater connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers, and any other gas-burning appliance to their previous condition of use.
6. If improper venting is observed during any of the above tests, the venting system must be corrected.

## 9.0 Commissioning and Startup (cont'd)

### 9.3 Check installation after startup (cont'd)

- ☐ With the unit in operation, measure valve outlet gas pressure. If operated at high altitude, adjust outlet gas pressure for altitude (see information and instructions in Paragraph 6.1).
- ☐ Turn the unit off and on, pausing two minutes between each cycle. Observe for smooth ignition.
- ☐ Place the "Literature Bag" containing the Limited Warranty, this booklet, the venting manual, and any control or optional information in an accessible location near the heater.

### **DANGER**

The gas burner in this gas-fired equipment is designed and equipped to provide safe controlled complete combustion. However, if the installation does not permit the burner to receive the proper supply of combustion air, complete combustion may not occur. The result is incomplete combustion which produces carbon monoxide, a poisonous gas that can cause death. Safe operation of indirect-fired gas burning equipment requires a properly operating vent system that vents all flue products to the outside atmosphere. **FAILURE TO PROVIDE PROPER VENTING WILL RESULT IN A HEALTH HAZARD WHICH COULD CAUSE SERIOUS PERSONAL INJURY OR DEATH.**

Always comply with the combustion air requirements in the installation codes and in Paragraph 6.2. Combustion air at the burner should be regulated only by manufacturer-provided equipment. **NEVER RESTRICT OR OTHERWISE ALTER THE SUPPLY OF COMBUSTION AIR TO ANY HEATER.** Standard Power Vent models units installed in a confined space must be supplied with air for combustion as required by Code and in Paragraph 6.2 of this heater installation manual. **MAINTAIN THE VENT OR VENT/COMBUSTION AIR SYSTEM IN STRUCTURALLY SOUND AND PROPER OPERATING CONDITION.**

## 10.0 Maintenance and Service

### **WARNING**

**If you turn off the power supply, turn off the gas (see Hazard Levels, page 2).**

The material contained in the MAINTENANCE AND SERVICE Section of this manual is designed to aid a qualified service person in maintaining and servicing this equipment. This heater will operate with a minimum of maintenance. To ensure long life and satisfactory performance, a heater that is operated under normal conditions should be inspected and cleaned at the start of each heating season. If the heater is operating in an area where an unusual amount of dust or soot or other impurities are present in the air, more frequent maintenance is recommended.

When any service is completed, be careful to reassemble correctly to ensure that no unsafe conditions are created. When re-lighting, always follow the lighting instructions on the heater.

Inspect the burner/control compartment annually to determine if cleaning is necessary.


## 10.1 Maintenance Schedule

**Maintenance Schedule:** The following procedures should be carried out at least annually (see **FIGURE 18** and Paragraphs 10.2.1–10.2.14):

- Clean all dirt, lint, and grease from the combustion air opening (Standard Power Vent) and venter assembly.
- Clean all dirt, lint, and grease from the fan blade, fan guard, and motor.
- Check the heat exchanger both internally and externally.
- Check the burner for scale, dust, or lint accumulation. Clean if needed.
- Check gas valve to ensure that gas flow is being shutoff completely.
- Check the vent or vent/combustion air system for soundness. Clean openings. Replace any parts that do not appear sound.
- Check the wiring for any damaged wire. Replace damaged wiring (see Paragraph 7 for replacement wiring requirements).

**NOTE:** If replacement parts are required, use only factory-authorized parts.

**FIGURE 18 - Location of Controls**





## 10.2 Maintenance Procedures

### 10.2.1 Heat Exchanger Maintenance

### 10.2.2 Burner Maintenance

Remove any external dirt or dust accumulation. Visually check the heat exchanger for cracks and holes. If a crack or hole is observed, replace the heat exchanger.

**NOTE:** Inspection of the lower portion of the heat exchanger is done with the burner removed. See the Burner Service section below for information on inspecting the lower portion of the heat exchanger.


If there is an accumulation of dirt, dust, and/or lint, clean the compartment and follow the instructions below to remove and clean the burner.

**CAUTION: Use of eye protection is recommended.**

#### Burner Removal Instructions (refer to FIGURE 19)

1. Outside the cabinet, shut the gas supply off at the manual valve ahead of the union.
2. Turn off electric supply.
3. Disconnect the gas supply at the union outside of the cabinet.
4. Remove the access panel.
5. **Disconnect and Move the Gas Train:** At the gas valve, mark and disconnect the wires. Carefully remove the burner orifice and orifice adapter locking nut. Slide the orifice adapter out through the bracket on the burner pushing the gas train to the right. This will move the gas train out of the way.
6. **Move the Control Assembly:** Remove the two screws holding the control assembly bracket. Being careful not to disconnect any wires, slide the control assembly to the right.
7. **Remove Secondary Air Baffles (Sizes 60–400 Only):** Vertical along the right side of the burner, locate the flat plate(s) identified as the secondary air baffle(s). The quantity of baffles could be one to four depending on heater size. Each baffle is held in place by one screw. **For re-assembly, on the secondary air shield, mark the location (top and bottom) of each baffle.** Remove all baffles.
8. **Remove Burner Assembly**
  - a) Locate the burner body supports. Depending on the size, the burner will have two or more supports. At each support, remove the one screw that attaches it to the secondary air shield.
  - b) Holding the venturi tube, slide the entire burner assembly slightly to the right to disengage the burner from the supports on the left. Then rotate the open end of the venturi tube inward toward the heater. Carefully pull the burner assembly out of the cabinet.

**FIGURE 19 - Burner Removal (Standard Power Vent model illustrated; same process for both Standard Power Vent and Separated Combustion models)**



## Inspect and Clean the Burner

With the burner assembly removed, shine a flashlight on the burner ribbons. Look for carbon buildup, scale, dust, lint, and/or anything that might restrict flow through the spaces between the burner ribbons. Holding the burner assembly so that any foreign material will fall away from the burner, use a stiff bristle brush to loosen and remove any foreign material(s). If the burner is excessively dirty, remove one of the burner end caps. Remove the four screws that hold the end cap to the burner housing. Lightly tap the end cap to remove it.

Clean all foreign material from the burner and venturi. After the burner is thoroughly clean, replace the end cap making certain that it is tight against the burner housing.

**NOTE:** If any of the burner components are damaged or deteriorated, replace the burner assembly.

## Inspect the Lower Portion of the Heat Exchanger (with burner assembly removed)

At the burner flame entrance of each tube, shine a bright light into each heat exchanger section. With the light shining into the heat exchanger, observe the outside for visible light. Repeat this procedure with each heat exchanger section. If any light is observed, replace the heat exchanger.

## Re-Install the Burner

### Instructions to Re-Install the Burner (Refer to FIGURE 19)

- 1. Attach the Burner Assembly:** Holding the venturi tube, slide the entire burner assembly into position. Align the supports on the left side with the slots in the burner shield; sliding the supports into the slots. On the right, re-attach each burner body support to the secondary air shield.
- 2. Attach the Secondary Air Baffles (Sizes 60–400 Only):** Re-attach the secondary air baffles as marked. Baffles may be different sizes and each **must** be attached in the correct location.
- 3. Attach the Control Assembly:** Carefully slide the control assembly into position. Re-attach with the same screws. Check to be sure all wire connections are secure.
- 4. Attach the Gas Train:** Slide the gas train so that the orifice adapter is through the bracket. Fasten the gas train to the bracket with the locking nut. Install the gas orifice. Re-connect the wires to the gas valve.
- 5.** Close the access panel.
- 6.** Reconnect the gas supply at the union outside of the cabinet. Leak test the connection with leak detecting solution.
- 7.** Turn on the electric and the gas. Check for proper operation.


## 10.2.3 Burner Orifice

Burner orifice usually only needs to be replaced when installing a gas conversion kit. If ordering a replacement orifice only, give BTUH content and specific gravity of gas, as well as the model and serial number of the unit. When removing or replacing the burner orifice, be careful not to damage the venturi tube and/or the bracket.

## 10.2.4 Ignition System

**DSI Integrated Control Module (circuit board) (see FIGURE 20).** The module monitors the operation of the heater including ignition. The only replaceable component is the 3 amp Type ATC or ATO fuse. If the fuse is blown, the problem is most likely an external overload. Correct the problem and replace the fuse.

**FIGURE 20 - DSI Integrated Control Module (Circuit Board)**



## 10.0 Maintenance and Service (cont'd)

### 10.2 Maintenance Procedures (cont'd)



Ignitor



Flame Sensor

### 10.2.4 Ignition System (cont'd)

Do not attempt to disassemble the control module. However, each heating season check the lead wires for insulation deterioration and good connections.


Proper operation of the direct spark ignition system requires a minimum flame signal of 1.0 microamps as measured by a microammeter.

For further information and check out procedure on the direct spark ignition system, refer to Paragraph 8.3 and the Troubleshooting Flow Chart in Paragraph 10.3.

**Ignitor:** Refer to **FIGURE 18** and locate the ignitor. Disconnect the wire; remove the screw and the ignitor. Clean the ignitor assembly with an emery cloth.

Spark gap must be maintained to 1/8" (see **FIGURE 21**).

**FIGURE 21 - Ignitor showing required Spark Gap measurement**



**CAUTION: Due to high voltage on the spark wire and electrode, do not touch when energized (see Hazard Levels, page 2).**


**Flame Sensor:** Refer to **FIGURE 18** and locate the flame sensor. Disconnect the wire; remove the screw and the flame sensor. Clean with an emery cloth.

### 10.2.5 Fan Motor, Fan Blades, and Guard

Remove dirt and grease from the motor, the fan guard, and blades. Use care when cleaning the fan blades to prevent causing misalignment or imbalance. Check that the hub of the fan blades is secure to the shaft.

Follow these instructions for replacement of the fan guard, fan motor and/or fan blades.

**FIGURE 22 - Fan Blade Position on the Shaft by Unit Size and Type of Fan Guard**



Size (all Models)	A = Fan Spacing				Setscrew Torque (in-lb ±10)
	Standard Wire Fan Guard with 0.5" (13 mm) Spacing		Option AZ8 Wire Fan Guard with .334" (8.5 mm) Spacing		
30	1"	25 mm	1"	25 mm	80
45	9/16"	14 mm	1-1/16"	27 mm	
45-LN	3/4"	19 mm	N/A		
60	1-1/2"	38 mm	1-3/4"	44 mm	
75	2-1/8"	54 mm	1-1/2"	38 mm	
100	2-3/8"	60 mm	2-3/8"	60 mm	120
125	2-5/16"	59 mm	2-1/8"	54 mm	
150	2-3/8"	60 mm	N/A		130
175	2-1/8"	54 mm			
200	1-5/8"	41 mm			
225/250/300	2"	51 mm			
350	1-7/8"	48 mm			
400	1-3/8"	35 mm			

1. If the heater is installed, turn off the gas and disconnect the electric power.
2. Open the access door and disconnect the fan motor wires, capacitor wires at the capacitor, and ground screw.
3. Remove the assembled parts (the fan guard, the motor and the fan blade).
4. Disassemble and replace whatever parts are needed and reassemble using whatever part(s) are being replaced and the original parts.

Be sure the fan blade is in the proper position on the shaft; refer to the illustration and table in **FIGURE 22**.

Position the assembly on the heater. Attach the fan guard.

Rotate the fan blade to check for adequate clearance. If adjustment is required, loosen the mounting screws, re-position the fan guard, and tighten the screws. Rotate the fan blade and re-check for adequate clearance. Repeat this procedure until the assembly is positioned properly.

5. Reconnect the fan motor wires according to the wiring diagram and close the access panel.
6. Restore power to the heater and turn on the gas. Light, following the instructions on the lighting instruction plate. Check for proper operation.


### 10.2.6 Venter Motor and Wheel

#### Replacement Instructions

Remove dirt and grease from the motor casing, the venter housing, and the venter wheel. Venter motor bearings are permanently lubricated. Follow these instructions for replacement of the venter motor and wheel assembly. Keep all hardware removed to be used in re-assembling and installing the replacement parts.

1. Turn off the gas and disconnect the electric power.
2. Open the burner/control compartment access panel.
3. Disconnect the three venter motor wires at the DSI control, capacitor wires at the capacitor (if applicable), and ground screw (located on the control panel).
4. Sizes 30 and 45—Disconnect the gas train and move it out of the way. Disconnect the gas supply at the union outside of the cabinet. At the gas valve, mark and disconnect the wires. Carefully remove the burner orifice and orifice adapter locking nut. Slide the orifice adapter out through the bracket on the burner pushing the gas train to the right. This will move the gas train out of the way.
5. Holding the venter motor, remove the three or four screws that attach the venter motor mounting plate to the venter housing. Remove the motor and wheel assembly from the heater.
6. Re-assemble with the replacement venter motor and wheel assembly (see **FIGURE 23**).

**FIGURE 23 - Venter Wheel Position on Shaft**



7. Follow the wiring diagram to connect the venter wires.
8. Sizes 30 and 45—Reconnect the gas supply at the union outside of the cabinet. Leak test the connection with leak detecting solution.
9. Replace the access panel. Restore power to the heater and turn on the gas. Light, following the instructions on the lighting instruction plate. Check for proper operation.

### 10.2.7 Operating Gas Valve

Carefully remove external dirt accumulation and check wiring connections.

#### WARNING

**The operating valve is the prime safety shutoff. All gas supply lines must be free of dirt or scale before connecting to the unit to ensure positive closure (see Hazard Levels, page 2).**

The combination gas valve must be checked annually to ensure that the valve is shutting off gas flow completely.

#### Instructions:

- 1) Locate the 1/8" NPT pressure tap on the combination valve (see **FIGURE 24**, page 34).