SERVICE AND TECHNICAL SUPPORT MANUAL Two-Stage, Variable Speed ECM Blower Motor 35" Tall, High Efficiency Condensing Gas Furnace (F/G)9MVT

Save this manual for future reference.

Safety Labeling and Signal Words

4

4 4

4

5 5

10

11

11 11 13

13 13 14

16

16

17

18

18 19

20 21

DANGER, WARNING, CAUTION, and NOTE The signal words DANGER, WARNING, CAUTION, and NOTE are used to identify levels of hazard seriousness. The signal word DANGER is only used on product labels to signify an immediate hazard. The signal words WARNING, CAUTION, and NOTE will be used on product labels and throughout this manual and other manual that may apply to the product.

DANGER – Immediate hazards which will result in severe personal injury or death.

WARNING – Hazards or unsafe practices which could result in severe personal injury or death.

CAUTION – Hazards or unsafe practices which may result in minor personal injury or product or property damage.

NOTE – Used to highlight suggestions which will result in enhanced installation, reliability, or operation.

TABLE OF CONTENTS

START-UP, ADJUSTMENT, AND SAFETY CHECK
SELECT SETUP SWITCH POSITIONS
CONTINUOUS FAN (CF) SETUP SWITCHES (SW3)
PRIME CONDENSATE TRAP WITH WATER
PURGE GAS LINES
ADJUSTMENTS
ADJUST TEMPERATURE RISE
ADJUST BLOWER OFF DELAY (HEAT MODE)
ADJUST COOLING AIRFLOW
ADJUST CONTINUOUS FAN AIRFLOW
ADJUST THERMOSTAT HEAT ANTICIPATOR
CHECK SAFETY CONTROLS
CHECKLIST
COOLING AND HEATING AIR DELIVERY - CFM
SERVICE AND MAINTENANCE PROCEDURES
ELECTRICAL CONTROLS AND WIRING
TROUBLESHOOTING
CARE AND MAINTENANCE
CLEANING AND/OR REPLACING AIR FILTER
BLOWER MOTOR AND WHEEL MAINTENANCE
CLEANING BURNERS AND FLAME SENSOR
SERVICING HOT SURFACE IGNITER
FLUSHING COLLECTOR BOX AND DRAINAGE SYSTEM
CLEANING CONDENSATE DRAIN AND TRAP
CLEANING HEAT EXCHANGERS
SERVICE LABEL
WIRING DIAGRAM
TROUBLESHOOTING GUIDE – FLOW CHART
SEQUENCE OF OPERATION
PARTS REPLACEMENT INFORMATION GUIDE
PRODUCT NOMENCLATURE

Signal Words in Manuals

The signal word **WARNING** is used throughout this manual in the following manner:

WARNING

The signal word **CAUTION** is used throughout this manual in the following manner:

CAUTION

Signal Words on Product Labeling

Signal words are used in combination with colors and/or pictures or product labels.

▲ Safety-alert symbol

When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

MODELS (F/G)9MVT0401410A (F/G)9MVT0601714A (F/G)9MVT0801716A (F/G)9MVT0802120A (F/G)9MVT1002120A (F/G)9MVT1202422A





Use of the AHRI Certified TM Mark indicates a manufacturer's participation in the program. For verification of certification for individual products, go to www.ahridirectory.org.

SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Use quenching cloth for brazing operations. Have fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes, the current editions of the National Fuel Gas Code (NFCG) NFPA 54/ANSI Z223.1, and the National Electrical Code (NEC) NFPA 70.

In Canada refer to the current editions of the National standards of Canada CAN/CSA–B149.1 and .2 Natural Gas and Propane Installation Codes, and Canadian Electrical Code CSA C22.1.

Recognize safety information. This is the safety-alert symbol

 \triangle . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words; DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

WARNING

PERSONAL INJURY, AND/OR PROPERTY DAMAGE HAZARD

Failure to carefully read and follow this warning could result in equipment malfunction, property damage, personal injury and/or death.

Installation or repairs made by unqualified persons could result in equipment malfunction, property damage, personal injury and/or death.

The information contained in this manual is intended for use by a qualified service technician familiar with safety procedures and equipped with proper tools and test instruments.

Installation must conform with local building codes and with the Natural Fuel Gas Code (NFCG) NFPA 54/ANSI Z223.1, and National standards of Canada CAN/CSA-B149.1 and .2 Natural Gas and Propane Installation Codes.

WARNING

ELECTRICAL SHOCK HAZARD

A

A

Failure to follow this warning could cause personal injury or death.

Before performing service or maintenance operations on unit, always turn off main power switch to unit and install lockout tag. Unit may have more than one power switch.

WARNING

CARBON MONOXIDE POISONING AND FIRE HAZARD

Failure to follow safety warnings could result in personal injury, death, and/or property damage.

This furnace is not designed for use in mobile homes, trailers or recreational vehicles.

CUT HAZARD

Failure to follow this caution may result in damage personal injury.


Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

START-UP CHECK SHEET For Variable Speed Models (F/G)9MVT

(This sheet is optional. Keep for future reference.)

Date of Start-Up:	Calculated Input (BTU) Rate: (See	Checks and Adjustments
Dealer Name:	Section).	
Address:	Heating Check	
City, State(Province), Zip or Postal Code:	Measured Line Pressure During Hig	gh Heat:
	Measured Manifold Pressure:	High Heat
Phone:		Low Heat
Owner Name:	Temperature of Supply Air:	High Heat
Address:		Low Heat
City, State(Province), Zip or Postal Code:	Temperature of Return Air:	
	Temperature Rise (Supply – Return): High Heat
Model Number:		Low Heat
Serial Number:	In Rise Range (see furnace rating p	plate)?
Setup Checks	Static Pressure (Ducts) High Heat:	Supply
Check the box when task is complete.		Return
All Electrical Connections Tight?	Optional Check:	CO?
Have hoses been relocated for furnace U/D/H application?		CO2?
	Cooling Check	
Condensate Drain Connected?	Temperature of Supply Air:	
Condensate Drain Trapped?	Temperature of Return Air:	
Manual Gas Shut-off Upstream of Furnace/Drip Leg	Temperature Difference:	
Gas Valve turned ON?	Static Pressure (Ducts) Cooling:	Supply
Type of Gas: Natural: 🖵 Propane: 🖵		Return
Filter Type and Size:	 Dealer Comments: 	

Shade in Final Furnace Settings Below:



START-UP, ADJUSTMENT, AND SAFETY CHECK

General

1. Furnace must have a 115-v power supply properly connected and grounded.

NOTE: Proper polarity must be maintained for 115-v wiring. Control status indicator light flashes code 10 and furnace does not operate if polarity is incorrect.

- 2. Thermostat wire connections at terminals R, W/W1, G, and Y/Y2 must be made at 24-v terminal block on furnace control.
- 3. Natural gas service pressure must not exceed 0.5 psig (14- in. w.c.), but must be no less than 0.16 psig (4.5-in. w.c.).
- 4. Blower door must be in place to complete 115-v electrical circuit to furnace.

UNIT OPERATION HAZARD

Failure to follow this caution may result in intermittent unit operation or performance satisfaction.

These furnaces are equipped with a manual reset limit switch in burner assembly. This switch opens and shuts off power to the gas valve if an overheat condition (flame rollout) occurs in burner assembly. Correct inadequate combustion–air supply or improper venting condition before resetting switch. DO NOT jumper this switch.

Before operating furnace, check flame rollout manual reset switch for continuity. If necessary, press button to reset switch.

EAC-1 terminal is energized whenever blower operates. HUM terminal is only energized when blower is energized in heating.

Select Setup Switch Positions

There are four sets of setup switches on the furnace control board. These switches configure the furnace for correct application requirement. They also select the airflow settings for Air Conditioning and Continuous Fan CFM.

The Setup Switch locations are shown and described on **Figure 4**, **Figure 5** and **Table 5**. The setup switches are also shown on the unit wiring label.

Setup Switches (SW1)

The furnace control has 8 setup switches that may be set to meet the application requirements. To set these setup switches for the appropriate requirement:

- Remove blower door.
- Locate setup switches on furnace control.
- Configure the set-up switches as necessary for the application.
- Replace blower door.

NOTE: If a bypass humidifier is used, setup switch SW1-3 (Low Heat Rise Adjust) should be in ON position. This compensates for the increased temperature in return air resulting from bypass.

Air Conditioning (A/C) Setup Switches (SW2)

The air conditioning setup switches are used to match furnace airflow to cooling unit used.

- To set the desired cooling airflow:
 - 1. Remove blower door.
 - 2. Locate A/C setup switches on furnace control.
 - 3. Determine air conditioning tonnage used.
 - 4. Configure the switches for the required cooling airflow.

NOTE: Excessive airflow caused by improper A/C switch setup may cause condensate blow-off in cooling mode.

5. Replace blower door.

Continuous Fan (CF) Setup Switches (SW3)

The CF setup switches are used to select desired airflow when thermostat is in continuous fan mode or to select low-cooling airflow for two-speed cooling units. This setup feature allows continuous fan airflow or low-cooling airflow to be adjusted. To set desired continuous fan airflow or low-cooling airflow:

- 1. Remove blower door.
- 2. Locate CF setup switches on furnace control.
- 3. Determine desired continuous fan airflow or low-cooling airflow.
- 4. Configure the switches for the required continuous fan or low-cooling airflow.
- 5. Replace blower door.

Setup Switch (SW4)

Setup switches SW4 are used for applications using a communicating wall control and to adjust airflow. Refer to the communicating wall control instructions for configuration of SW4 for communications. Refer to **Figure 5** for configuration of SW4 airflow options.

Prime Condensate Trap with Water

CAUTION

UNIT OPERATION HAZARD

Failure to follow this caution may result in intermittent unit operation or performance satisfaction.

Condensate trap must be PRIMED or proper draining may not occur. The condensate trap has two internal chambers which can ONLY be primed by pouring water into the inducer drain side of condensate trap.

- 1. Remove upper and middle collector box drain plugs opposite of the condensate trap. (See Figure 1)
- 2. Connect field-supplied 1/2-in. (13 mm) OD tube to upper collector box drain connection.
- 3. Insert field-supplied funnel into tube.
- 4. Pour one quart of water into funnel/tube. Water should run through collector box, overfill condensate trap, and flow into open field drain.
- 5. Remove funnel; replace collector box drain plug.
- 6. Connect field-supplied 1/2-in. (13 mm) OD tube to middle collector box drain port.
- 7. Pour one quart of water into funnel/tube. Water should run through collector box, overfill condensate trap, and flow into open field drain.
- 8. Remove funnel and tube from collector box and replace collector box plug.

<section-header><section-header><section-header>

Purge Gas Lines

If not previously done, purge the lines after all connections have been made and check for leaks.

WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

Adjustments

WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.


DO NOT bottom out gas valve regulator adjusting screw. This can result in unregulated manifold pressure and result in excess overfire and heat exchanger failures.

FURNACE DAMAGE HAZARD

4

Failure to follow this caution may result in reduced furnace life.

DO NOT redrill orifices. Improper drilling (burrs, out-of-round holes, etc.) can cause excessive burner noise and misdirection of burner flames. This can result in flame impingement of heat exchangers, causing failures. (See **Figure 2**)



For proper operation and long term reliability the furnace input rate must be within +/-2 percent of input rate on furnace rating plate.

The gas input rate on rating plate is for installation at altitudes up to 2000 ft. (610 M).

In the U.S.A., the input rating for altitudes above 2000 ft. (610 M) must be reduced by 2 percent for each 1000 ft. (305 M) above sea level refer to **Table 1**.

In Canada, the input rating must be derated by 5 percent for altitudes of 2000 ft. (610 M) to 4500 ft. (1372 M) above sea level.

To adjust manifold pressure to obtain the proper input rate, first, determine if the furnace has the correct orifice installed. At higher altitudes or different gas heat contents, it may be necessary to change the factory orifice to a different orifice. Tables have been provided in the furnace Service and Technical Manual to match the required orifice to the manifold pressure to the heat content and specific gravity of the gas. to do this:

- a. Obtain average yearly gas heat value (at installed altitude) from local gas supplier.
- b. Obtain average yearly gas specific gravity from local gas supplier.
- c. Find installation altitude in Table 3.
- d. Find closest natural gas heat value and specific gravity in **Table 3**.
- e. Follow heat value and specific gravity lines to point of intersection to find orifice size and low-and high-heat manifold pressure settings for proper operation.
- f. Check and verify burner orifice size in furnace. NEVER ASSUME ORIFICE SIZE. ALWAYS CHECK AND VERIFY.
- g. Replace orifice with correct size, if required by **Table 3**. Use only factory–supplied orifices. See EXAMPLE.

EXAMPLE: 0 - 2000 ft. (0 - 609.6M) altitude

Heating value = 1050 Btu/cu ft.

Specific gravity = 0.62

Therefore: Orifice No. 44

Manifold pressure: 3.4-in. w.c. for high heat, 1.4-in. w.c. for low heat

* Furnace is shipped with No. 44 orifices. In this example, all main burner orifices are the correct size and do not need to be changed to obtain proper input rate.

Table 1	Altitude Dera	te Multiplier for U.S.A.
ALTITUDE FT. (M)	PERCENT OF DERATE	DERATE MULTIPLIER FACTOR*
0–2000 (0–610)	0	1.00
2001–3000 (610–914)	4-6	0.95
3001–4000 (914–1219)	6–8	0.93
4001–5000 (1219–1524)	8–10	0.91
5001–6000 (1524–1829)	10–12	0.89
6001–7000 (1829–2134)	12–14	0.87
7001–8000 (2134–2438)	14–16	0.85
8001–9000 (2438–2743)	16–18	0.83
9001–10,000 (2743–3048)	18–20	0.81

* Derate multiplier factors are based on midpoint altitude for altitude range. NOTE: For Canadian altitudes of 2000 to 4500 ft. (610 to 1372 M), use USA altitudes of 2001 to 3000 ft. (610 to 914 M)


NOTE: If orifice hole appears damaged or it is suspected to have been redrilled, check orifice hole with a numbered drill bit of correct size. Never redrill an orifice. A burr-free and squarely aligned orifice hole is essential for proper flame characteristics.

- 1. Adjust manifold pressure to obtain low fire input rate. (See Figure 3)
 - a. Turn gas valve ON/OFF switch to OFF.
 - b. Remove manifold pressure tap plug from gas valve.
 - c. Connect a water column manometer or similar device to manifold pressure tap.
 - d. Turn gas valve ON/OFF switch to ON.
 - e. Move setup SW1—2 on furnace control to ON position to lock furnace in low-heat operation. (See **Figure 4** and **Figure 5**)
 - f. Manually close blower door switch.
 - g. Jumper R and W/W1 thermostat connections on control to start furnace. (See **Figure 4**)
 - h. Remove regulator adjustment cap from low heat gas valve pressure regulator (See **Figure 3**) and turn low-heat adjusting screw (3/16 or smaller flat-tipped screwdriver) counterclockwise (out) to decrease input rate or clockwise (in) to increase input rate.

NOTE: DO NOT set low-heat manifold pressure less than 1.3-in. w.c. or more than 1.7-in. w.c. for natural gas. If manifold pressure is outside this range, change main burner orifices.

- i. Install low-heat regulator adjustment cap.
- j. Move setup switch SW1-2 to off position after completing low-heat adjustment.
- k. Leave manometer or similar device connected and proceed to Step 2.
- 2. Adjust manifold pressure to obtain high fire input rate. (See Figure 3)
 - a. Jumper R to W/W1 and W2 thermostat connections on furnace control. This keeps furnace locked in high-heat operation.
 - b. Remove regulator adjustment cap from high-heat gas valve pressure regulator (See **Figure 3**) and turn high heat adjusting screw (3/16-in. or smaller

flat-tipped screwdriver) counterclockwise (out) to decrease input rate or clockwise (in) to increase input rate.



NOTE: DO NOT set high-heat manifold pressure less than 3.2-in. w.c. or more than 3.8 in. w.c. for natural gas. If manifold pressure is outside this range, change main burner orifices to obtain manifold pressure in this range.

- c. When correct input is obtained, replace caps that conceal gas valve regulator adjustment screws. Main burner flame should be clear blue, almost transparent. (See **Figure 14**)
- d. Re-install manifold pressure tap plug to gas valve.
- e. Remove jumpers R to W/W1 and R to W2.

WARNING


FIRE HAZARD

T

Failure to follow this warning could result in personal injury, death, and/or property damage.

Re-install manifold pressure tap plug in gas valve to prevent gas leak.

- 3. Verify natural gas input rate by clocking meter.
 - a. Turn off all other gas appliances and pilots served by the meter.
 - b. Move setup switch SW1-2 to ON position. This keeps furnace locked in low-heat operation.
 - c. Jumper R to W/W1.
 - d. Run furnace for 3 minutes in low-heat operation.
 - e. Measure time (in sec) for gas meter to complete 1 revolution and note reading. The 2 or 5 cubic feet dial provides a more accurate measurement of gas flow.
 - f. Refer to Table 2 for cubic ft. of gas per hr.
 - g. Multiply gas rate cu ft./hr by heating value (Btuh/cu ft.) to obtain input. If clocked rate does not match required input from Step 1, increase manifold pressure to increase input or decrease manifold pressure to decrease input. Repeat steps b through e until correct low-heat input is achieved. Re-install low heat regulator seal cap on gas valve.
 - h. Move setup switch SW1–2 to OFF position and jumper R to W/W1, and W2. This keeps furnace locked in high-heat operation. Repeat items d through g for high-heat operation.



Gas Furnace: (F/G)9MVT

Table 2	Gas Rate (CU ft./hr)											
SECONDS G	SIZ	ZE OF TEST	DIAL	SECONDS	SIZE OF TEST DIAL							
FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.	FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.					
10	360	720	1800	50	72	144	360					
11	327	655	1636	51	71	141	355					
12	300	600	1500	52	69	138	346					
13	277	555	1385	53	68	136	340					
14	257	514	1286	54	67	133	333					
15	240	480	1200	55	65	131	327					
16	225	450	1125	56	64	129	321					
17	212	424	1059	57	63	126	316					
18	200	400	1000	58	62	124	310					
19	189	379	947	59	61	122	305					
20	180	360	900	60	60	120	300					
21	171	343	857	62	58	116	290					
22	164	327	818	64	56	112	281					
23	157	313	783	66	54	109	273					
24	150	300	750	68	53	106	265					
25	144	288	720	70	51	103	257					
26	138	277	692	72	50	100	250					
27	133	267	667	74	48	97	243					
28	129	257	643	76	47	95	237					
29	124	248	621	78	46	92	231					
30	120	240	600	80	45	90	225					
31	116	232	581	82	44	88	220					
32	113	225	563	84	43	86	214					
33	109	218	545	86	42	84	209					
34	106	212	529	88	41	82	205					
35	103	206	514	90	40	80	200					
36	100	200	500	92	39	78	196					
37	97	195	486	94	38	76	192					
38	95	189	474	96	38	75	188					
39	92	185	462	98	37	74	184					
40	90	180	450	100	36	72	180					
41	88	176	439	102	35	71	178					
42	86	172	429	104	35	69	173					
43	84	167	419	106	34	68	170					
44	82	164	409	108	33	67	167					
45	80	160	400	110	33	65	164					
46	78	157	391	112	32	64	161					
47	76	153	383	116	31	62	155					
48	75	150	375	120	30	60	150					
49	73	147	367		-							

Orifice Size and Manifold Pressure (in. w.c.) for Gas Input Rate – Two–Stage

TWO-STAGE FURNACE (TABULATED DATA BASED ON 20,000 BTUH HIGH-HEAT / 13,000 BTUH LOW-HEAT PER BURNER, DERATED 2%/1000 FT (305M) ABOVE SEA LEVEL)

RANGE HAT VAULE AT ALTITUDE Ordice Ordice (m) Mindl Press Mindl Press Ordice Mindl Mindl Press Ordice Mindl Mindl Press Ordice Mindl Press Ordice Mi	^	LTITUDE	AVG. GAS	DERATED 2%/1000 FT (305M) ABOVE SEA LEVEL) SPECIFIC GRAVITY OF NATURAL GAS										
h AT ALTTUDE (Bitucu ft) Ontice No. HighLow HighLow No. HighLow HighLow No. HighLow HighLow No. HighLow HighLow No. HighLow HighLow No. HighLow No. HighLow <td></td> <td></td> <td></td> <td></td> <td>0.58</td> <td>JFEU</td> <td></td> <td></td> <td></td> <td></td> <td>0.64</td>					0.58	JFEU					0.64			
ft (m) (Butucu ft) No. HighLow				Orifice		Orifice		Orifice		Orifice				
geg (0) 900 925 43 43 43 43 43 38/16 43 36/15 42 43 43 43 37/16 43 35/15 43 43 43 37/16 43 36/15 42 43 43 38/16 43 36/15 42 43 43 38/16 43 36/15 42 43 43 38/16 43 42 33/14 32/14 44 42 32/14 32/14 43 42 33/16 32/14 43 42 33/16 32/14 43 42 33/16 32/14 44 42 33/16 32/16 43 33/14 33/14 44 33/16 33/16 42 33/14 33/14 44 33/16 33/14 44 33/16 33/16 44 33/14 33/14 44 33/14 33/14 44 33/14 33/14 44 33/14 33/14 42 33/14 33/14		ft (m)												
Percever 0 925 43 3.6.1.5 43 3.7.1.6 43 3.8.1.6 42 3.2.1.1.4 00 950 43 3.4.1.1 43 3.5.1.5 43 3.6.1.5 43 3.6.1.5 43 3.6.1.5 43 3.6.1.5 43 3.6.1.5 44 3.6.1.5 44 3.6.1.5 44 3.6.1.5 44 3.6.1.5 44 3.6.1.5 44 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 44 3.7.1.6 44 3.7.1.6 44 3.7.1.6 44 3.7.1.6 43 3.7.1.6 44 3.7.1.6 44 3.7.1.6 43 3.7.1.6 44 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 3.7.1.6 43 <td></td> <td>, <i>,</i></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>		, <i>,</i>												
Top (0) 950 43 3.4.1.4 43 3.5.1.5 43 3.8.1.5 43 3.7.1.5 Cons 1000 44 3.5.1.5 44 3.6.1.5 44 3.4.1.5 43 3.4.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 43 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 43 3.8.1.5 43 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44 3.8.1.5 44	e.	o												
(610) 1075 45 3.7/1.6 45 3.8/1.6 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.5 43 3.3/1.5 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 43 3.3/1.5 43 3.3/1.6 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 <t< td=""><td>adi</td><td>(0)</td><td></td><td>43</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	adi	(0)		43										
(610) 1075 45 3.7/1.6 45 3.8/1.6 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.5 43 3.3/1.5 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 43 3.3/1.5 43 3.3/1.6 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 <t< td=""><td>Can</td><td>()</td><td></td><td>44</td><td></td><td>44</td><td></td><td></td><td></td><td></td><td></td></t<>	Can	()		44		44								
(610) 1075 45 3.7/1.6 45 3.8/1.6 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.5 43 3.3/1.5 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 43 3.3/1.5 43 3.3/1.6 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 <t< td=""><td>pu</td><td>to</td><td></td><td>44</td><td>3.5 / 1.5</td><td>44</td><td>3.6 / 1.5</td><td>44</td><td>3.8 / 1.6</td><td>43</td><td></td></t<>	pu	to		44	3.5 / 1.5	44	3.6 / 1.5	44	3.8 / 1.6	43				
(610) 1075 45 3.7/1.6 45 3.8/1.6 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.5 43 3.3/1.5 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 43 3.3/1.5 43 3.3/1.6 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 <t< td=""><td>a</td><td></td><td></td><td>44</td><td>3.3 / 1.4</td><td>44</td><td>3.5 / 1.5</td><td>44</td><td></td><td>44</td><td></td></t<>	a			44	3.3 / 1.4	44	3.5 / 1.5	44		44				
(610) 1075 45 3.7/1.6 45 3.8/1.6 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.4 42 3.3/1.5 43 3.3/1.5 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.4 43 3.3/1.5 43 3.3/1.6 43 3.3/1.4 44 3.3/1.4 44 3.3/1.4 44 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 43 3.3/1.6 <t< td=""><td>S.</td><td>2000</td><td>1050</td><td>44</td><td>3.2 / 1.3</td><td>44</td><td>3.3 / 1.4</td><td>44</td><td>3.4 / 1.4</td><td>44</td><td>3.5 / 1.5</td></t<>	S.	2000	1050	44	3.2 / 1.3	44	3.3 / 1.4	44	3.4 / 1.4	44	3.5 / 1.5			
U.S.A. 800 42 3.4 /1.4 42 3.5 /1.5 42 3.6 /1.5 42 3.7 /1.6 2001 (611) 825 43 3.8 /1.6 42 3.3 /1.4 42 3.4 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 42 3.3 /1.4 43 3.5 /1.5 43 3.8 /1.6 3000 (914) 950 44 3.7 /1.6 44 3.8 /1.6 43 3.5 /1.5 43 3.3 /1.4 44 3.8 /1.6 43 3.4 /1.4 2001 (611) 950 44 3.2 /1.3 44 3.3 /1.4 44 3.3 /1.6 43 3.8 /1.6 43 3.4 /1.4 43 3.4 /1.4 44 3.7 /1.6 4001 (372) 1000 45 3.8 /1.6 43 3.5 /1.5 43 3.6 /1.5 43 3.6 /1.5 3001 800 44 3.8 /1.6	D	(610)	1075	45	3.7 / 1.6	45	3.8 / 1.6	44	3.3 / 1.4	44	3.4 / 1.4			
geg 2001 (611) 825 43 3.8 / 1.6 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 u 880 43 3.6 / 1.5 43 3.7 / 1.6 42 3.2 / 1.3 42 3.3 / 1.4 3000 (914) 900 44 3.7 / 1.6 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 Canada 925 44 3.5 / 1.5 44 3.8 / 1.6 44 3.6 / 1.5 44 3.8 / 1.6 2001 (611) 950 44 3.2 / 1.3 44 3.6 / 1.5 44 3.6 / 1.5 4500 (1372) 1000 46 3.8 / 1.6 42 3.8 / 1.6 42 3.8 / 1.4 3001 800 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.2 / 1.4 (915) 825 43 3.6 / 1.5 43 3.7 / 1.6 43 3.5 / 1.5 44 3.7 / 1.6 (915) 825 41 3.2 /			1100	46	3.7 / 1.6	46	3.8 / 1.6	45	3.8 / 1.6	44	3.2 / 1.4			
To S50 43 3.6 / 1.5 43 3.7 / 1.6 42 3.2 / 1.3 42 3.3 / 1.4 3000 (914) 875 43 3.4 / 1.4 43 3.5 / 1.5 43 3.7 / 1.5 43 3.6 / 1.5 43 3.5 / 1.5 43 3.5 / 1.5 43 3.5 / 1.5 44 3.5 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.5 / 1.5 44 3.5 / 1.5 44 3.5 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.5 / 1.5 42 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5		U.S.A.	800	42	3.4 / 1.4	42	3.5 / 1.5	42	3.6 / 1.5	42	3.7 / 1.6			
to 9'5 44 3.2 / 1.3 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 43 3.3 / 1.4 44 3.3 / 1.4 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.6 / 1.5 4(915) 825 43 3.6 / 1.5 43 3.5 / 1.5 43 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 43 3.6	IJ	2001 (611)	825	43	3.8 / 1.6	42	3.3 / 1.4	42	3.4 / 1.4	42	3.5 / 1.5			
to 9'5 44 3.2 / 1.3 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 43 3.3 / 1.4 44 3.3 / 1.4 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.6 / 1.5 4(915) 825 43 3.6 / 1.5 43 3.5 / 1.5 43 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 43 3.6	nad	to	850	43	3.6 / 1.5	43	3.7 / 1.6	42	3.2 / 1.3	42	3.3 / 1.4			
to 9'5 44 3.2 / 1.3 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 43 3.3 / 1.4 44 3.3 / 1.4 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.6 / 1.5 4(915) 825 43 3.6 / 1.5 43 3.5 / 1.5 43 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 43 3.6	Cal	3000 (914)	875	43	3.4 / 1.4	43	3.5 / 1.5	43	3.7 / 1.5	43	3.8 / 1.6			
to 9'5 44 3.2 / 1.3 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 43 3.3 / 1.4 44 3.3 / 1.4 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.6 / 1.5 4(915) 825 43 3.6 / 1.5 43 3.5 / 1.5 43 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 43 3.6	put		900	44	3.7 / 1.6	44	3.8 / 1.6	43	3.5 / 1.5	43	3.6 / 1.5			
to 9'5 44 3.2 / 1.3 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 43 3.3 / 1.4 44 3.3 / 1.4 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.6 / 1.5 4(915) 825 43 3.6 / 1.5 43 3.5 / 1.5 43 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 43 3.6	A. a	Canada	925	44	3.5 / 1.5	44	3.6 / 1.5	44	3.8 / 1.6	43	3.4 / 1.4			
to 9'5 44 3.2 / 1.3 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 44 3.3 / 1.4 43 3.3 / 1.4 44 3.3 / 1.4 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.6 / 1.5 4(915) 825 43 3.6 / 1.5 43 3.5 / 1.5 43 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 43 3.6	J.S.	2001 (611)	950	44	3.3 / 1.4	44	3.4 / 1.5	44	3.6 / 1.5	44				
A 775 42 33/14 42 34/14 42 35/15 42 36/15 3001 800 43 38/16 42 32/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 42 33/14 43 35/15 43 37/16 43 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 44 35/15 43 36/15 43 36/15 43 36/15 43 36/15 43 36/15 43 36/15 43 36/15 43 36/15 43 36/15 <td><u>ر</u></td> <td></td> <td>975</td> <td>44</td> <td>3.2 / 1.3</td> <td>44</td> <td>3.3 / 1.4</td> <td>44</td> <td></td> <td>44</td> <td></td>	<u>ر</u>		975	44	3.2 / 1.3	44	3.3 / 1.4	44		44				
3001 800 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.4 / 1.4 (915) 825 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 43 3.8 / 1.6 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 43 3.6 / 1.5 44 3.6 / 1.5 43 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 43 3.6 / 1.5		4500 (1372)												
Per (915) 825 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.2 / 1.4 to 850 44 3.8 / 1.6 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 44 3.7 / 1.6 43 3.6 / 1.5 44 3.7 / 1.5 44 3.6 / 1.5 4000 900 44 3.2 / 1.4 44 3.2 / 1.4 44 3.3 / 1.4 44 3.6 / 1.5 950 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5														
(1219) 925 44 3.2 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 950 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 4001 775 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.														
(1219) 925 44 3.2 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 950 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 4001 775 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.	Ŋ	(915)												
(1219) 925 44 3.2 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 950 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 4001 775 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.	o ∕	to												
(1219) 925 44 3.2 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 950 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 4001 775 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.	S.													
Image 950 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 A001 7750 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.3 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 43 3.7 / 1.6 43 3.6 / 1.5 (1220) 800 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 43 3.6 / 1.5 to 825 44 3.8 / 1.6 43 3.7 / 1.5 44 3.8 / 1.6 43 3.6 / 1.5 to 850 44 3.8 / 1.6 43 3.7 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 to 850 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 43 3.4 / 1.4 to 900 44 3.7 / 1.5 <th< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>														
Vert 750 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 4001 775 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 42 3.4 / 1.4 (1220) 800 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 0 825 44 3.8 / 1.6 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 0 825 44 3.8 / 1.6 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 0 850 844 3.5 / 1.5 44 3.3 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 0 900 844 3.2 / 1.4 44 3.3 / 1.4 44 3.4 / 1.4 43 3.4 / 1.4 101 725 42 3.2 / 1.4 42 3.3 / 1.4 44 3.4 / 1.4 43 3.5 / 1.5 101 750		(1219)												
4001 775 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 42 3.4 / 1.4 (1220) 800 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 to 825 44 3.8 / 1.6 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 5000 875 44 3.5 / 1.5 44 3.7 / 1.5 44 3.8 / 1.6 43 3.4 / 1.4 5000 875 44 3.5 / 1.5 44 3.7 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 (1524) 900 44 3.2 / 1.3 44 3.3 / 1.4 42 3.4 / 1.4 44 3.5 / 1.5 5001 755 42 3.2 / 1.4 42 3.8 / 1.6 42 3.4 / 1.4 42 3.5 / 1.5 5001 755 42 3.2 / 1.4 42 3.8 / 1.6 43 3.7 / 1.5 43 3.6 / 1.5 <														
P (1220) 800 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 to 825 44 3.8 / 1.6 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 to 850 44 3.5 / 1.5 44 3.7 / 1.6 43 3.6 / 1.5 43 3.6 / 1.5 5000 875 44 3.3 / 1.4 44 3.5 / 1.5 44 3.8 / 1.6 43 3.4 / 1.4 5000 875 44 3.3 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.4 / 1.4 900 44 3.2 / 1.3 44 3.3 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.5 / 1.5 900 44 3.2 / 1.4 42 3.3 / 1.4 43 3.4 / 1.4 43 3.6 / 1.5 44 3.5 / 1.5 5001 750 43 3.7 / 1.6 44 3.8 / 1.6 43 3.7 / 1.6 44 3.		1001												
Ý 10 850 44 3.5 / 1.5 44 3.7 / 1.5 44 3.8 / 1.6 43 3.4 / 1.4 5000 875 44 3.3 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 (1524) 900 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 900 40 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 900 46 3.8 / 1.6 45 3.7 / 1.6 44 3.2 / 1.4 42 3.4 / 1.4 43 3.7 / 1.5 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.4 / 1.4 43 3.5 / 1.5 43 3.7 / 1.5 43 3.4 / 1.5 43 3.5 / 1.5 10 800 44 3.5 / 1.5 44 3.6 / 1.5 43 3.6 / 1.5 43														
Ý 10 850 44 3.5 / 1.5 44 3.7 / 1.5 44 3.8 / 1.6 43 3.4 / 1.4 5000 875 44 3.3 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 (1524) 900 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 900 40 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 900 46 3.8 / 1.6 45 3.7 / 1.6 44 3.2 / 1.4 42 3.4 / 1.4 43 3.7 / 1.5 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.4 / 1.4 43 3.5 / 1.5 43 3.7 / 1.5 43 3.4 / 1.5 43 3.5 / 1.5 10 800 44 3.5 / 1.5 44 3.6 / 1.5 43 3.6 / 1.5 43	luc	(1220)												
(1524) 900 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 925 46 3.8 / 1.6 45 3.7 / 1.6 44 3.2 / 1.4 44 3.3 / 1.4 925 42 3.2 / 1.4 42 3.3 / 1.4 42 3.4 / 1.5 42 3.3 / 1.4 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.7 / 1.5 43 3.8 / 1.6 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.5 / 1.5 to 800 44 3.7 / 1.6 44 3.8 / 1.6 43 3.4 / 1.4 44 3.6 / 1.5 43 3.5 / 1.5 6000 850 44 3.7 / 1.6 44 3.4 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 (1829) 875 45 3.7 / 1.6 44 3.2 / 1.3	ج ک	to												
(1524) 900 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 925 46 3.8 / 1.6 45 3.7 / 1.6 44 3.2 / 1.4 44 3.3 / 1.4 925 42 3.2 / 1.4 42 3.3 / 1.4 42 3.4 / 1.5 42 3.3 / 1.4 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.7 / 1.5 43 3.8 / 1.6 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.5 / 1.5 to 800 44 3.7 / 1.6 44 3.8 / 1.6 43 3.4 / 1.4 44 3.6 / 1.5 43 3.5 / 1.5 6000 850 44 3.7 / 1.6 44 3.4 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 (1829) 875 45 3.7 / 1.6 44 3.2 / 1.3	.S.	5000												
No 925 46 3.8 / 1.6 45 3.7 / 1.6 44 3.2 / 1.4 44 3.3 / 1.4 No 725 42 3.2 / 1.4 42 3.3 / 1.4 42 3.4 / 1.5 42 3.5 / 1.5 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.4 42 3.3 / 1.5 43 3.5 / 1.5 43 3.5 / 1.5 43 3.5 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1														
App 725 42 3.2 / 1.4 42 3.3 / 1.4 42 3.4 / 1.5 42 3.5 / 1.5 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.7 / 1.5 43 3.5 / 1.5 43 3.7 / 1.5 43 3.8 / 1.6 800 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 44 3.8 / 1.6 6000 850 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 43 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 <		(1324)												
j 5001 750 43 3.7 / 1.5 43 3.8 / 1.6 42 3.2 / 1.4 42 3.3 / 1.4 (1525) 775 43 3.4 / 1.4 43 3.5 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 43 3.7 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 44 3.8 / 1.6 43 3.7 / 1.6 44 3.8 / 1.6 43 3.7 / 1.6 44 3.8 / 1.6 44 3.8 / 1.6 44 3.8 / 1.6 44 3.8 / 1.6 44 3.6 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.8 / 1.6 44 3.4 / 1.4 44 3.8 / 1.6 44 3.4 / 1.4 44 3.8 / 1.6 44 3.2 / 1.3 44 3.8 / 1.6 44 <		l												
j (1525) 775 43 3.4 / 1.4 43 3.5 / 1.5 43 3.7 / 1.5 43 3.8 / 1.6 to 800 44 3.7 / 1.6 44 3.8 / 1.6 43 3.7 / 1.5 43 3.8 / 1.6 6001 825 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 44 3.8 / 1.6 6000 850 44 3.3 / 1.4 44 3.6 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 6000 850 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 (1829) 875 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 42 3.8 / 1.6 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 90 750 43 3.6 / 1.		5001												
(1829) 875 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 6001 675 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.8 / 1.6 44 3.2 / 1.4 (1830) 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 43 3.6 / 1.5 43 3.8 / 1.6 42 3.5 / 1.5 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 to 750 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.5 / 1.5 to 775 44 3.6 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 <th< td=""><td>≥</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>	≥													
(1829) 875 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 6001 675 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.8 / 1.6 44 3.2 / 1.4 (1830) 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 43 3.6 / 1.5 43 3.8 / 1.6 42 3.5 / 1.5 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 to 750 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.5 / 1.5 to 775 44 3.6 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 <th< td=""><td>ő</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>	ő													
(1829) 875 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 6001 675 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.8 / 1.6 44 3.2 / 1.4 (1830) 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 43 3.6 / 1.5 43 3.8 / 1.6 42 3.5 / 1.5 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 to 750 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.5 / 1.5 to 775 44 3.6 / 1.5 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 <th< td=""><td>¥.</td><td>to</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>	¥.	to												
(1829) 875 45 3.7 / 1.6 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 6001 675 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.8 / 1.6 44 3.2 / 1.4 6001 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.6 / 1.5 42 3.8 / 1.6 42 3.8 / 1.6 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 10 750 43 3.6 / 1.5 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.4 / 1.4 43 3.5 / 1.5 10 700 800 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.5 / 1.5	U.S	6000												
900 46 3.7 / 1.6 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 6001 6001 700 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.8 / 1.6 6001 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 42 3.8 / 1.6 42 3.8 / 1.6 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 750 43 3.6 / 1.5 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 700 700 800 44 3.6 / 1.5 44 3.7 / 1.6 43 3.4 / 1.4 43 3.5 / 1.5 7000 800 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 (2133) 825 44 3.2 / 1.3 44 3.3 / 1.4 3.4 / 1.4 44														
6001 675 42 3.4 / 1.4 42 3.5 / 1.5 42 3.6 / 1.5 42 3.8 / 1.6 6001 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.6 / 1.5 42 3.8 / 1.6 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 to 750 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 rois 750 43 3.6 / 1.5 44 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 700 800 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 7000 800 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 7000 825 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5 <td></td>														
6001 700 42 3.2 / 1.3 42 3.3 / 1.4 42 3.4 / 1.4 42 3.5 / 1.5 (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 to 750 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.5 / 1.5 700 800 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 7000 800 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 (2133) 825 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5							-							
Jest Solution (1830) 725 43 3.6 / 1.5 43 3.7 / 1.6 43 3.8 / 1.6 42 3.3 / 1.4 to 750 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 y 750 44 3.6 / 1.5 44 3.7 / 1.6 43 3.4 / 1.4 43 3.5 / 1.5 43 3.6 / 1.5 43 3.7 / 1.6 7000 800 44 3.4 / 1.4 44 3.5 / 1.5 44 3.6 / 1.5 44 3.7 / 1.6 (2133) 825 44 3.2 / 1.3 44 3.3 / 1.4 44 3.4 / 1.4 44 3.5 / 1.5		6001												
(2133) 825 <u>44</u> <u>3.2 / 1.3</u> <u>44</u> <u>3.3 / 1.4</u> <u>44</u> <u>3.4 / 1.4</u> <u>44</u> <u>3.5 / 1.5</u>	Ę			43		43		43						
(2133) 825 <u>44</u> <u>3.2 / 1.3</u> <u>44</u> <u>3.3 / 1.4</u> <u>44</u> <u>3.4 / 1.4</u> <u>44</u> <u>3.5 / 1.5</u>	ō			43		43		43						
(2133) 825 <u>44</u> 3.2 / 1.3 <u>44</u> 3.3 / 1.4 <u>44</u> 3.4 / 1.4 <u>44</u> 3.5 / 1.5	S.A	10	775	44		44		43		43				
	U.S	7000	800	44	3.4 / 1.4	44	3.5 / 1.5	44	3.6 / 1.5	44	3.7 / 1.6			
850 46 3.8 / 1.6 45 3.8 / 1.6 44 3.2 / 1.4 44 3.3 / 1.4		(2133)	825	44	3.2 / 1.3	44	3.3 / 1.4	44	3.4 / 1.4	44	3.5 / 1.5			
		l	850	46	3.8 / 1.6	45	3.8 / 1.6	44	3.2 / 1.4	44	3.3 / 1.4			

440 04 4221 03

Table 3 (Cont.) Orifice Size and Manifold Pressure (in. w.c.) for Gas Input Rate – Two-Stage

TWO-STAGE FURNACE (TABULATED DATA BASED ON 20,000 BTUH HIGH-HEAT / 13,000 BTUH LOW-HEAT PER BURNER, DERATED 2%/1000 FT (305M) ABOVE SEA LEVEL)

A	LTITUDE	AVG. GAS	RATED	SPECIFIC GRAVITY OF NATURAL GAS										
	RANGE	HEAT VALUE		0.58		0.60		0.62		0.64				
		AT ALTITUDE	Orifice	Mnfld Press	Orifice	Mnfld Press	Orifice	Mnfld Press	Orifice	Mnfld Press				
	ft (m)	(Btu/cu ft)	No.	High/Low	No.	High/Low	No.	High/Low	No.	High/Low				
		650	42	3.4 / 1.4	42	3.5 / 1.5	42	3.6 / 1.5	42	3.7 / 1.6				
	7001	675	43	3.8 / 1.6	42	3.2 / 1.4	42	3.3 / 1.4	42	3.4 / 1.5				
Only	(2134)	700	43	3.5 / 1.5	43	3.7 / 1.5	43	3.8 / 1.6	42	3.2 / 1.4				
ō	to	725	44	3.8 / 1.6	43	3.4 / 1.4	43	3.5 / 1.5	43	3.6 / 1.5				
U.S.A.		750	44	3.5 / 1.5	44	3.7 / 1.5	44	3.8 / 1.6	43	3.4 / 1.4				
Ü.	8000	775	44	3.3 / 1.4	44	3.4 / 1.4	44	3.5 / 1.5	44	3.7 / 1.5				
	(2438)	800	45	3.8 / 1.6	44	3.2 / 1.4	44	3.3 / 1.4	44	3.4 / 1.4				
		825	46	3.7 / 1.6	46	3.8 / 1.6	45	3.8 / 1.6	44	3.2 / 1.4				
		625	42	3.4 / 1.4	42	3.5 / 1.5	42	3.6 / 1.5	42	3.7 / 1.6				
~	8001	650	43	3.8 / 1.6	42	3.2 / 1.4	42	3.3 / 1.4	42	3.4 / 1.4				
Only	(2439)	675	43	3.5 / 1.5	43	3.6 / 1.5	43	3.7 / 1.6	42	3.2 / 1.3				
Ă.	to	700	44	3.7 / 1.6	43	3.4 / 1.4	43	3.5 / 1.5	43	3.6 / 1.5				
U.S.A.	10	725	44	3.5 / 1.5	44	3.6 / 1.5	44	3.7 / 1.6	44	3.8 / 1.6				
	9000	750	44	3.3 / 1.4	44	3.4 / 1.4	44	3.5 / 1.5	44	3.6 / 1.5				
	(2743)	775	45	3.7 / 1.6	44	3.2 / 1.3	44	3.3 / 1.4	44	3.4 / 1.4				
	9001	600	42	3.3 / 1.4	42	3.4 / 1.5	42	3.6 / 1.5	42	3.7 / 1.6				
Ŋ	(2744)	625	43	3.7 / 1.6	42	3.2 / 1.3	42	3.3 / 1.4	42	3.4 / 1.4				
ō	to	650	43	3.5 / 1.5	43	3.6 / 1.5	43	3.7 / 1.6	43	3.8 / 1.6				
U.S.A. Only	10	675	44	3.7 / 1.6	44	3.8 / 1.6	43	3.4 / 1.4	43	3.5 / 1.5				
Ŭ,	10000	700	44	3.4 / 1.4	44	3.5 / 1.5	44	3.7 / 1.5	44	3.8 / 1.6				
	(3048)	725	44	3.2 / 1.3	44	3.3 / 1.4	44	3.4 / 1.4	44	3.5 / 1.5				

A11252B

* Orifice numbers shown in **BOLD** are factory-installed

Adjust Temperature Rise

NOTE: Blower door must be installed when taking temperature rise reading. Leaving blower door off will result in incorrect temperature measurements.

FURNACE DAMAGE HAZARD

Failure to follow this caution may result in:

- Overheating the heat exchangers or condensing flue gases in heat exchanger areas not designed for condensate.
- Shortened furnace life.
- Component damage.

Temperature rise must be within limits specified on furnace rating plate. Recommended operation is at midpoint of rise range or slightly above.

When setup switch SW1–4 is ON, operation will be near the high end of the rise range for improved comfort.

Furnace must operate within ranges of temperature rise specified on the furnace rating plate. Determine air temperature rise as follows:

- a. Place thermometers in return and supply ducts as near furnace as possible. Be sure thermometers do not see heat exchanger so that radiant heat does not affect readings. This practice is particularly important with straight-run ducts.
- b. When thermometer readings stabilize, subtract return-air temperature from supply-air temperature to determine air temperature rise.

NOTE: Temperature rise can be determined for low-heat operation by placing setup switch SW1-2 on furnace control in ON position. For high-heat operation, place setup switch SW1-2 in OFF position and jumper R-W2 on furnace control. DO NOT forget to return setup switch to OFF position and remove R-W2 jumper upon completion of testing.

- c. This furnace is capable of automatically providing proper airflow to maintain the temperature rise within the range specified on furnace rating plate. If temperature rise is outside this range, proceed as follows:
 - (1.) Check gas input for low- and high-heat operation.
 - (2.) Check derate for altitude if applicable.
 - (3.) Check all return and supply ducts for excessive restrictions causing static pressure greater than 0.5–in. w.c.
 - (4.) Ensure Low Heat Rise Adjust switch SW1–3 on furnace control is in ON position when a bypass humidifier is used. (See Figure 4 for switch location.)
 - (5.) Make sure proper model plug is installed.
- d. Remove thermostat jumpers and release blower door switch.
- e. Repeat Steps a through c as required to adjust for high heat temperature rise.
- f. When correct high heat input rate and temperature rise is achieved, turn gas valve ON/OFF switch to OFF.
- g. Release blower door switch.
- h. Remove manometer or similar device from gas valve.

i. Re-install manifold pressure tap plug in gas valve. (See **Figure 3**)

FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Reinstall manifold pressure tap plug in gas valve to prevent gas leak.

- j. Remove thermostat jumper wire from furnace control board.
- k. Turn gas valve ON/OFF switch to ON.

CAUTION

FURNACE OVERHEATING HAZARD

 Λ

Failure to follow this caution may result in reduced furnace life.

Recheck temperature rise. It must be within limits specified on the rating plate. Recommended operation is at the mid-point of rise range or slightly above.

I. Proceed to "Set Blower Off Delay" before installing blower door.

Adjust Blower Off Delay (Heat Mode)

- a. Remove blower door if installed.
- b. Turn Dip switch SW–7 or SW–8 ON or OFF for desired blower off delay. (See Table 4 and Figure 4, Figure 5)

Table 4	Blower S	Speed Taps
DESIRED HEATING MODE BLOWER OFF DELAY (SEC.)		H (SW1—7 and —8) SITION
90	OFF	OFF
120	ON	OFF
150	OFF	ON
180	ON	ON

Adjust Cooling Airflow – High–Speed and Low–Speed Cooling

The ECM blower can be adjusted for a range of airflows for low-speed or high-speed cooling. See **Table 5**-Air Delivery – CFM (with Filter) and **Figure 5**. Furnace Setup Switches and Descriptions. Depending on the model size, the cooling airflow can be adjusted from 1.5 tons to 6 tons of nominal cooling based on 350 CFM ton.

NOTE: 6 ton airflow will truncate at 2200 CFM on applicable models.

The high-speed or single-speed cooling airflow is adjusted by turning setup switches SW2-1, SW2-2 and SW2-3 either ON or OFF. Select the required airflow from **Table 5**. **Table 5** is based on 350 CFM per ton. For other CFM per ton setup switch selections, see **Figure 4**, **Figure 5** and **Figure 16**.

The Continuous Fan airflow selection via setup switches SW3 is also the airflow for low-speed cooling when the furnace is used with a two-speed cooling or heat pump unit. Adjust the Continuous Fan CFM setup switches SW3 to match the airflow required for low-speed cooling. Select the required airflow from **Table 5** and **Figure 5**.

NOTE: The airflow selected via SW3 (low-speed cooling airflow) cannot exceed the airflow selected via SW2 (high-speed cooling airflow). For other CFM per ton setup switch selections, see **Figure 4** and **Figure 5**.

NOTE: The airflow settings for SW2 and SW3 airflow selections are the same for furnaces rated at 1400 CFM of airflow. See **Figure 5** – Furnace setup Switches and Descriptions and a range of airflows for low-speed or high-speed cooling. See **Table 5** – Air Delivery – CFM (with Filter). The SW3 airflow selections for furnaces rated at 2000 CFM and above can be found in **Figure 5**.


For a complete explanation of cooling airflow, refer to the section titled "Sequence of Operation."

Adjust Continuous Fan Airflow/Low Speed Cooling Airflow

NOTE: When the furnace is used with a two-speed cooling or heat pump unit, the airflow selected for Continuous Fan via setup switch SW3 will also be the airflow used for low-speed cooling, and vice versa. The Continuous Fan speed can be further adjusted at a conventional thermostat using the Continuous Fan speed select function. Changing the Continuous Fan speed at a conventional thermostat DOES NOT change the low-speed cooling airflow selected via SW3 at the control board.

NOTE: When the furnace is used with a two-speed cooling or heat pump unit, adjust the Continuous Fan CFM setup switches SW3 to match the airflow required for low-speed cooling.

Select the required Continuous Fan airflow using setup switches SW3 as shown in **Figure 5** and **Table 5**.




L11F097

440 04 4221 03

120-22

Adjust Thermostat Heat Anticipator

- a. Mechanical thermostat. Set thermostat heat anticipator to match the amp. draw of the electrical components in the R–W/W1 circuit. Accurate amp. draw readings can be obtained at the wires normally connected to thermostat subbase terminals, R and W. The thermostat anticipator should NOT be in the circuit while measuring current.
 - (1.) Set SW1-2 switch on furnace control board to ON.
 - (2.) Remove thermostat from subbase or from wall.
 - (3.) Connect an amp. meter as shown in Figure 6 across the R and W subbase terminals or R and W wires at wall.
 - (4.) Record amp. draw across terminals when furnace is in low heat and after blower starts.
 - (5.) Set heat anticipator on thermostat per thermostat instructions and install on subbase or wall.
 - (6.) Turn SW1-2 switch OFF.
 - (7.) Install blower door.
- b. Electronic thermostat: Set cycle rate for 3 cycles per hr.



Check Safety Controls

The flame sensor, gas valve, and pressure switch were all checked in the Start-up procedure section as part of normal operation.

- 1. Check Main Limit Switch
 - This control shuts off combustion system and energizes air-circulating blower motor, if furnace overheats. By using this method to check limit control, it can be established that limit is functioning properly and will operate if there is a restricted return-air supply or motor failure. If limit control does not function during this test, cause must be determined and corrected.
 - a. Run furnace for at least 5 minutes.
 - b. Gradually block off return air with a piece of cardboard or sheet metal until the limit trips.
 - c. Unblock return air to permit normal circulation.
 - d. Burners will re-light when furnace cools down.
- 2. Check Pressure Switch(es)
 - This control proves operation of the draft inducer blower.
 - a. Turn off 115-v power to furnace.
 - b. Disconnect inducer motor lead wires from wire harness.
 - c. Turn on 115-v power to furnace.
 - d. Set thermostat to "call for heat" and wait 1 minute. When pressure switch is functioning properly, hot surface igniter should **NOT** glow and control diagnostic light flashes a status code 3. If hot surface igniter glows when inducer motor is disconnected, shut down furnace immediately.
 - e. Determine reason pressure switch did not function properly and correct condition.
 - f. Turn off 115-v power to furnace.
 - g. Reconnect inducer motor wires, replace door, and turn on 115-v power.
 - h. Blower will run for 90 seconds before beginning the call for heat again.
 - i. Furnace should ignite normally.

Checklist

- 1. Put away tools and instruments. Clean up debris.
- 2. Verify that switches SW1–1 and SW1–6 are OFF and other setup switches are set as desired. Verify that switches SW1–7 and SW1–8 for the blower OFF DELAY are set as desired per **Table 4**.
- 3. Verify that blower and control doors are properly installed.
- 4. Cycle test furnace with room thermostat.
- 5. Check operation of accessories per manufacturer's instructions.
- 6. Review Home Owner's Information with owner.
- 7. Attach literature packet to furnace.

440 04 4221 03

SERVICE A	ND TEC										urnace		IVM
Table 5			G ⁴ AND H V1-5 and SW4	EATING		ELIVEF	RY - CF	M (Bott	om Ret	turn ⁵ w	ith filte	r)	
Unit Size		ng Switch S	Settings					al Static	Pressure	e (ESP)			
040-10	SW2-3	SW2-2	SW2-1	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0
Clg Default:	OFF	OFF	OFF	1125	1080	1020	970	905	855	805	755	700	635
	OFF	OFF	ON	615	555	510	475	440	395	355	270	230	note 8
	OFF	ON	OFF	785	740	695	665	630	590	565	520	485	450
	OFF	ON	ON	990	950	910	875	850	815	770	720	670	615
Cooling (SW2)	ON	OFF	OFF	1125	1080	1020	970	905	855	805	755	700	635
	ON	OFF	ON	1125	1080	1020	970	905	855	805	755	700	635
	ON	ON	OFF	1125	1080	1020	970	905	855	805	755	700	635
	ON	ON	ON	1125	1080	1020	970	905	855	805	755	700	635
Clg SW2:	Max	imum Clg Ai	rflow ²	1125	1080	1020	970	905	855	805	755	700	635
Heating	Hi	gh Heat Airfl	ow ³	815	770	725	695	660	625	595	550	510	475
(SW1)	Lc	w Heat Airfl	ow ³	660	605	560	530	495	450	415	340	300	note 7
060-14 Clg Default:	OFF	OFF	OFF	1330	1295	1260	1220	1190	1150	1110	1075	1045	1005
	OFF	OFF	ON	725	660	600	520	435			See note 4	4	
	OFF	ON	OFF	780	725	660	615	540	See note 4				
	OFF	ON	ON	975	925	875	835	785	750	690	655	610	570
Cooling (SW2)	ON	OFF	OFF	1160	1120	1090	1045	1010	970	920	885	840	800
	ON	OFF	ON	1330	1295	1260	1220	1190	1150	1110	1075	1045	1005
	ON	ON	OFF	1705	1650	1595	1545	1475	1415	1340	1275	1200	1105
	ON	ON	ON	1705	1650	1595	1545	1475	1415	1340	1275	1200	1105
Clg SW2:	Max	imum Clg Ai	rflow ²	1705	1650	1595	1545	1475	1415	1340	1275	1200	1105
	Hi	gh Heat Airfl	ow ³	1145	1105	1075	1030	995	955	905	870	825	785
Heating (SW1)	Lc	ow Heat Airfl	ow ³	870	820	760	720	655	620	560	525	470	435
080-16 Clg Default:	OFF	OFF	OFF	1805	1765	1720	1665	1610	1540	1475	1400	1315	1235
	OFF	OFF	ON	775	635	455	230		ę	See note 8	8		
	OFF	ON	OFF	840	740	675	625	555			See note 4	4	
	OFF	ON	ON	995	955	910	860	815	770	720	660	620	585
Cooling (SW2)	ON	OFF	OFF	1175	1140	1090	1060	1025	980	940	905	855	815
	ON	OFF	ON	1325	1280	1245	1210	1180	1140	1105	1070	1025	990
	ON	ON	OFF	1545	1515	1480	1445	1410	1380	1350	1315	1245	1175
	ON	ON	ON	1805	1765	1720	1665	1610	1540	1475	1400	1315	1235
Clg SW2:	Max	imum Clg Ai	rflow ²	1805	1765	1720	1665	1610	1540	1475	1400	1315	1235
Heating	Hi	gh Heat Airfl	ow ³	1520	1490	1455	1420	1385	1355	1320	1285	1220	1155
(SW1)	Lo	w Heat Airfl	ow ³	1180	1145	1095	1065	1030	985	945	910	860	820

Gas Furnace: (F/G)9MVT

Table 5 (Con Unit Size	t.)		G ⁴ AND H	EATING	AIR D	ELIVEF					ith filte	r)	
Unit Size	SW2-3	ing Switch S SW2-2	Settings SW2-1	0.1	0.2	0.3	0.4	0.5	Pressure 0.6	e (ESP) 0.7	0.8	0.9	1.0
080-20		-				-	-			-			
Clg Default:	OFF	OFF	OFF	1905	1870	1825	1785	1750	1700	1665	1625	1560	1460
	OFF	OFF	ON	950	770	620	515	440	365		See n	ote 4	
	OFF	ON	OFF	1015	935	880	825	765	690	625	580	See r	note 4
	OFF	ON	ON	1155	1105	1040	990	920	875	815	755	710	645
Cooling (SW2)	ON	OFF	OFF	1335	1290	1245	1190	1145	1085	1040	990	930	890
	ON	OFF	ON	1520	1485	1435	1390	1340	1300	1255	1200	1160	1115
	ON	ON	OFF	1905	1870	1825	1785	1750	1700	1665	1625	1560	1460
	ON	ON	ON	2290	2230	2160	2085	2005	1915	1820	1730	1640	1525
Clg SW2:	Max	kimum Clg Ai	2290	2230	2160	2085	2005	1915	1820	1730	1640	1525	
	Н	igh Heat Airf	ow ³	1575	1535	1485	1445	1400	1350	1310	1260	1215	1170
Heating (SW1)		ow Heat Airfl		1230	1170	1125	1065	1015	955	900	855	795	755
100-20				1		l							
Clg Default:	OFF	OFF	OFF	1890	1845	1800	1755	1700	1655	1610	1560	1510	1460
	OFF	OFF	ON	1015	825	630	485	405	325		See n	ote 4	
	OFF	ON	OFF	1080	895	815	740	690	615	555	475	See r	note 4
	OFF	ON	ON	1155	1080	1020	940	890	825	785	710	660	590
Cooling (SW2)	ON	OFF	OFF	1310	1260	1195	1140	1075	1025	970	925	875	810
	ON	OFF	ON	1520	1475	1425	1365	1315	1255	1210	1155	1110	1055
	ON	ON	OFF	1890	1845	1800	1755	1700	1655	1610	1560	1510	1460
	ON	ON	ON	2290	2230	2160	2085	2005	1915	1820	1730	1640	1525
		1											
Clg SW2:	Max	kimum Clg Ai	rflow ²	2290	2230	2160	2085	2005	1915	1820	1730	1640	1525
Heating	Н	igh Heat Airf	ow ³	1905	1865	1825	1775	1730	1685	1640	1590	1545	1490
(SW1)	L	ow Heat Airfl	ow ³	1480	1435	1375	1330	1265	1215	1160	1115	1060	1005
120-22 Clg Default:	OFF	OFF	OFF	2010	1960	1910	1850	1800	1750	1690	1645	1565	1480
	OFF	OFF	ON	1015	805	645	550	480		ļ	See note 4		
	OFF	ON	OFF	1075	975	915	835	765		9	See note 4		
	OFF	ON	ON	1205	1135	1055	1000	935			See note 4		
Cooling (SW2)	ON	OFF	OFF	1400	1330	1260	1190	1145	1080	1035	970	905	845
	ON	OFF	ON	1615	1550	1500	1435	1370	1325	1265	1215	1160	1110
	ON	ON	OFF	2010	1960	1910	1850	1800	1750	1690	1645	1565	1480
	ON	ON	ON	note 8	2375	2300	2205	2115	2010	1890	1750	1645	1550
Clg SW2:	Max	kimum Clg Ai	rflow ²	note 8	2375	2300	2205	2115	2010	1890	1750	1645	1550
		igh Heat Airf		note 8	2375	2300	2205	2115	2010	1890	1750	1645	1550
Heating (SW1)		ow Heat Airfl		1735	1675	1625	1560	1500	1455	1395	1345	1285	1225
(SVVI) See Notes following		an near Airli		1100	10/5	1020	1000	1000	1400	1090	1040	1200	1223

NOTE:

- Nominal 350 CFM/ton cooling airflow is delivered with SW1–5 and SW4–3 set to OFF. Set both SW1–5 and SW4–3 to ON for +7% airflow (nominal 370 CFM/ton). Set SW1–5 to ON and SW4–3 to OFF for +15% airflow (nominal 400 CFM/ton). Set SW4–3 to ON and SW1–5 to OFF for –7% airflow (nominal 325 CFM/ton). The above adjustments in airflow are subject to motor horspower range/capacity.
- 2. Maximum cooling airflow is achieved when switches SW2-1, SW2-2, SW2-3 and SW1-5 are set to ON, and SW4-3 is set to OFF.
- 3. All heating CFM's are when low heat rise adjustment switch (SW1-3) and comfort/efficiency adjustment switch (SW1-4) are both set to OFF.
- 4. Ductwork must be sized for high-heating CFM within the operational range of ESP. Operation within the blank areas of the chart is not recommended because high-heat operation will be above 1.0 ESP.
- 5. All airflows of 1880 CFM or less on 21" and 24.5" casing size furnaces are 5% less on side return only installations.
- 6. Airflows over 1800 CFM require bottom return, two-side return, or bottom and side return. A minimum filter size of 20" x 25" is required.
- For upflow applications, air entering from one side into both the side of the furnace and a return air base counts as a side and bottom return.
 Airflow not stable at this ESP.

SERVICE AND MAINTENANCE PROCEDURES

WARNING

FIRE, INJURY OR DEATH HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

The ability to properly perform maintenance on this equipment requires certain knowledge, mechanical skills, tools, and equipment. If you do not possess these, do not attempt to perform any service and maintenance on this equipment other than those procedures recommended in the Owner's Manual.

A CAUTION

ENVIRONMENTAL HAZARD

Failure to follow this caution may result in environmental pollution.

Remove and recycle all components or materials (i.e. oil, refrigerant, control board, etc.) before unit final disposal.

WARNING

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death, or property damage.

Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position and install a lockout tag. There may be more than one disconnect switch. Lock out and tag switch with a suitable warning label. Verify proper operation after servicing.


ELECTRICAL OPERATION HAZARD

Failure to follow this caution may result in improper furnace operation or failure of furnace.

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

General

These instructions are written as if the furnace is installed in an upflow application. An upflow furnace application is where the blower is located below the combustion and controls section of the furnace, and conditioned air is discharged upward. Since this furnace can be installed in any of the 4 positions shown in **Figure 7**, you must revise your orientation to component location accordingly.



Electrical Controls and Wiring

 Λ

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

There may be more than one electrical supply to the furnace. Check accessories and cooling unit for additional electrical supplies that must be shut off during furnace servicing. Lock out and tag switch with a suitable warning label.

The electrical ground and polarity for 115-v wiring must be properly maintained. Refer to **Figure 8** for field wiring information and to **Figure 16** for furnace wiring information.

NOTE: If the polarity is not correct, the STATUS LED on the control will flash code 10 and prevent the furnace from heating. The control system also requires an earth ground for proper operation of the control and flame-sensing electrode.


The 24-v circuit contains an automotive-type, 3-amp. fuse located on the control. (See **Figure 4**) Any shorts of the 24-v wiring during installation, service, or maintenance will cause

Troubleshooting

Refer to the service label. (See Figure 15—Service Label)

The Troubleshooting Guide – Flow Chart (See **Figure 17**) can be a useful tool in isolating furnace operation problems. Beginning with the word "Start," answer each question and follow the appropriate arrow to the next item. Gas Furnace: (F/G)9MVT

Proper instrumentation is required to service electrical controls. The control in this furnace is equipped with a Status Code LED (Light–Emitting Diode) to aid in installation, servicing, and troubleshooting. Status codes can be viewed at the indicator in blower door. The amber furnace control LED is either a heartbeat, off or a code composed of 1 or 2 digits. The first digit is the number of short flashes, the second digit is the number of long flashes.



For an explanation of status codes, refer to service label located on control door or **Figure 15**, and the troubleshooting guide which can be obtained from your distributor.

Retrieving Stored Fault Codes

The stored status codes will NOT be erased from the control memory, when 115– or 24–v power is interrupted. The control will store up to the last 7 Status Codes in order of occurrence.

1. To retrieve status codes, proceed with the following: **NOTE**: NO thermostat signal may be present at control, and all blower–OFF delays must be completed.

- a. Leave 115-v power to furnace turned on.
- b. Look into blower door indicator for current LED status.
- c. Remove blower door.

NOTE: The Status Codes cannot be retrieved by disconnecting the limit switch. To retrieve Status Codes, follow the procedure below.

- 2. Turn Setup Switch, SW1-1 "ON."
- 3. Manually close blower door switch.
- 4. Control will flash up to 7 Status Codes.
- 5. The last Status Code, or 8th Code, will be a heartbeat.
- 6. Turn SW1-1 "OFF."
- 7. A heartbeat amber LED will appear and indicates proper operation.
- 8. Release blower door switch, install control door and refer to the SERVICE label on the control door for more information.

Component Self-Test

Component Test can ONLY be initiated by performing the following:

- 1. Remove blower door.
- 2. Remove the wire from the "R" terminal of the control board.
- 3. Turn Setup Switch, SW-1-6 "ON."
- 4. Manually close blower door switch.

Blower door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

WARNING

ELECTRICAL SHOCK HAZARD

4

Failure to follow this warning could result in personal injury, or death.

Blower door switch opens 115–v power to furnace control. No component operation can occur unless switch is closed. Exercise caution to avoid electrical shock from exposed electrical components when manually closing this switch for service purposes.

- 5. Component Test sequence will function as follows:
- a. Inducer motor starts on high-speed and continues to run until Step (d.) of component test sequence.

- c. Blower operates for 10 sec, then turns off.
- d. Inducer motor goes to low-speed for 10 seconds, then turns off.
- e. After component test is completed, one or more status codes (heartbeat, 2+5, or 4+1) will flash. See component test section of service label for explanation of status codes.

NOTE: To repeat component test, turn setup switch SW1–6 OFF then back ON.

- f. Turn setup switch SW1-6 OFF.
- 6. Release blower door switch, reattach wire to "R" terminal on furnace control board and replace blower door.

Care and Maintenance

WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never store flammable or combustible materials on, near, or in contact with the furnace, such as:

- 1. Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners, or other cleaning tools.
- 2. Soap powders, bleaches, waxes or other cleaning compounds, plastic or plastic containers, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, or other volatile fluids.
- 3. Paint thinners and other painting compounds, paper bags, or other paper products. Exposure to these materials could lead to corrosion of the heat exchangers.

For continuing high performance and to minimize possible furnace failure, periodic maintenance must be performed on this furnace. Consult your local dealer about proper frequency of maintenance and the availability of a maintenance contract.

WARNING

ELECTRICAL SHOCK AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Turn off the gas and electrical supplies to the furnace and install lockout tag before performing any maintenance or service. Follow the operating instructions on the label attached to the furnace.

WARNING

CARBON MONOXIDE POISONING AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never operate furnace without a filter or filtration device installed. Never operate a furnace with filter or filtration device access doors removed.

Gas Furnace: (F/G)9MVT

CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts, and servicing furnaces.

The minimum maintenance on this furnace is as follows:

- 1. Check and clean air filter each month or more frequently if required. Replace if torn.
- 2. Check blower motor and wheel for cleanliness each heating and cooling season. Clean as necessary.
- 3. Check electrical connections for tightness and controls for proper operation each heating season. Service as necessary.
- Inspect burner compartment before each heating season for rust, corrosion, soot or excessive dust. If necessary, have furnace and burner serviced by a qualified service agency.
- 5. Inspect the vent pipe/vent system before each heating season for water leakage, sagging pipes or broken fittings. Have vent pipes/vent system serviced by a qualified service agency.
- 6. Inspect any accessories attached to the furnace such as a humidifier or electronic air cleaner. Perform any service or maintenance to the accessories as recommended in the accessory instructions.

Cleaning and/or Replacing Air Filter

The air filter type may vary depending on the application or orientation. The filter is external to the furnace casing. There are no provisions for an internal filter with this furnace. See "Filter Arrangement" under the "Installation" section of this manual.

NOTE: If the filter has an airflow direction arrow, the arrow must point toward the blower.

To clean or replace filters, proceed as follows:

4

WARNING

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death, or property damage.

Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position and install a lockout tag. There may be more than one disconnect switch. Lock out and tag switch with a suitable warning label. Verify proper operation after servicing.

- 1. Turn off electrical supply to furnace.
- 2. Remove filter cabinet door.
- 3. Slide filter out of cabinet.
- 4. If equipped with permanent, washable filter, clean filter by spraying cold tap water through filter in opposite direction of airflow. Rinse filter and let dry. Oiling or coating of the filter is not recommended.

A

- 5. If equipped with factory specified disposable media filter, replace only with a factory specified media filter of the same size.
- 6. Slide filter into cabinet.
- 7. Replace filter cabinet door.
- 8. Turn on electrical supply to furnace.

Blower Motor and Wheel Maintenance

To ensure long life, economy, and high efficiency, clean accumulated dirt and grease from blower wheel and motor annually.

The inducer and blower motors are pre–lubricated and require no additional lubrication. These motors can be identified by the absence of oil ports on each end of the motor.

The following items should be performed by a qualified service technician. Clean blower motor and wheel as follows:

- 1. Turn off electrical supply to furnace.
- 2. Remove blower door.
- 3. All factory wires can be left connected, but field thermostat and accessory wiring may need to be disconnected depending on their length and routing.
- 4. If the vent and combustion air pipe passes through the blower compartment, it will be necessary to remove the pipes from the blower compartment.

Disconnect the vent and combustion air pipe by:

- a. Loosen the clamps on the vent couplings and combustion air pipe external to the furnace.
- b. Separate the pipes from the couplings and move them aside.
- c. Loosen the clamps on the vent couplings and combustion air pipe located on the blower shelf.
- d. Separate the pipes from the blower compartment and set aside.
- e. Remove the couplings from the pipe adapters and set aside.
- f. After servicing the blower, reverse steps a through e.
- g. Tighten all clamps 15 lb-in.

See Figure 9 for steps 5 through 14.

5. Remove screws securing blower assembly to blower shelf and slide blower assembly out of furnace. Detach ground wire and disconnect blower motor harness plugs from blower motor.


NOTE: Blower wheel is fragile. Use care.

- 6. Clean blower wheel and motor by using a vacuum with soft brush attachment. Be careful not to disturb balance weights (clips) on blower wheel vanes. Do not bend wheel or blades as balance will be affected.
- 7. If greasy residue is present on blower wheel, remove wheel from the blower housing and wash it with an appropriate degreaser. To remove wheel:
 - a. Mark blower wheel location on shaft before disassembly to ensure proper reassembly.
 - b. Loosen setscrew holding blower wheel on motor shaft.

NOTE: Mark blower mounting arms and blower housing so each arm is positioned at the same hole location during reassembly.

- c. Mark blower wheel orientation and cutoff plate location to ensure proper reassembly.
- d. Remove screws securing cutoff plate and remove cutoff plate from housing.
- e. Remove bolts holding motor mounts to blower housing and slide motor and mounts out of housing.
- f. Remove blower wheel from housing.

- g. Clean wheel per instructions on degreaser cleaner. Do not get degreaser in motor.
- 8. Reassemble motor and blower wheel by reversing items 7b through 7f. Ensure wheel is positioned for proper rotation.
- 9. Torque motor mounting bolts to 40 +/- 10 lb-in. when reassembling.
- 10. Torque blower wheel set screw to 160 +/- 20 lb-in. when reassembling.
- 11. Verify that blower wheel is centered in blower housing and set screw contacts the flat portion of the motor shaft. Loosen set screw on blower wheel and reposition if necessary.



Blower Assembly (Cont.)

- 12. Spin the blower wheel by hand to verify that the wheel does not rub on the housing.
- 13. Reinstall blower assembly in furnace.
- 14. Reinstall 2 screws securing blower assembly to blower deck.
- Reconnect blower leads to furnace control. Refer to furnace wiring diagram, and connect thermostat leads if previously disconnected.

NOTE: Be sure to attach ground wire and reconnect blower harness plugs to blower motor.

WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Blower door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

- 16. Downflow or horizontal furnaces with vent pipe through furnace only:
 - a. Install and connect short piece of vent pipe inside furnace to existing vent.
 - b. Connect vent connector to vent elbow.
- 17. Turn on electrical supply. Manually close blower door switch. Use a piece of tape to hold switch closed. Check for proper rotation and speed changes between heating and cooling by jumpering R to G and R to Y/Y2 on furnace control thermostat terminals. If outdoor temperature is below 70°F, turn off circuit breaker to outdoor unit before running furnace in the cooling cycle. Turn outdoor circuit breaker on after completing cooling cycle. (See Figure 4)

NOTE: If R–W/W1 thermostat terminals are jumpered at the time blower door switch is closed, blower will run for 90 sec before beginning a heating cycle.

- a. Perform component self-test as shown at the bottom of the SERVICE label, located on the control door.
- b. Verify blower is rotating in the correct direction
- 18. If furnace is operating properly, RELEASE BLOWER DOOR SWITCH. Remove any jumpers or reconnect any disconnected thermostat leads. Replace blower door.

19. Turn on gas supply and cycle furnace through one complete heating cycle. Verify the furnace temperature rise as shown in Adjustments Section. Adjust temperature rise as shown in Adjustments Section.

Cleaning Burners and Flame Sensor

The following items must be performed by a qualified service technician. If the burners develop an accumulation of light dirt or dust, they may be cleaned by using the following procedure:

NOTE: Use a back-up wrench on the gas valve to prevent the valve from rotating on the manifold or damaging the mounting to the burner assembly.

WARNING

ELECTRICAL SHOCK AND FIRE HAZARD


Failure to follow this warning could result in personal injury, death, and/or property damage.

Turn off the gas and electrical supplies to the furnace and install lockout tag before performing any maintenance or service. Follow the operating instructions on the label attached to the furnace.

Refer to Figure 10.

Ą

- 1. Disconnect power at external disconnect, fuse or circuit breaker.
- 2. Turn off gas at external shut-off or gas meter.
- 3. Remove control door and set aside.
- 4. Turn electric switch on gas valve to OFF.
- 5. Disconnect the gas pipe from gas valve and remove pipe from the furnace casing.
- 6. Remove individual wires from terminals on gas valve (All other models).
- 7. Disconnect Hot Surface Igniter (HSI) wires from HSI.
- 8. Disconnect Flame Sensor wire from Flame Sensor.
- 9. Support the manifold and remove the 4 screws that secure the manifold assembly to the burner assembly and set aside. Note the location of the green/yellow wire and ground terminal.
- 10. Inspect the orifices in the manifold assembly for blockages or obstructions. Remove orifice and clean or replace orifice.
- 11. Remove the four screws that attach the top plate of the casing to the furnace.
- 12. Raise top plate up slightly and prop it up with a small piece of wood or folded cardboard.
- 13. Support the burner assembly and remove the screws that attach the burner assembly to the heat exchanger cell panel.
- 14. Remove wires from both rollout switches.
- 15. Slide one-piece burner out of slots on sides of burner assembly.
- 16. Remove the flame sensor from the burner assembly.
- 17. (Optional) Remove the Hot Surface Igniter (HSI) and bracket from the burner assembly.
- 18. Check igniter resistance. Nominal resistance is 40 to 70 ohms at room temperature and is stable over the life of the igniter.
- 19. Clean burner with a brush and a vacuum.
- 20. Clean the flame sensor with fine steel wool (0000 grade). Do not use sand paper or emery cloth.




To reinstall burner assembly:

- 1. Install the Hot Surface Igniter (HSI) and bracket in burner assembly.
- 2. Install flame sensor on burner.
- Align the edges of the one-piece burner with the slots in the burner assembly and slide the burners forward until they are fully seated in the burner assembly.
- 4. Align the orifices in the manifold assembly with the support rings on the end of the burner.
- 5. Insert the orifices in the support rings of the burners.

NOTE: If manifold does not fit flush against the burner, do not force the manifold on the burner assembly. The burners are not fully seated forward in the burner assembly. Remove the manifold and check burner positioning in the burner assembly assembly before re-installing the manifold.

- 6. Attach the green/yellow wire and ground terminal to one of the manifold mounting screws.
- 7. Install the remaining manifold mounting screws.
- 8. Check the igniter alignment. See Figure 10, Figure 11 and Figure 12.




- 9. Attach the wires to the roll-out switches.
- 10. Align the burner assembly with the openings in the primary cell inlet panel and attach the burner assembly to the cell panel.
- 11. Connect the wire for the flame sensor.
- 12. Connect the wire for the Hot Surface Igniter.

NOTE: Use propane-resistant pipe dope to prevent leaks. Do not use Teflon tape.

13. Install the gas pipe to the gas valve.

Gas Furnace: (F/G)9MVT



WARNING

FIRE OR EXPLOSION HAZARD

A

Failure to follow this warning could result in personal injury, death, and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

- 14. Check for gas leaks with a commercially available soap solution made specifically for the detection of leaks.
- 15. Turn gas on at electric switch on gas valve and at external shut-off or meter
- 16. Turn power on at external disconnect, fuse or circuit breaker.
- 17. Run the furnace through two complete heating cycles to check for proper operation
- 18. Install control door when complete.

Servicing Hot Surface Igniter

The igniter does **NOT** require annual inspection. Check igniter resistance before removal. Refer to **Figure 10**, **Figure 11** and **Figure 12**.

- 1. Turn off gas and electrical supplies to furnace.
- 2. Remove control door.
- 3. Disconnect igniter wire connection.
- 4. Check igniter resistance. Igniter resistance is affected by temperature. Only check resistance when the igniter is at room temperature.
 - a. Using an ohm meter, check resistance across both igniter leads in connector.
 - b. Cold reading should be between 40 ohms and 70 ohms.
- 5. Remove igniter assembly.
 - a. Using a 1/4-in. driver, remove the two screws securing the igniter mounting bracket to the burner assembly. (See Figure 10)

- b. Carefully withdraw the igniter and bracket assembly through the front of the burner assembly without striking the igniter on surrounding parts.
- c. Inspect igniter for signs of damage or failure.
- d. If replacement is required, remove the screw that secures the igniter on igniter bracket and remove the igniter.
- 6. To replace igniter and bracket assembly, reverse items 5a through 5d.
- 7. Reconnect igniter harness to the igniter, dressing the igniter wires to ensure there is no tension on the igniter itself. (See **Figure 10**)
- 8. Turn on gas and electrical supplies to furnace.
- 9. Verify igniter operation by initiating control board self-test feature or by cycling thermostat.
- 10. Replace control door.

Flushing Collector Box and Drainage System

WARNING

ELECTRICAL SHOCK AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Turn off the gas and electrical supplies to the furnace and install lockout tag before performing any maintenance or service. Follow the operating instructions on the label attached to the furnace.

- 1. Turn off gas and electrical supplies to furnace.
- 2. Remove control door.
- 3. Disconnect pressure switch tube from pressure switch port.

NOTE: Ensure the pressure switch tube disconnected from the pressure switch is higher than the collector box opening or water will flow out of tube.

- 4. Remove the collector box plug from the top port on the upper corner of the collector box. (See **Figure 1**)
- 5. Attach a funnel with a flexible tube to port on the collector box.
- 6. Flush inside of collector box with water until discharge water from condensate trap is clean and runs freely.
- 7. Repeat steps 4 thru 6 with middle plug on upper corner of collector box.
- 8. Remove the pressure switch tube from the collector box.

NOTE: Do **NOT** blow into tube with tube connected to the pressure switch.

- 9. Clean pressure switch port on collect box with a small wire. Shake any water out of pressure switch tube.
- 10. Reconnect tube to pressure switch and pressure switch port.
- 11. Remove the relief tube from the port on the collector box and the trap.
- 12. Clean the relief port on collect box and the trap with a small wire. Shake any water out of the tube.
- 13. Reconnect relief tube to trap and collector box ports.

Cleaning Condensate Drain and Trap

NOTE: If the condensate trap is removed, a new gasket between the trap and collector box is required. Verify a condensate trap gasket is included in the service kit or obtain one from your local distributor.

- 1. Disconnect power at external disconnect, fuse or circuit breaker.
- 2. Turn off gas at external shut-off or gas meter.

- 3. Remove control door and set aside.
- 4. Turn electric switch on gas valve to OFF.
- 5. Disconnect external drain from condensate drain elbow or drain extension pipe inside the furnace and set aside.
- 6. Disconnect the condensate trap relief hose from collector box port and condensate trap.

NOTE: If condensate has a heat pad attached to the trap, trace the wires for the pad back to the connection point and disconnect the wires for the heat pad.

- 7. Remove the screw that secures the condensate trap to the collector box, remove the trap and set aside.
- 8. Remove the trap gasket from the collector box if it did not come off when the trap was removed.
- 9. Discard the old trap gasket.
- 10. Rinse condensate trap in warm water until trap is clean.
- 11. Flush condensate drain lines with warm water. Remember to check and clean the relief port on the collector box.
- 12. Shake trap dry.
- 13. Clean port on collector box with a small wire.

To re-install Condensate Drain and Trap:

- 1. Remove adhesive backing from condensate trap gasket
- 2. Install gasket on collector box
- 3. Align the condensate trap with the drain opening on the collector box and secure the trap with the screw
- 4. Attach the relief hose to the relief port on the condensate trap and collector box.
- 5. Secure tubing to prevent any sags or traps in the tubing.
- 6. Connect condensate drain elbow or drain extension elbow to the condensate trap
- 7. Connect the leads of the condensate heat pad (if used)
- 8. Connect external drain piping to the condensate drain elbow or drain extension pipe.
- 9. Turn gas on at electric switch on gas valve and at external shut-off or meter
- 10. Turn power on at external disconnect, fuse or circuit breaker.
- 11. Run the furnace through two complete heating cycles to check for proper operation
- 12. Install control door when complete.

Checking Heat Pad Operation (If Applicable)

In applications where the ambient temperature around the furnace is $32^{\circ}F$ or lower, freeze protection measures are required. If this application is where heat tape has been applied, check to ensure it will operate when low temperatures are present.

NOTE: The Heat Pad, when used, should be wrapped around the condensate drain trap. There is no need to use heat tape within the furnace casing. Most heat tapes are temperature activated, and it is not practical to verify the actual heating of the tape. Check the following:

- 1. Check for signs of physical damage to heat tape such as nicks, cuts, abrasions, gnawing by animals, etc.
- 2. Check for discolored heat tape insulation. If any damage or discolored insulation is evident, replace heat tape.
- 3. Check that heat tape power supply circuit is on.

Cleaning Heat Exchangers

The following items must be performed by a qualified service technician.

Primary Heat Exchangers


If the heat exchangers get an accumulation of light dirt or dust on the inside, they may be cleaned by the following procedure:

NOTE: If the heat exchangers get a heavy accumulation of soot and carbon, both the primary and secondary heat exchangers should be replaced rather than trying to clean them thoroughly due to their intricate design. A build-up of soot and carbon indicates that a problem exists which needs to be corrected, such as improper adjustment of manifold pressure, insufficient or poor quality combustion air, improper vent termination, incorrect size or damaged manifold orifice(s), improper gas, or a restricted heat exchanger (primary or secondary). Action must be taken to correct the problem.

- 1. Turn off gas and electrical supplies to furnace.
- 2. Remove control door.
- 3. Disconnect wires or connectors to flame rollout switch, gas valve, igniter, and flame sensor.
- 4. Using backup wrench, disconnect gas supply pipe from furnace gas control valve.
- 5. Remove two screws attaching top filler plate and rotate upwards to gain access to screws attaching burner assembly to cell panel.
- 6. Remove screws attaching burner assembly to cell panel. (See Figure 10)


NOTE: Burner cover, manifold, gas valve, and burner assembly should be removed as one assembly.

7. Clean heat exchanger openings with a vacuum and a soft brush. (See Figure 13)



NOTE: After cleaning, inspect the heat exchangers to ensure they are free of all foreign objects that may restrict flow of combustion products.

- 8. Reverse items 6 through 1 for reassembly.
- 9. Refer to furnace wiring diagram and reconnect wires to flame rollout switch, gas valve, igniter, and flame sensor.
- 10. Turn on gas and electrical supplies to furnace.
- 11. Check furnace operation through two complete heat operating cycles. Look at burners. Burner flames should be clear blue, almost transparent. (See **Figure 14**)
- 12. Check for gas leaks.



WARNING

FIRE OR EXPLOSION HAZARD

 Λ

Failure to follow this warning could result in personal injury, death, and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

13. Replace main furnace door.

Secondary Heat Exchangers

The condensing side (inside) of the secondary heat exchanger CANNOT be serviced or inspected without complete removal of the heat exchanger assembly. Detailed information on heat exchanger removal can be obtained from your Distributor.

Winterization



UNIT AND PROPERTY DAMAGE HAZARD

Failure to follow this caution may result in unit component or property damage.

If the furnace is installed in an unconditioned space where the ambient temperatures may be 32° F (0° C) or lower, freeze protection measures must be taken to prevent property or product damage.

Since the furnace uses a condensing heat exchanger, some water will accumulate in the unit as a result of the heat transfer process. Therefore, once it has been operated, it cannot be turned off and left off for an extended period of time when temperatures will reach $32^{\circ}F$ (0°C) or lower unless winterized. Follow these procedures to winterize your furnace:

UNIT COMPONENT DAMAGE HAZARD

Failure to follow this caution may result in damage to the furnace and other property damage.


Do not use ethylene glycol (automotive antifreeze coolant or equivalent). Failure of plastic components may occur.

- 1. Obtain propylene glycol (RV/swimming pool antifreeze or equivalent).
- 2. Turn off gas and electrical supplies to your furnace.
- 3. Remove furnace control door.
- Remove the top unused rubber plug from the port on the collector box opposite the condensate trap. (See Figure 1)
- 5. Connect a field supplied 3/8-in. (9.5-mm) ID tube to the open port on the collector box

- 6. Insert a field supplied funnel into the tube.
- 7. Pour 1 quart of anti-freeze solution into the funnel/tube. Antifreeze should run through the collector box, overfill condensate trap and flow to an open drain.


Gas Furnace: (F/G)9MVT

- 8. Replace the rubber plug in the port on the collector box.
- 9. Remove the middle unused rubber plug from the port on the collector box opposite the condensate trap. See **Figure 1**.
- 10. Repeat Steps 5 through 8.
- 11. If a condensate pump is used, check with pump manufacturer to verify pump is safe for use with antifreeze used. Allow pump to start and pump anti-freeze to open drain.
- 12. Replace main door.
- 13. When furnace is re-started, flush condensate pump with clear water to check for proper operation before re-starting furnace.
- 14. Propylene glycol need not be removed before re-starting furnace.




338317-2 Rev G







- Solid lines inside PCB are printed circuit board conductors and
- are not included in legend.
- Replace only with a 3 amp fuse.
- Inductor is used with 3/4 hp and 1 hp ECM Blower motors.
- 8. Factory connected when (LGPS) not used.
- Blower off-delay, gas heating selections are (90, 120, 150, 180) seconds, cooling or heat pump 90 seconds or 5 seconds when dehumidify call is active.
- Ignition lockout will occur after four consecutive usuccessful trials for ignition. Control will auto-reset after three hours.
- 11. Any of the 5 wires shown within the NEUTRAL L2 box can be connected to any terminal within the box.
- 12. Blower motor (BLWM) and Inducer motor (IDM) are locked-rotor overload protected by redundant electronic control circuits.



338317-2 Rev G







Figure 17

Troubleshooting Guide – Flow Chart





Gas Furnace: (F/G)9MVT



Sequence of Operation

NOTE: Furnace control must be grounded for proper operation or else control will lock out. Control is grounded through green/yellow wire routed to gas valve and burner box screw. Using the schematic diagram in **Figure 16**, follow the sequence of operation through the different modes. Read and follow the wiring diagram very carefully.

NOTE: If a power interruption occurs during a call for heat (W/W1 or W/W1-and-W2), the control will start a 90-second blower-only ON period two seconds after power is restored, if the thermostat is still calling for gas heating. The amber LED light will flash code 1+2 during the 90-second period, after which the LED will flash a heartbeat (bright-dim), as long as no faults are detected. After the 90-second period, the furnace will respond to the thermostat normally.

The blower door must be installed for power to be conducted through the blower door interlock switch ILK to the furnace control CPU, transformer TRAN, inducer motor IDM, blower motor BLWM, hot-surface igniter HSI, and gas valve GV.

1. Two-Stage Heating (Adaptive Mode) with Single-Stage Thermostat

NOTE: The low-heat only switch SW1-2 selects either the low-heat only operation mode when ON, (see item 2. below) or the adaptive heating mode when OFF in response to a call for heat. (See **Figure 5**) When the W2 thermostat terminal is energized it will always cause high-heat operation when the R-to-W circuit is closed, regardless of the setting of the low-heat only switch. This furnace can operate as a two-stage furnace with a single-stage thermostat because the furnace control CPU includes a programmed adaptive sequence of controlled operation, which selects low-heat or high-heat operation. This selection is based upon the stored history of the length of previous gas-heating periods of the single-stage thermostat.

The furnace will start up in either low- or high-heat. If the furnace starts up in low-heat, the control CPU determines the low-heat on-time (from 0 to 16 minutes) which is permitted before switching to high-heat.

If the power is interrupted, the stored history is erased and the control CPU will select low-heat for up to 16 minutes and then switch to high-heat, as long as the thermostat continues to call for heat. Subsequent selection is based on stored history of the thermostat cycle times.

The wall thermostat "calls for heat", closing the R-to-W circuit. The furnace control performs a self-check, verifies the low-heat and high-heat pressure switch contacts LPS and HPS are open, and starts the inducer motor IDM in high-speed.

a. Inducer Prepurge Period

- (1.) If the furnace control CPU selects low-heat operation the inducer motor IDM comes up to speed, the low-heat pressure switch LPS closes, and the furnace control CPU begins a 15-second prepurge period. If the low-heat pressure switch LPS fails to remain closed the inducer motor IDM will remain running at high-speed. After the low-heat pressure switch re-closes the furnace control CPU will begin a 15-second prepurge period, and continue to run the inducer motor IDM at high-speed.
- (2.) If the furnace control CPU selects high-heat operation, the inducer motor IDM remains running at high-speed, and the high-heat pressure switch relay HPSR is de-energized to close the NC contact. When sufficient pressure is available the high-heat pressure switch HPS closes, and the high-heat gas valve solenoid

GV-HI is energized. The furnace control CPU begins a 15-second prepurge period after the low-heat pressure switch LPS closes. If the high-heat pressure switch HPS fails to close and the low-heat pressure switch LPS closes, the furnace will operate at low-heat gas flow rate until the high-heat pressure switch closes for a maximum of 2 minutes after ignition.

- b. **Igniter Warm-Up** –At the end of the prepurge period, the Hot–Surface Igniter HSI is energized for a 17–second igniter warm–up period.
- c. **Trial-For-Ignition Sequence** –When the igniter warm-up period is completed the main gas valve relay contact GVR closes to energize the gas valve solenoid GV-M. The gas valve solenoid GV-M permits gas flow to the burners where it is ignited by the HSI. Five seconds after the GVR closes, a 2-second flame proving period begins. The HSI igniter will remain energized until the flame is sensed or until the 2-second flame proving period begins. If the furnace control CPU selects high-heat operation, the high-heat gas valve solenoid GV-HI is also energized.
- d. Flame-Proving When the burner flame is proved at the flame-proving sensor electrode FSE, the inducer motor IDM switches to low-speed unless the furnace is operating in high-heat, and the furnace control CPU begins the blower-ON delay period and continues to hold the gas valve GV-M open. If the burner flame is not proved within two seconds, the control CPU will close the gas valve GV-M, and the control CPU will repeat the ignition sequence for up to three more Trials-For-Ignition before going to Ignition-Lockout. Lockout will be reset automatically after three hours, or by momentarily interrupting 115 vac power to the furnace, or by interrupting 24 vac power at SEC1 or SEC2 to the furnace control CPU (not at W/W1, G, R, etc.). If flame is proved when flame should not be present, the furnace control CPU will lock out of Gas-Heating mode and operate the inducer motor IDM on high speed until flame is no longer proved.
- Blower-On delay If the burner flame is proven the blower-ON delays for low-heat and high-heat are as follows:

Low-heat – 45 seconds after the gas valve GV–M is opened the blower motor BLWM is turned ON at low-heat airflow.

High-heat – 25 seconds after the gas valve GV-M is opened the BLWM is turned ON at high-heat airflow. Simultaneously, the humidifier terminal HUM and electronic air cleaner terminal EAC-1 are energized and remain energized throughout the heating cycle.

- f. Switching from Low- to High-Heat If the furnace control CPU switches from low-heat to high-heat, the furnace control CPU will switch the inducer motor IDM speed from low to high. The high-heat pressure switch relay HPSR is de-energized to close the NC contact. When sufficient pressure is available the high-heat pressure switch HPS closes, and the high-heat gas valve solenoid GV-HI is energized. The blower motor BLWM will transition to high-heat airflow five seconds after the furnace control CPU switches from low-heat to high-heat.
- g. **Switching from High- to Low-Heat** -The furnace control CPU will not switch from high-heat to low-heat while the thermostat R-to-W circuit is closed when using a single-stage thermostat.
- h. **Blower-Off Delay** –When the thermostat is satisfied, the R to W circuit is opened, de-energizing the gas

valve GV-M, stopping gas flow to the burners, and de-energizing the humidifier terminal HUM. The inducer motor IDM will remain energized for a 15-second post-purge period. The blower motor BLWM and air cleaner terminal EAC-1 will remain energized at low-heat airflow or transition to low-heat airflow for 90, 120, 150, or 180 seconds (depending on selection at blower-OFF delay switches). The furnace control CPU is factory-set for a 120-second blower-OFF delay.

2. Two-Stage Thermostat and Two-Stage Heating See Figure 18-Figure 21 for thermostat connections.

NOTE: In this mode the low-heat only switch SW1-2 must be ON to select the low-heat only operation mode in response to closing the thermostat R-to-W1 circuit. Closing the thermostat R-to-W1-and-W2 circuits always causes high-heat operation, regardless of the setting of the low-heat only switch.

The wall thermostat "calls for heat", closing the R-to-W1 circuit for low-heat or closing the R-to-W1-and-W2 circuits for high-heat. The furnace control performs a self-check, verifies the low-heat and high-heat pressure switch contacts LPS and HPS are open, and starts the inducer motor IDM in high-speed.

The start up and shut down functions and delays described in item 1. above apply to the 2-stage heating mode as well, except for switching from low- to high-Heat and vice versa.

- a. **Switching from Low- to High-Heat** If the thermostat R-to-W1 circuit is closed and the R-to-W2 circuit closes, the furnace control CPU will switch the inducer motor IDM speed from low to high. The high-heat pressure switch relay HPSR is de-energized to close the NC contact. When sufficient pressure is available the high-heat pressure switch HPS closes, and the high-heat gas valve solenoid GV-HI is energized. The blower motor BLWM will transition to high-heat airflow five seconds after the R-to-W2 circuit closes.
- b. Switching from High- to Low-Heat -If the thermostat R-to- W2 circuit opens, and the R-to-W1 circuit remains closed, the furnace control CPU will switch the inducer motor IDM speed from high to low. The high-heat pressure switch relay HPSR is energized to open the NC contact and de-energize the high-heat gas valve solenoid GV-HI. When the inducer motor IDM reduces pressure sufficiently, the high-heat pressure switch HPS will open. The gas valve solenoid GV-M will remain energized as long as the low-heat pressure switch LPS remains closed. The blower motor BLWM will transition to low-heat airflow five seconds after the R-to-W2 circuit opens.

3. Cooling mode

The thermostat "calls for cooling".

a. Single-Speed Cooling-

See Figure 18 and Figure 20 for thermostat connections

The thermostat closes the R-to-G-and-Y circuits. The R-to- Y circuit starts the outdoor unit, and the R-to-G-and-Y/Y2 circuits start the furnace blower motor BLWM on cooling airflow. Cooling airflow is based on the A/C selection shown in **Table 5**. The electronic air cleaner terminal EAC-1 is energized with 115 vac when the blower motor BLWM is operating.

When the thermostat is satisfied, the R-to-G-and-Y circuits are opened. The outdoor unit will stop, and the furnace blower motor BLWM will continue operating at cooling airflow for an additional 90 seconds. Jumper Y/Y2 to DHUM to reduce the cooling off-delay to 5 seconds. (See **Figure 4**)

b. Two-Stage Thermostat and Two-Speed Cooling See Figure 19 and Figure 21 for thermostat connections

The thermostat closes the R-to-G-and-Y1 circuits for low-cooling or closes the R-to-G-and-Y1-and-Y2 circuits for high-cooling. The R-to-Y1 circuit starts the outdoor unit on low-cooling speed, and the R-to-G-and-Y1 circuit starts the furnace blower motor BLWM at low-cooling airflow which is the CF (continuous fan) selection as shown in **Figure 5**. The R-to-Y1-and-Y2 circuits start the outdoor unit on high-cooling speed, and the R-to-G-and-Y/Y2 circuits start the furnace blower motor BLWM at high-cooling airflow. High-cooling airflow is based on the A/C (air conditioning) selection shown in **Figure 5**.

The electronic air cleaner terminal EAC-1 is energized with 115 vac whenever the blower motor BLWM is operating.

When the thermostat is satisfied, the R-to-G-and-Y1 or R-to-G-and-Y1-and-Y2 circuits are opened. The outdoor unit stops, and the furnace blower BLWM and electronic air cleaner terminal EAC-1 will remain energized for an additional 90 seconds. Jumper Y1 to DHUM to reduce the cooling off-delay to 5 seconds. (See **Figure 16**)

4. Dehumidfy Mode

See **Figure 18**–**Figure 24** for thermostat connections. The H output on the humidify sensing thermostat should be connected to the furnace control thermostat terminal DHUM. When there is a dehumidify demand, the DHUM input is activated, which means 24 vac signal is removed from the DHUM input terminal. In other words, the DHUM input logic is reversed. The DHUM input is turned ON when no dehumidify demand exists. **Activation/Deactivation**

Once 24 vac is detected by the furnace control on the DHUM input, the furnace control operates in dehumidify mode. If the DHUM input is low for more than 48 hours, the furnace control reverts back to non-dehumidify mode.

The cooling operation described in Item 3, Cooling mode. above also applies to operation with a humidity sensing thermostat. The exceptions are listed below:

- a. **Low Cooling**–When the R–to–G–and–Y1 circuit is closed and there is a demand for dehumidification, the low cooling airflow demand is reduced by 10 percent.
- b. High-Cooling-When the R-to-G-and-Y/Y2 circuit is closed and there is a demand for dehumidification, the high cooling airflow demand is reduced by 10 percent.
- c. **Cooling off-delay**–When the "call for cooling" is satisfied and there is a demand for dehumidification, the cooling blower–off delay is decreased from 90 seconds to 5 seconds.

5. Continuous Blower Mode

When the R-to-G circuit is closed by the thermostat, the blower motor BLWM will operate at continuous blower airflow. Continuous blower airflow selection is initially based on the CF (continuous fan) selection shown in **Figure 5**. Factory default is shown in **Figure 5**. Terminal EAC-1 is energized as long as the blower motor BLWM is energized.

During a call for heat, the furnace control CPU will transition the blower motor BLWM to continuous blower airflow, low-heat airflow, or the mid-range airflow, whichever is lowest. The blower motor BLWM will remain ON until the main burners ignite then shut OFF and remain OFF for the blower-ON delay (45 seconds in low-heat, and 25 seconds in high-heat), allowing the furnace heat exchangers to heat up more quickly, then restarts at the end of the blower-ON delay period at

low-heat or high-heat airflow, respectively.

The blower motor BLWM will revert to continuous-blower airflow after the heating cycle is completed. In high-heat, the furnace control CPU will drop the blower motor BLWM to low-heat airflow during the selected blower-OFF delay period before transitioning to continuous-blower airflow.

When the thermostat "calls for low-cooling", the blower motor BLWM will switch to operate at low-cooling airflow. When the thermostat is satisfied, the blower motor BLWM will operate an additional 90 seconds at low-cooling airflow before transitioning back to continuous-blower airflow.


When the thermostat "calls for high-cooling", the blower motor BLWM will operate at high cooling airflow. When the thermostat is satisfied, the blower motor BLWM will operate an additional 90 seconds at high-cooling airflow before transitioning back to continuous-blower airflow. When the R-to-G circuit is opened, the blower motor BLWM will continue operating for an additional 5 seconds, if no other function requires blower motor BLWM operation.


6. Heat pump

See Figure 20 and Figure 21 for thermostat connections. When installed with a heat pump, the furnace control automatically changes the timing sequence to avoid long blower off times during demand defrost cycles. Whenever W/W1 is energized along with Y1 or Y/Y2, the furnace control CPU will transition to or bring on the blower motor BLWM at cooling airflow, low-heat airflow, or the mid-range airflow, whichever is lowest. The blower motor BLWM will remain on until the main burners ignite then shut OFF and remain OFF for 25 seconds before coming back on at heating airflow. When the W/W1 input signal disappears, the furnace control begins a normal inducer post-purge period while changing the blower airflow. If Y/Y2 input is still energized the furnace control CPU will transition the blower motor BLWM airflow to cooling airflow. If Y/Y2 input signal disappears and the Y1 input is still energized the furnace control CPU will transition the blower motor BLWM to low-cooling airflow. If both the Y1 and Y/Y2 signals disappear at the same time, the blower motor BLWM will remain on at low-heat airflow for the selected blower-OFF delay period. At the end of the blower-OFF delay, the blower motor BLWM will shut OFF unless G is still energized, in which case the blower motor BLWM will operate at continuous blower airflow.

Component Self Test

Refer to page 17 for instructions.





Gas Furnace: (F/G)9MVT

Сом

Пном

L09F029

Сом


- ним

DHUM

L09F029



HP with Variable Speed Furnace,



NOTES FOR FIGURES Figure 18 – Figure 24

- 1. Refer to outdoor equipment Installation Instructions for additional information and setup procedure.
- 2. Outdoor Air Temperature Sensor must be attached in all dual fuel applications.
- 3. Refer to ICP thermostat Installation Instructions for additional information and setup procedure.
- 4. When using a Humidity Sensing Thermostat, set DEHUMIDIFY OPTIONS to H DE-ENRGZD FOR DEHUM.
- 5. Optional connection. If wire is connected SW1-2 on VS furnace control should be set in ON position to allow ICP Thermostat to control the furnace staging.
- 6. HUM connection is 24 VAC and is energized when the blower turns on during a call for heat.
- 7. When connecting 115 VAC to humidifier use a separate 115 VAC supply.
- 8. When using a humidifier on a HP installation connect humidifier to hot water.

Control door Blower door Top filler plate Bottom filler plate Door Knob Assembly

Electrical group

Control box Junction box Limit switch(es) Circuit board Door switch Transformer 3–Amp fuse Flame Rollout Switch Main Wiring Harness Blower Motor Harness (when used)

Filter Group

Filter(s)

Blower group

Cut-off Plate Blower housing Blower motor Blower wheel Capacitor (when used) Capacitor strap (when used) Power choke (where used)

WARNING

FIRE, EXPLOSION, ELECTRICAL SHOCK AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in dangerous operation, personal injury, death or property damage.

Improper installation, adjustment, alteration, service, maintenance, or use can cause carbon monoxide poisoning, explosion, fire, electrical shock, or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, local gas supplier, or your distributor or branch for information or assistance. The qualified installer or agency must use only factory-authorized and listed kits or accessories when modifying this product.

Have available the product/model number and the serial number located on the unit rating plate to ensure correct replacement parts.

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or the classified section of your local telephone directory under the "Heating Equipment" or "Air Conditioning Contractors and Systems" headings for dealer listing by brand name.

Gas Control Group

Manifold Burner Orifice Flame sensor Hot surface igniter Gas valve

Heat exchanger group

Primary Heat Exchanger assembly Primary Heat Exchanger cell panel Secondary Heat Exchanger assembly Coupling box Containment Plate Tubing Gaskets

Inducer group

Pressure switch(es) Inducer assembly Inducer Inducer motor Motor Module (when used) Inducer motor capacitor (when used) Collector box Condensate trap Condensate trap elbow Gaskets

PRODUCT NOMENCLATURE										
DIGIT POSITION	1	2	3	4	5	6, 7, 8	9, 10	11, 12	13	14
	G	9	М	V	Т	060	17	14	Α	1
G = Mainline Look 1										
F = Mainline Look 2										
N = Entry										
9 = 90% - 100%	EFFIC	IENCY	ļ							
M = Multiposition										
H = Horizontal										
U = Upflow										
D = Downflow		FE	ATURE							
A = Modulating Variable	e Speed ECM									
V = Variable Speed										
X = ECM										
S = Single-stage										
T = Two-stage			FE.	ATURE						
B = Base AFUE Efficie	•									
E = Extra AFUE Efficie	ncy									
C = Communicating										
D = Dual Certified 2-pi	pe or 1–pipe									
R = 2-pipe only										
S = Single-stage										
T = Two-stage										
N = Standard										
L = Low Nox				FE.	ATURE	ļ				
040 = 40,000 BTU/hr										
060 = 60,000 BTU/hr										
080 = 80,000 BTU/hr										
100 = 100,000 BTU/hr										
120 = 120,000 BTU/hr					INPU	ΓΗΕΑΤ	ļ			
14 = 14-3/16"										
17 = 17–1/2"										
21 = 21"					-					
24 = 24–1/2"					CA	ABINET	WIDTH	ļ		
10 = 1000 CFM (max)										
14 = 1400 CFM (max)										
16 = 1600 CFM (max)										
20 = 2000 CFM (max)										
22 = 2200 CFM (max)						COOL	ING AIF	RFLOW		
SALES (MAJOR) REV										
ENGINEERING (MINO	R) REVISION	DIGIT								

International Comfort Products, LLC Consumer Relations Department P.O. Box 128 Lewisburg, TN 37091, USA 931–270–4100