



COPPER BASIN INSTALLATION INSTRUCTIONS

For Drop-In Installation:

1. Use actual basin as your template. Place it upside down on countertop and mark countertop by tracing edge of basin. Be sure to allow clearance for faucet and other accessories or fixtures.
2. Measure inside edge of lip and mark countertop accordingly, inside of the first line.
3. Cut countertop midway in-between the two lines.
4. Temporarily place basin in hole to verify proper fit.
5. Apply silicone around hole in countertop and place basin in hole.
6. Use a level to make sure that the basin is sitting level in all directions, front to back and side to side; while pressing down to seal.
7. Carefully remove any excess silicone.

For Undermount Installation:

1. Use actual basin as your template. Place it upside down on countertop and mark countertop by tracing edge of basin. Be sure to allow clearance for faucet and other accessories or fixtures.
2. Measure inside edge of lip and mark countertop accordingly, inside of the first line.
3. Cut countertop on inside line.
4. Apply silicone around hole in underside of countertop, and position basin.
5. Use a level to make sure that the basin is sitting level in all directions, front to back and side to side; while pressing down to seal.
6. Use mounting clip fasteners to secure basin under the countertop.
7. Carefully remove any excess silicone.

For Vessel Installation:

1. Measure drain opening and mark countertop for drain opening.
2. Cut countertop for drain opening.
3. Place basin on top of countertop and make sure that the drain opening sits down inside of countertop.
4. Use a level to make sure that the basin is sitting level in all directions, front to back and side to side.
5. The hold down nut of the drain pipe will secure the basin to the countertop.

For Raise Profile Installation:

1. Use actual basin as your template. Place it upside down on countertop and mark countertop by tracing edge of basin. Be sure to allow clearance for faucet and other accessories or fixtures.
2. Measure inside edge of lip and mark countertop accordingly, inside of the first line.
3. Cut countertop midway in-between the two lines.
4. Temporarily place basin in hole to verify proper fit.
5. Use wood screws from underneath the countertop and screw into wood blocks and countertop to secure to countertop.
6. Use a level to make sure that the basin is sitting level in all directions, front to back and side to side; while pressing down to seal.
7. Apply silicone around hole in countertop.
8. Carefully remove any excess silicone.

General Installation Notes:

All Native Trails basins, especially undermount installations, should be installed by professional installers. As our basins are hand crafted and dimensions are approximate, we recommend using the actual basin for the cut-out. Different countertop materials will require different methods of cutting and may have other specific needs such as exposed areas of wood that may need waterproofing for undermounting.

Remember to always use non-abrasive cleaners on Native Trails basins. Mild soap and water is recommended.