

Installation Instructions for Top Mounting (self rim) Oliveri Sinks

CAUTION... The sink may have sharp edges around the perimeter & punch-outs, which may cause personal injury.

Please read these instructions before commencing installation.

Stainless Steel is easily scratched. Therefore, considerable care must be undertaken during installation

Inspect the sink for any damage and ensure that any punch-outs are the correct size and location.

DO NOT INSTALL if the sink is DAMAGED, contact your supplier immediately.

1. Ensure that the measurements for the sink chosen will fit into the cabinet.
2. Place the template marked "Top Mount Self Rim Template" on the benchtop in the *exact* position required. Mark around the template and cut around the **INSIDE** of the line.
3. Trial fit to ensure that the sink fits correctly.
4. It is important to seal the vertical face of the benchtop cutout with a suitable timber sealant.
5. Install the foam sealant tape supplied, on the underside of the sink, ensuring that there are no more gaps.
6. Fit the clips to the underside of the sink in the positions shown on the template.
7. It is recommended that a suitable silicone sealant be used in conjunction with the foam tape, particularly on textured or uneven surfaces, to ensure a waterproof seal.
8. Place the sink in the cutout and tighten the fixing clips, using a No. 2 Phillips screwdriver, working from the center of the sink out to the ends.

Care must be taken when tightening the fixing clips, ensuring that the screwdriver point does not slip and damage the sink or cause personal injury.

IT IS ESSENTIAL THAT THE INSTALLATION IS CARRIED OUT CORRECTLY AND THAT THE SEAL IS WATERPROOF, AS TASMAN SINKWARE WILL NOT BE RESPONSIBLE FOR ANY DAMAGE CAUSED BY FAULTY INSTALLATION.

If it is not an Oliveri, it's a compromise.