

INSTALLATION GUIDE FOR STRUCTURAL FOAM BASINS

1. Inspect all parts and material supplied by Jackel, Inc. to assure no shipping damage.
2. Excavate hole large enough to accommodate basin, backfill and inlet piping.
3. Add 4" to 6" of backfill material or concrete to bottom of hole. Ensure it is level, compacted and smooth.
4. Install basin in hole making sure it is level.
5. Carefully backfill with naturally rounded gravel or stone, larger than 3/8" and smaller than 3/4" diameter, around periphery of the basin.
6. Connect all piping as required.
7. Finish floor around basin as required.

