Freestanding Bath Supplies

Cat. No. 4502-PL



ASSEMBLY INSTRUCTIONS

(These instructions are for assembly of bath supplies ONLY not for connection to water supply.)

Parts Included

- Left Supply Tube Right Supply Tube 2- Shafts each connected to a Stop Valve 14 Screws 14 Anchors •
- 2 Connecting Nuts and 2 Flat Rubber Washers 2 Flat Floor Flanges 2 Wall Mounts 2 Wall Support Tubes 2 Tube Fasteners •

Tools Needed

• Wrench • Pliers • Teflon Tape (use as a sealant on all male threaded tubing) •

This water supply tube kit includes the parts listed above ONLY. The faucet in your bathtub should be purchased previously and separate from this kit. This should NOT be used with faucets that use shower risers and shower rods, or with leg tubs that have factory drilled holes.



- 1. First be sure to shut off the the water supply. Remove old water supply tubing. Place a flat rubber washer onto the upper end of each supply tube.
- 2. Screw flat floor flange on to 5" shaft with stop valve attached. Be sure to leave enough thread to go through floor, to attach to your plumbing.
- 3. Screw flange back down till level with floor. Attach to floor with provided screws.
- **4.** If rubber washers are inside connecting nuts remove them. Slide connecting nut over the thread end of the supply tubes and up over the fittings. So that the fittings are completely inside the connecting nuts. Place washers deep inside of connect nuts.
- **5.** When fastening supply tube to wall mounts:
 - a. Attach wall mount flanges to the wall support tubes.
 - b. Attach tube fasteners to wall support tubes and tighten screws.
 - c. Decided where supports will be attached to the wall and fasten with provided screws. Use anchors if necessary.
 - **d.** Slide threaded end of top supply tube into tube fasteners.
- 6. Assemble supply tube into top of stop valve. Tighten screws on tube fastener.

Cleaning Instructions

Wipe this whole set off with warm water and a soft cloth. DO NOT use soaps, cleansers, or brass cleaners as they will disintegrate the protective lacquer coating and leave the brass exposed causing it to tarnish.

NOTE: The Gold Nuts are extra pieces for use with your plumbing. They are not necessarily needed for your installation. Please seek professional help if you have copper plumbing in your home.