



TOWEL HOLDER

BEFORE INSTALLING

Read entire Towel Holder Installation Instructions. Observe all local building and safety codes.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your towel holder, contact Customer Service.

We recommend anchoring any fixtures that will bear weight to wall studs or solid wood blocking. If the studs in your bathroom do not line up to the mounting location for your towel holder, wood blocking can be installed between the studs using standard 2 x 4's. We recommend consulting a professional if you are unfamiliar with this type of installation.

Because wall construction and materials vary from home to home, Signature Hardware does not provide mounting hardware for all of our towel holders. The appropriate mounting hardware can be purchased from your local hardware store.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls or for personal injury during installation.

TOOLS AND MATERIALS:



Pencil



Screwdriver



Level



Drill



Tape Measure



Stud Finder

TOWEL BAR

1. If the mounting brackets and towel bar arrive assembled, disassemble by removing the set screws with an Allen wrench (provided) or screwdriver.
2. Determine the installation location and mark the wall through each of the mounting holes in the mounting brackets.
3. Drill the screw holes with the appropriate drill bit for the wall surface or material.
4. Attach the mounting brackets to the wall with the mounting hardware. Use your level and tape measure to ensure your brackets are perfectly straight and in the proper position.
5. Attach the towel bar to the bar holders and place the bar holders on the mounting brackets. The set screws should be on the underside of the towel holder.
6. Secure by tightening the set screws with your Allen wrench (provided) or screwdriver.

TOWEL RING

1. Determine the installation location and mark the wall through each of the mounting holes in the mounting bracket. The mounting holes should be aligned vertically.
 2. Drill the screw holes with the appropriate drill bit for the wall surface or material.
 3. Attach the mounting bracket to the wall with the mounting hardware.
 4. Place the towel ring on the mounting bracket. The set screw should be on the underside of the towel ring.
- Note: If the set screw is already in place, you may need to loosen the screw when installing your towel ring so that the mounting bracket and towel ring fit together properly.**
5. Secure by tightening the set screws with your Allen wrench (provided) or screwdriver.



TOWEL RACK OR SHELF

1. Assemble by attaching any shelves with the hardware provided. This is done by inserting the assembly screws through the back of the wall brackets and into the shelves. Tighten the assembly screws with the provided Allen wrench.

2. Determine the installation location and mark the wall through each of the mounting holes in the wall bracket. Use your level and tape measure to ensure your shelf is perfectly straight and in the proper position.

3. Drill the screw holes with the appropriate drill bit for the wall surface or material.

4. Attach the shelf to the wall with the mounting hardware.

