

PVC ADAPTOR INSTALLATION PROCEDURES

ADAPTOR

Step One

Identify the valve type (AFC, Mueller, Kennedy, Clow, EJ, etc.) and size (2" to 16"). Then select the proper 6" PVC Adaptor to match the valve.



Step Two and Three

Insert PVC pipe into top of 6" PVC Adaptor and push down until securely in place.



Step Four and Five

Place PVC pipe and 6" PVC Adaptor onto bonnet of valve, push down until securely in place.



CALL OR VISIT OUR WEBSITE TO LEARN MORE

2151 South 54th Street, West Allis, WI 53219 • office 414.764.6733 • fax 414.764.1494 • adaptorinc.com •



American Made