



## TWO PIECE ENTRANCE SET

### BEFORE INSTALLING

Before you begin, read the installation instructions below. Observe all local building and safety codes. For the following installation instructions it is assumed that holes for the handle and lock set are pre-drilled.

### INSTRUCTIONS

Unpack and inspect the product for any shipping damages and ensure that none of the required pieces are missing. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your door handle and lock set, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the handle, lock set, or door, or for personal injury during installation.

Due to the number of pieces that must be fitted simultaneously, it is recommended that someone assist you while attaching the hardware to the door.

### TOOLS AND MATERIALS:



Drill



Masking Tape



Tape Measure



Screwdriver



Hex Wrench



Wood Chisel

### INSTALLATION

1. Tape the handle/deadbolt template in the desired mounting position on the face of the door.
2. Mark the mounting hole locations.
3. Drill mounting holes in the locations marked in the previous step.
4. Tape the latch bolt template to the edge of the door, lining it up with the holes drilled in the previous step.
5. Mark the mounting hole locations on the edge of the door.
6. Drill mounting holes in the locations marked in the previous step.

**Note:** Refer to the template for depth specifications.

7. Insert the deadbolt latch bolt (**A**) into the top hole on the edge of the door. If the faceplate is not flush with the door, carefully chisel out the door as needed.
8. Repeat the previous step for the handle latch bolt (**B**). Remove the latch bolts when complete.
9. Mark the deadbolt face plate (**C**) mounting hole locations on the edge of the door.





## TWO PIECE ENTRANCE SET

### INSTALLATION

10. Drill pilot holes in the locations marked in the previous step.
11. Reinsert the deadbolt latch bolt and attach the face plate with the provided mounting hardware.
12. Repeat the previous steps for the handle face plate (**D**) and latch bolt.
13. Push the handle latch bolt in and insert the spindle (**E**) through the latch bolt mechanism so that the split in the spindle is in the center of the latch bolt. Turn the spindle in the latch bolt to make sure the spindle engages the latch bolt (**F**).
14. To attach the mounting tubes (**G**), thread the short hex screws (**H**) onto the two exterior escutcheon holes (**I**) and tighten with a hex wrench to secure.
15. Thread the mounting tubes (**G**) onto the hex screws and tighten (**J**).
16. Insert the deadbolt cylinder (**K**) into the exterior escutcheon. Make sure the cylinder tail piece is vertical. Push the deadbolt latch bolt in and fit the exterior escutcheon onto the door, keeping the tail piece vertical and making sure to fit the exterior handle over the spindle.
17. Hold the interior mounting plate (**L**) in place with the deadbolt cylinder in the center hole and attach to the door with the provided mounting hardware (**M**).
18. Place the interior escutcheon on the door with the door knob over the spindle. The deadbolt cylinder tail piece fits into the slot on the interior escutcheon.
19. Hand-thread the long mounting screws (**N**) through the interior escutcheon into the mounting tubes attached in step 10. Tighten firmly with a screwdriver.
20. Check both latch bolts to make sure they are functioning correctly. If necessary, unscrew the escutcheons to adjust.





## TWO PIECE ENTRANCE SET

### INSTALLATION

21. Attach the decorative support screw (O) to the mounting tube at the bottom of the exterior escutcheon. Tighten to secure.

22. To install the strike plates (P), mark the end of the latch bolts with lipstick or paint. Close the door, and turn the deadbolt and handle several times to mark the door frame.

23. Use the marks to position the strike plate template. Mark and drill the mounting holes in the door frame according to the depth specified on the template.

24. Chisel out the strike plate area as necessary so that the plate fits flush with the door frame.

25. Secure the strike plates to the door frame with provided mounting hardware.

