


# INSTALLATION STEPS


## For Solid Concrete



1. Drill hole at least 1/4" deeper than anchor length and insert anchor until flange is flush.




2. Fasten fixture by inserting sheet metal screw through fixture and into anchor.



3. Tighten screw.


## For Hollow Material



1. Drill hole and insert anchor until flange is flush.



2. Fasten fixture by inserting sheet metal screw through fixture and into anchor.



3. Expand anchor after screw head is against fixture, tighten screw the number of additional turns indicated on the chart below.