
SINK CARRIER


640

CLINICAL SERVICE SINK CARRIER WITH STEEL UPRIGHTS, CLOSET COUPLING, SUPPORT HARDWARE, NEOPRENE BOWL GASKET & FINISH TRIM.



Style	Min.	Max.
Carrier w/ Adapter	2 1/4	11 1/4
Carrier w/ Fitting	1 1/2	9 1/2

MFG.	NO.	DETAIL	B
American Standard	9512.013	A	24 3/4
Crane	7H-544	A	24 3/8
Eljer	241-0260	A	21 1/4
Kohler	K-12867	B	32 1/4



INSTALLATION

1. SLIDE HEADER COUPLINGS OVER UPRIGHTS AND POSITION BRACKETS IN THE REQUIRED CONFIGURATION (DETAIL A OR B)
2. SECURE BRACKETS TO HEADER COUPLINGS WITH THE HARDWARE PROVIDED.
3. POSITION THE CARRIER TO THE REQUIRED LOCATION AND SECURELY ANCHOR TO THE FLOOR WITH 1/2" WEDGE ANCHORS (ANCHORS NOT INCLUDED)
4. LOCATE BRACKETS TO THE SPECIFIED DIMENSIONS FROM THE FINISHED FLOOR, THEN TIGHTEN THE HEADER COUPLING SET SCREWS.
5. THE 350 WASTE/VENT FITTING MAY NOW BE SECURED TO THE BRACKETS WITH THE HARDWARE PROVIDED. CONNECT PIPING.
6. INSTALL THE THREADED RODS, JAM NUTS AND 4" PLASTIC CLOSET COUPLING.
7. THE FINISH TRIM WILL BE USED AFTER THE FINISH WALLS ARE CONSTRUCTED AND THE SINK IS READY FOR INSTALLATION

Approval Date | Customer Approval | Job Location | Job Name

Dimensional Data (Inches/mm) are Subject to Manufacturers Tolerance and Change Without Notice. Wade Division / Tyler Pipe Assumes No Responsibility For Superseded or Voided Data

AutoCad.dwg