

1. Attached the nipple into the coupler, then secured by the hex nut .
2. Put the cover and the poly column on the nipple, then secured by the loop .
3. Hang the crystal 1 into the ball nut .
4. Put the tube on the socket.
5. Hang the crystal 2 into the arm .

