



INSTALLATION INSTRUCTIONS:

- 1. Be sure wax ring is at least 70°F in temperature to insure proper flow of wax.**
- 2. Press reinforced wax ring around opening.**
- 3. Set bowl in place and use body weight to compress wax. Twist bowl slightly to spread wax.**
- 4. Carefully install toilet to drainage fittings.**