

INSTALLATION: Install hanger type flanges and rod with 4 - #8 X 1-1/4" round head zinc plated steel screws provided. Cover flanges to be on rod before installation of hangers and rod. Slide cover flanges over hangers to complete installation. Install adjustable tension mounted holders and rod by sizing rod 1-5/8" shorter than wall opening. Insert rod into holders and tighten into position with counterclockwise motion on threaded holder until secure.

OPTIONAL FASTENER INFORMATION:

- Wood blocking is preferable behind all wall surfaces where screw-in installation is used (176, 177). If wood blocking is not available, the following fasteners are suggested: Tile/Masonry - Plastic or Lead Anchors, Plaster/Drywall - Toggle Bolts.
- SPECIFICATION: Surface mounted shower rod shall be model (fill in model number) by Liberty Hardware Manufacturing Corporation.

MODEL#	DIM "A"	
176	5', 6'	
176H	5', 6'	
176HP	5', 6'	
177	5', 6'	

