MUELLER® DRILLING AND TAPPING MACHINES

MUELLER 12.1 Shaded area indicates change Rev. 6-10

- ANTI-FRICTION THRUST COLLAR – fluorocarbon impregnated steel bearing sealed in a steel case - no lubrication required.
- RATCHET HANDLE fully enclosed

MUELLER B-101-99007 Machine features

- FEED NUT AND YOKE spring detents hold feed yoke securely in place around boring bar . Square shank on feed yoke fits power operator for automatic feed.
- FEED SLEEVE AND CAP Acme threads require only 2-1/2 turns to remove sleeve and cap for fast disassembly; long bearing surfaces provide exceptional boring bar rigidity; positive metalto-metal contact with upper barrel maintains boring bar alignment; O-ring seals.
- BORING BAR -

chrome plated to resist corrosion; helps assure long life of O-ring seals.

TOOL HOLDING METHOD – transmits force evenly through drive pins on tool to drill and tap pipe. Retaining screw holds tool tightly in boring bar socket for precise alignment of tool and boring bar. Convenient knock-out pin allows easy tool removal.





- □ LOCKING MECHANISM secures the boring bar to the feed yoke to prevent the drill from spiraling into the pipe before the hole is completely drilled. Helps prevent tool breakage.
- O-RING SEALS seal off special cavity inside feed sleeve to provide oil reservoir for lubricating boring bar and O-rings; boring bar wiper ring protects bottom O-ring.
- EASILY MAINTAINED BYPASS VALVE – uses O-ring valve technology for better sealing. Locking feature prevents unintended operation.
- OFFSET BODY reduces collection of chips around flop valve when machine is in horizontal or inclined position; increased diameter gives adequate clearance for inserting greater variety of stops and valves.
- FLOP VALVE seats with pressure, self-aligning, molded neoprene washer; lever handle has positive lock in open or closed position, position indicator included.

MUELLER A-3[™] Drilling and Tapping Machine (not shown)

Similar in design and features as the B-101[™] machine, the A-3 machine can insert larger size tees.

Rev. 3-08 Shaded area indicates changes

MUELLER[®] B-101-99007 DRILLING AND TAPPING MACHINE

MUELLER B-101-99007 Machine - for drilling, tapping and inserting operations under pressure 1/2" to 2-1/2" inclusive

- □ Catalog number **39650**
- Hand or power operation
- Designed for use on pressurized or dry mains

MUELLER

- □ Insert or extract machine inserted service stop tees; pipe plugs to 2-1/2" in size
- □ Use on cast iron or steel pipe
- □ 90 psig (621 kPa) maximum working pressure without optional power clevis
- *When drilling or tapping above 1" by hand, use extension handle.

| ltem | Sizes*** | | | | Operation | Method |
|------------|----------|--------------------------|---------|--------|-------------------------|------------------|
| | | | | | Drill and tap main | Hand or power |
| Service | | 3/4 | 4" | | Insert Service Stop tee | Hand |
| Stop Tees | | Extract Service Stop tee | Hand | | | |
| | 1/2" | 5/8" | 3/4" 1" | | Drill and tap main | Hand or power |
| Pipe Plugs | | | | 1" | Insert pipe plug | Hand |
| | | | | | Extract pipe plug | Hand |
| | | 1-1/4" 1-1/2" 2" | | | Drill and tap main | Hand* or power** |
| | 1-1/4" | | 2" | 2-1/2" | Insert pipe plug | Hand |
| | | | | | Extract pipe plug | Hand |



**When power operating the machine to drill and tap 1-1/2" and larger, only combined shell cutters and taps should be used. Equipment furnished with each machine:

- □ Metal Storage Chest (**89265**)
- Reversible Ratchet Handle (528273)
- □ Small Saddle Gasket (fits between machine and saddle) (40066)
- □ Large Saddle Gasket (fits between saddle and pipe) (40067)
- Flat Link Chain (580551)
- Chain Hooks, Nuts and Washers
- □ Open End Wrench (for E-Z[®] release inserting tools) (**501579**)
- Box End Wrench (for tightening chain hook nuts and tool retaining screw) (500708)
- Body Cleaning Chisel (for cleaning debris from inside machine body) (**40050**)
- Cutting Grease (88366)
- Instruction Manual (Form 8910)
- □ Enhanced Bypass Relief Valve with Locking Feature (682562)

Equipment to be selected:

- □ Combined Drills and Taps or Shell Cutters and Taps
- □ Inserting Tools (used to insert service stop tees or pipe plugs)
- □ Machine Saddles (adapts machine to specific type and size of main)

Optional equipment:

- □ Extracting Tools (used to remove service stop tees or plugs from mains)
- Equipment for special uses
- □ Power Operator

***Nominal



| Weight | |
|--|------------------|
| Total shipping weight | 114 lbs. (52 kg) |
| Handling weight during operation - Upper section | 20 lbs. (9 kg) |
| Handling weight during operation - Lower section | 23 lbs. (10 kg) |

NOTE: All tools and equipment used with the B-101 machine can also be used with the B-100 machine. "B-101" is a registered trademark of Mueller Co., Decatur, IL.



MUELLER Combined Drills and Taps/Shell Cutter and Taps for MUELLER B-101-99007 Machines

Mueller Combined Drills and Taps/Shell Cutter and Taps are designed and manufactured to perfectly match the corresponding service stop tee or plug thread to assure a pressure tight seal. To further assure these tools are of the highest quality, Mueller Combined Drills and Taps/Shell Cutter and Taps are tested by making an actual tap in a cast plate, and the resulting thread is gauged. Each Mueller Combined Drill and Tap/ Shell Cutter and Tap is subjected to a hardness test to assure material integrity.

NOTE: Mueller Co. offers a Reconditioning service for Mueller made combined drills and taps, combined shell cutters and taps, and shell cutters. Contact Mueller Customer Service Center for details.

| Type of Pipe | Size* of Pipe | Tap Size* | CD&T Part Number | Shell Cutter and Tap Complete Part Number |
|--------------|---------------|-----------|------------------|--|
| Cast Iron | 4"-24" | 3/4" | 680581 | - |
| Cast Iron | 4"-24" | 1" | 680582 | - |
| Cast Iron | 4"-24" | 1-1/4" | 681503 | 681970 |
| Cast Iron | 4"-24" | 1-1/2" | 681504 | 681971 |
| Cast Iron | 4"-24" | 2" | 681505 | 681972 |
| Cast Iron | 4"-24" | 2-1/2" | 681506 | 681973 |
| Steel | 4"-24" | 1/2" | 680569 | - |
| Steel | 4"-24" | 3/4" | 680586 | - |
| Steel | 4"-24" | 1" | 680587 | - |
| Steel | 4"-48" | 1-1/4" | 681507 | 682263 |
| Steel | 4"-48" | 1-1/2" | 681508 | 682264 |
| Steel | 4"-48" | 2" | 681509 | 682265 |
| Steel | 4"-48" | 2-1/2" | - | 681973 |

MUELLER[®] B-101-99007 DRILLING AND TAPPING **MACHINE INSERTING & EXTRACTING TOOLS**

Shaded area indicates changes Rev. 12-06

MUELLER E-Z Release® Inserting Tools are provided with a feature that allows the drilling and tapping machine to disengage the tee without backing the tee out of the main. E-Z Release Inserting Tools consist of two parts (a shank and a nut) which are joined by a coarse Acme thread. When the machine disengages

the tee, the two parts of the inserting tool seperate at the Acme thread. The part of the inserting tool left attached to the tee is easily removed once the tapping machine is removed from the main.



Inside thread

Outside thread

Screw Plugs for Machine Inserted Service Stop Tees

| Size^ | | |
|--------|--|--|
| 3/4" | | |
| 680595 | | |
| - | | |
| 680631 | | |
| | | |



Inside thread

Extracting Tools for Service Stop Tees

| Туре | Size* 3/4" |
|--|---------------|
| Extracting Tool - Inside I.P. Thread | 680619 |
| Extracting Tool - Outside I.P. Thread | 680638 |



Outside thread

Outside

thread

Inserting and Extracting Tools for H-10037-99004 Plugs



Type 1/2" 3/4" 1" 1-1/4" 1-1/2" Inserting Tool - Outside 680643 680644 680644 680644 680645 680645 Thread Extracting Tool - Outside 680640 680641 680641 680641 680642 680642 Thread

Size*

2"

2-1/2"

680645

MUELLER[®] B-101-99007 DRILLING AND TAPPING MACHINE SADDLES

Saddle for Cast Iron Pipe

| | O.D. Ran | Dout Number | | |
|------------|----------|-------------|-------------|--|
| Pipe Size* | Minimum | Maximum | Part Number | |
| 2" | 2-11/16" | 3" | 75832 | |
| 3" | 3-1/2" | 4" | 75810 | |
| 4" | 4-3/8" | 5" | 75812 | |
| 5" | 5-13/16" | 6-3/8" | 75833 | |
| 6" | 6-7/16" | 7-1/8" | 75815 | |
| 8" | 8" | 9-1/2" | 75817 | |
| 10" | 10" | 11-5/8" | 40074 | |
| 12" | 11" | 14-1/2" | 75821 | |
| 14" | 14" | 17-3/8" | 75835 | |
| 16" | 16" | 19-3/8" | 75836 | |
| 18" | 17" | 21-1/8" | 75837 | |
| 20" | 19" | 27-1/8" | 75204 | |
| 24" | 21" | 29-1/8" | 75838 | |
| 30" | 26" | 41" | 75839 | |
| 36" | 28" | 47" | 75840 | |
| 48" | 32" | 77" | 75841 | |

Saddle for Steel Pipe

| | O.D. Ran | David Massala au | | |
|------------|----------|------------------|-------------|--|
| Pipe Size* | Minimum | Maximum | Part Number | |
| 2" | 2-1/4" | 2-11/16" | 75808 | |
| 2-1/2" | 2-5/8" | 3-1/8" | 75809 | |
| 3" | 3-1/2" | 4" | 75810 | |
| 3-1/2" | 4" | 4-5/16" | 75811 | |
| 4" | 4-3/8" | 5" | 75812 | |
| 5" | 5-13/16" | 6-3/8" | 75833 | |
| 6" | 6-7/16" | 7-1/8" | 75815 | |
| 8" | 8" | 9-1/2" | 75817 | |
| 10" | 9-1/2" | 12-1/4" | 75819 | |
| 12" | 10-5/8" | 13-1/8" | 75820 | |
| 14" | 11" | 14-1/2" | 75821 | |
| 16" | 14" | 17-3/8" | 75835 | |
| 18" | 16" | 19-3/8" | 75836 | |
| 20" | 17" | 21-1/8" | 75837 | |
| 24" | 19" | 27-1/8" | 75204 | |
| 30" | 26" | 41" | 75839 | |
| 36" | 28" | 47" | 75840 | |



MUELLER

5

Shaded area indicates change Rev. 12-06

MUELLER[®] B-101[™] Machine Saddles

12.6

MUELLER

MUELLER[®] B-101-99007 DRILLING AND TAPPING MACHINES SPECIAL USE EQUIPMENT

Rev. 12-06 Shaded area indicates changes

Ratchet Handle Extension

PART NUMBER: **500684** – Extends length of ratchet handle to give more leverage when hand opening.

| | Flat Link Chain with Eyebolt and Nut PART NUMBER: 580551 – For pipe up to 12". |
|-----------------|--|
| | Flat Link Extension Chain with Bolts and Nuts PART NUMBER: 89059 – 4' (1.2m) extension chain increases 12" (305mm) chain to fit 12"-24" pipe. PART NUMBER: 88126 – 6' (1.8m) extension chain increases 12" (305mm) chain to fit 12"-36" pipe. PART NUMBER: 88127 –10' (3.0m) extension chain increases 12" (305mm) chain to fit 12"-48" pipe. |
| Sector Contract | Elat Chain Hook with Nut |



Flat Chain Hook with Nut PART NUMBER: **580550** Chain hook with nut.



Chain Spreader

PART NUMBER: 40321

Used when tapping pipe 3" or smaller to spread the chain so that it will clear the lower edge of the body of the machine.

MUELLER[®] B-101-99007 DRILLING AND TAPPING MACHINE REPAIR PARTS

MUELLER 12.7

Shaded area indicates change Rev. 12-06

| ltem No. | Part Name | Part Number | |
|----------|------------------|---|---|
| 1 | 5000851 | Detent Pin - 2 | |
| 2 | 59810 | Spring - 2 | |
| 3 | 305006 | Screw - 2 | |
| 4 | 580610 | Friction Collar | |
| 5 | 48130 | Retaining Pin | |
| 6 | 580611 | Feed Nut & Yoke Complete | |
| 7 | 312443 | Yoke Retaining Screw - 2 | |
| 8 | 537126 | Washer - 2 | |
| 9 | 79269 | Boring Bar O-ring - 2 | |
| 10 11 | 500685 | Feed Sleeve & Cap | |
| 11 | 500687 502022 | Cap Packing Boring Bar | |
| 12 | 502022 | Rollpin | |
| 14 | 502025 | Pivot Arm | |
| 15 | 502026 | Pivot Arm Spring | |
| 16 | 502028 | Operating Screw | |
| 17 | 502029 | Lock Nut | |
| 18 | 41435 | Oil Plug | |
| 19 | 500887 | Wiper Ring | |
| 20 | 580609 | Boring Bar Complete | |
| 21 | 500692 | Bearing | |
| 22 | 48130 | Retaining Pin | |
| 23 | 500691 | Bearing Sleeve | |
| 24 | 97795 | Chain Yoke Retaining Screw | |
| 25 | 500683 | Chain Yoke | (61) |
| 26 | 500682 | Cylinder | |
| 27 | 500670 | Valve Body O-ring | |
| 28 | 682161 | Bypass Valve Sub Assembly | 60) |
| 29 30 | 312148 | Bypass Valve Screw - 2 Bypass Valve Gasket | |
| 30 | 311812 502046 | Valve Body | |
| 32 | 40066 | Small Saddle Gasket | |
| 33 | 40067 | Large Saddle Gasket | |
| 34 | 52165 | Lock Washer | |
| 35 | 500672 | Valve Gate Arm | |
| 36 | 72627 | Spring | |
| 37 | 500675 | Lock Screw | - 00- 00- 00- 00- 00- 00- 00- 00- 00- 0 |
| 38 | 500676 | Lock Nut | |
| 39 | 500674 | Valve Washer And Stem | |
| 40 | 500673 | Gate Washer | |
| 41 | 500671 | Valve Gate | |
| 42 | 50369 | Pipe Plug | |
| 44 | 501061 | Handle Screw | |
| 45 | 302575 | Lock Screw | |
| 46 47 | 46280 500669 | Handle Knob | |
| 47 48 | 500669 | Handle Nut Lever Handle | |
| 48 49 | 500668 | Valve Stem Retaining Nut | Cocole 36 (52) (33) (33) |
| 50 | 500666 | Valve Stem | |
| 51 | 41301 | Valve Stem O-ring | |
| 52 | 580550 | Chain Hook - 1 | |
| 53 | 500707 | Chain Hook Washer - 2 | |
| 54 | 500706 | Chain Hook Nut -2 | |
| 55 | 580551 | Chain | |
| 56 | 500694 | Tool Rataining Screw | |
| 57 | 88366 | Cutting Grease | |
| 58 | 500693 | Knock Out Pin | |
| 59 | 500708 | Chain Hook Wrench | |
| 60 | 40050 | Body Cleaning Chisel | |
| 61 | 501579 | Inserting Tool Wrench | \sim $()$ |
| 62 | 528273 | Ratchet Handle Complete | |
| 63 | 682162 | Bypass Valve Safety Plate | |
| | 682561 | Bypass Valve Key Repair Kit | |
| | 306991 | Bypass Spare Retaining Ring | |
| | 682562 | Bypass Valve Repair Kit | |
| | 002002 | Dypass valve Repair Kit | |

NOTE: These illustrations are for parts identification only. DO NOT use these illustrations for assembly or disassembly of machine. Mueller Co. offers a machine repair service. Contact Mueller Customer Service Center for details. Rev. 12-06 Shaded area indicates changes

MUELLER[®] A-3[™] DRILLING AND TAPPING MACHINE

MUELLER A-3 Machine - for drilling, tapping and inserting operations under pressure

1" to 2-1/2" inclusive

8

7

- Catalog number 39210
- Hand or power operation
- Designed for use on pressurized or dry mains
- □ Insert or extract service stop tees 1" to 2" and pipe plugs to 2-1/2" in size

MUELLER

- Use on cast iron and steel pipe
- 90 psig (621 kPa) maximum working pressure without optional power clevis

| Item | | | Sizes** | | | Operation | Method |
|----------------------|----|--------|---------|-----------|--|--------------------------|-------------------|
| | | | | 2" | | Drill and tap main | Hand or power* |
| Service Stop Tees | 1" | 1-1/4" | | | | Insert Service stop tee | Hand |
| | | | | | | Extract Service stop tee | Hand |
| Pipe | | | | ~ | | Drill and tap main | Hand or power* |
| Plugs | 1" | 1-1/4" | 1-1/2" | 2" 2-1/2" | | Insert pipe plug | Hand |
| | | | | | | Extract pipe plug | Hand |

* When power operating the machine to drill and tap 1-1/2" and larger, only combined shell cutters and taps are recommended.

Equipment furnished with each machine:

- Wooden storage chest (98829)
- □ Ratchet handle (85308)
- Ratchet handle extension (86391)
- □ Small saddle gasket (fits between machine and saddle) (40229)
- □ Large saddle gasket (fits between saddle and pipe) (40230)
- □ Flat link chain with eyebolt and nut for 6" thru 16" pipe (83518)
- Chain hook, nut and washer
- Box end wrench for tightening chain hook nuts and tool retaining tools (40028)
- □ Allen wrench (90322)
- □ Open end combination wrench for E-Z release inserting tools (75409)
- Body cleaning chisel (for cleaning debris from inside of machine body) (40205)
- □ Cutting grease (88366)
- □ Instruction Manual (Form **8541**)

Equipment to be selected:

- Combined drills and taps or shell cutters and taps
- □ Inserting tools (used to insert service stop tees or pipe plugs)
- □ Machine saddles (adapts machine to specific type and size of main)

Optional equipment:

- □ Extracting tools (used to remove service stop tees or pipe plugs from mains)
- Equipment for special uses
- Power operator

**Nominal



| Weight | |
|---|------------------|
| Total shipping weight | 188 lbs. (85 kg) |
| Handling weight during operation - Upper section | 40 lbs. (18 kg) |
| Handling weight during operation - Lower section | 58 lbs. (26 kg) |

Shaded area indicates change Rev. 12-06



MUELLER Combined Drills and Taps/Cutters and Taps for A-3 Machines

Mueller Combined Drills and Taps/Cutters and Taps are designed and manufactured to perfectly match the corresponding tee or plug thread to assure a pressure tight seal. To further assure these tools are of the highest quality, Mueller Combined Drills and Taps/Cutters and Taps are tested by making an actual tap in a cast iron plate, and the resulting thread is gaged. Each Mueller Combined Drill and Tap/Cutters and Taps is subjected to a hardness test to assure material integrity.

NOTE: MUELLER CO. offers a reconditioning service for MUELLER made combined drills and taps, combined shell cutters and taps, and shell cutters. Contact MUELLER Customer Service Center for details.

| Type of pipe | Size* of pipe | Tap size* | CD&T part number | Shell cutter & tap complete part number |
|--------------|---------------|-----------|------------------|--|
| Cast Iron | 4"-24" | 3/4" | 680581 | - |
| Cast Iron | 4"-24" | 1" | 680582 | - |
| Cast Iron | 4"-24" | 1-1/4" | 681503 | 681970 |
| Cast Iron | 4"-24" | 1-1/2" | 681504 | 681971 |
| Cast Iron | 4"-24" | 2" | 681505 | 681972 |
| Cast Iron | 4"-24" | 2-1/2" | 681506 | 681973 |
| Steel | 4"-24" | 1/2" | 680569 | - |
| Steel | 4"-24" | 3/4" | 680586 | - |
| Steel | 4"-24" | 1" | 680587 | - |
| Steel | 4"-48" | 1-1/4" | 681507 | 682263 |
| Steel | 4"-48" | 1-1/2" | 681508 | 682264 |
| Steel | 4"-48" | 2" | 681509 | 682265 |
| Steel | 4"-48" | 2-1/2" | - | 681973 |

MUELLER[®] A-3[™] DRILLING AND TAPPING **MACHINE - INSERTING AND EXTRACTING TOOLS**

Rev. 6-10 Shaded area indicates changes

MUELLER E-Z Release® Inserting Tools are provided with a feature that allows the drilling and tapping machine to disengage the tee without backing the tee out of the main. E-Z Release Inserting Tools consist of two parts (a shank and a nut) which are joined by a coarse Acme

thread. When the machine disengages the tee, the two parts of the inserting tool separate at the acme thread. The part of the inserting tool left attached to the tee is easily removed once the tapping machine is removed from the main.



Inside thread

Outside thread





Screw plugs for machine inserted service stop tees

| Turno | Size* | | | |
|----------------------------------|--------|--------|-------|--------|
| Туре | 1" | 1-1/4" | 2" | 2-1/2" |
| E-Z Release Screw Plug | 680596 | 680628 | 83066 | 83157 |
| Inside I.P. Thread | - | 680597 | - | - |
| Screw Plug Outside I.P.Thread | 680632 | 61212 | 61214 | - |



Inside thread

Extracting tools for service stop tees

| Туре | Size* | | | |
|--|--------|--------|-------|-------|
| | 1" | 1-1/4" | 2" | 2-1/2 |
| Extracting Tool - Inside I.P. Thread | 680620 | 680621 | 83180 | - |
| Extracting Tool - Outside I.P. Thread | 680639 | - | - | - |



Outside thread

Inserting and extracting Tools for H-10037-99004 plugs



Outside thread

| Tuno | Size* | | | | |
|-------------------------------------|--------|--------|--------|--------|--------|
| Туре | 1" | 1-1/4" | 1-1/2" | 2" | 2-1/2" |
| Inserting Tool - Outside Thread | 680644 | 680644 | 680645 | 680645 | 680645 |
| Extracting Tool - Outside Thread | 680641 | 680641 | 680642 | 680642 | - |

MUELLER[®] A-3[™] DRILLING AND TAPPING MACHINE SADDLES

Saddle for Cast Iron Pipe

| Dia - 0i + | O.D. Ran | | | |
|------------|----------|---------|-------------|--|
| Pipe Size* | Minimum | Maximum | Part Number | |
| 4" | - | 5" | 75906 | |
| 6" | 6-9/16" | 7-1/8" | 75908 | |
| 8" | 8-7/8" | 9-3/8" | 75909 | |
| 10" | 10-1/8" | 11-1/4" | 75910 | |
| 12" | 11-7/8" | 13-1/2" | 40236 | |
| 14" | 14-1/8" | 16-1/4" | 75911 | |
| 16" | 16" | 18-3/4" | 40238 | |
| 18" | 17-3/4" | 20-1/2" | 75831 | |
| 20" | 18-1/8" | 22-3/4" | 40240 | |
| 24" | 22-1/2" | 27-1/2" | 40241 | |
| 30" | 25-3/4" | 35" | 75912 | |
| 36" | 30-1/8" | 43" | 75913 | |
| 40" | 31-1/4" | 45" | 76701 | |
| 42" | 34" | 51" | 59582 | |
| 48" | 34" | 58" | 75914 | |

Saddle for Steel Pipe

| | O.D. Rang | B ert New Jones | | |
|------------|-----------|------------------------|-------------|--|
| Pipe Size* | Minimum | Maximum | Part Number | |
| 4" | - | 5" | 75906 | |
| 6" | 6" | 6-5/8" | 46703 | |
| 8" | 8" | 8-5/8" | 45384 | |
| 10" | 10" | 10-3/4" | 43294 | |
| 12" | 11-7/8" | 13-1/2" | 40236 | |
| 16" | 14-1/8" | 16-1/4" | 75911 | |
| 18" | 16" | 18-3/4" | 40238 | |
| 20" | 17-3/4" | 20-1/2" | 75831 | |
| 24" | 22-1/2" | 27-1/28" | 40241 | |
| 30" | 25-3/4" | 35" | 75912 | |
| 36" | 30-1/8" | 43" | 75913 | |



MUELLER

Shaded area indicates change Rev. 12-06

MUELLER[®]A-3 Machine Saddles

12.12 MUELLER

Rev. 10-21 Shaded area indicates changes

MUELLER[®] A-3[™] DRILLING AND TAPPING MACHINE EQUIPMENT FOR SPECIAL USES

Flat Link Chain with Eyebolt and Nut PART NUMBER: 85318 – For pipe up to 12".

Flat Link Extension Chain with Bolts and Nuts

PART NUMBER: **82314** – increases 16" chain to fit 16"-24" pipe. PART NUMBER: **81028** – increases 16" chain to fit 16"-36" pipe. PART NUMBER: **81029** –increases 16" chain to fit 16"-48" pipe.



Chain Spreader PART NUMBER: **40321** Used when tapping pipe 6" or smaller to spread the chain so that it will clear the lower edge of the body of the machine.

MUELLER[®] A-3[™] DRILLING AND TAPPING MACHINE REPAIR PARTS

MUELLER 12.13

Shaded area indicates change Rev. 12-06

| Item Part Name 1 86391 Handle extension 2 85308 Ratchet handle complete 3 88366 Cutting grease 4 90322 Allen wrench 6 40028 Chain nut wrench 6 40205 Chisel 7 75409 Wrench 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet wheel 11 40007 Spring pin 13 502027 Rollpin 14 502027 Rollpin 15 502028 Operating screw 20 40213 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 88099 Chain hook 23 503149 Feed sleeve O-ring 24 4135 Oii plug 26 453 | | - | |
|---|-------------|----------------|--------------------|
| 2 85308 Ratchet handle complete 3 88366 Cutting grease 4 90322 Allen wrench 5 40028 Chain nut wrench 6 40205 Chisel 7 75409 Wrench 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet dog 11 40007 Spring 12 40006 Spring pin 13 502027 Rollpin 14 502026 Pivot arm 15 502028 Operating screw 0 4021 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 0 40213 Chain hook 21 89099 Chain hook 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 | ltem No. | Part Number | Part Name |
| 3 88366 Cutting grease 4 90322 Allen wrench 5 40028 Chain nut wrench 6 40205 Chisel 7 75409 Wrench 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet wheel 11 40007 Spring 12 40006 Spring pin 13 502027 Rollpin 14 502025 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85381 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve | | | Handle extension |
| 4 90322 Allen wrench 5 40028 Chain nut wrench 6 40205 Chisel 7 75409 Wrench 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet wheel 11 40007 Spring pin 13 502027 Rollpin 14 502026 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain hook 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw | | | • |
| 5 40028 Chain nut wrench 6 40205 Chisel 7 75409 Wrench 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet wheel 11 40007 Spring 12 40006 Spring pin 13 502025 Pivot arm 15 502026 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 8099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw | | | |
| 6 40205 Chisel 7 75409 Wrench 8 46029 Boring bar nut 9 40044 Ratchet dog 10 40137 Ratchet wheel 11 40006 Spring 12 40006 Spring pin 13 502027 Rollpin 14 502025 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook nut 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain hook 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 519 Handwheel nut 29 | | | |
| 7 75409 Wrench 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet wheel 11 40007 Spring pin 13 502027 Rollpin 14 502025 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Steat nut washer | | | |
| 8 46029 Boring bar nut 9 40004 Ratchet dog 10 40137 Ratchet wheel 11 40007 Spring pin 13 502027 Rollpin 14 502025 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook washer 18 503029 Lock nut 19 502028 Operating screw 24 85318 Chain hook 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing nut 33 503147 Valve body < | | | |
| 10 40137 Ratchet wheel 11 40007 Spring 12 40006 Spring pin 13 502027 Rollpin 14 502025 Pivot arm spring 16 40211 Chain hook wather 17 40212 Chain hook washer 18 502028 Operating screw 00 40213 Chain yoke 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve stem | 8 | | |
| 11 40007 Spring 12 40006 Spring pin 13 502027 Rollpin 14 502025 Pivot arm 15 502026 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502028 Operating screw 20 40213 Chain yoke 21 8909 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing washer 32 40194 Valve stem 33 503147 Valve stem 34 40189 Cag asket | | 40004 | Ratchet dog |
| 12 40006 Spring pin 13 502027 Rollpin 14 502025 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cag gasket | | 1 | |
| 13 502027 Rollpin 14 502025 Pivot arm spring 15 502026 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain yoke 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing washer 32 40194 Valve stem 33 503147 Valve stem 34 40189 Cag asket 35 42042 Seat nut washer <td>11</td> <td></td> <td></td> | 11 | | |
| 14 502025 Pivot arm spring 15 502026 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing washer 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve stem 33 503147 Valve stem 34 40042 Seat n | | | |
| 15 502026 Pivot arm spring 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain hook 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Ster packing nut 31 58461 Stem packing washer 32 40193 Stem packing washer 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob 38 40045 S | | | • |
| 16 40211 Chain hook nut 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain yoke 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel nut 20 58519 Handwheel mut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut 40 40047 Screw | | | |
| 17 40212 Chain hook washer 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain yoke 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing masher 32 40194 Valve stem 33 503147 Valve body 34 40189 Cag gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob 41 40047 Screw 42 40195 Gate arm 34 40203 | | | |
| 18 502029 Lock nut 19 502028 Operating screw 20 40213 Chain yoke 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel nut 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cag gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob 39 40048 Seat nut | | | |
| 20 40213 Chain yoke 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing mut 31 58461 Stem packing washer 32 40144 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob 38 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer | | | |
| 21 89099 Chain hook 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut washer 37 40043 Hand knob screw 38 40044 Hand knob screw 39 40048 Seat nut 40 40407 Screw 41 40047 Screw 42 40195 Gate arm 43 40200 Seat washer | | 502028 | Operating screw |
| 22 48130 Friction collar rollpin 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut washer 37 40043 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly <td></td> <td></td> <td></td> | | | |
| 23 503149 Feed sleeve 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut washer 37 40043 Hand knob screw 38 40044 Hand knob screw 39 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw | | | |
| 24 85318 Chain for 6"-16" mains 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat nut washer 36 40049 Seat nut washer 37 40043 Hand knob screw 38 40044 Hand knob screw 39 40048 Seat nut 40 40047 Screw 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw </td <td></td> <td></td> <td></td> | | | |
| 25 41435 Oil plug 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40047 Screw 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 49 40198 Seat washer 49 40196 | | | |
| 26 45374 Feed sleeve O-ring 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate screw washer 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 48 40198 Seat washer <t< td=""><td></td><td></td><td></td></t<> | | | |
| 27 98430 Set screw 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 <td></td> <td></td> <td>Feed sleeve O-ring</td> | | | Feed sleeve O-ring |
| 28 58849 Handwheel nut 29 58519 Handwheel 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40047 Screw 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40222 Gate-to-arm screw | 27 | | |
| 30 40193 Stem packing nut 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 49 40198 Seat washer 49 40198 Seat washer 49 40198 Seat washer 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin <tr< td=""><td></td><td></td><td></td></tr<> | | | |
| 31 58461 Stem packing washer 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket | | 58519 | Handwheel |
| 32 40194 Valve stem 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket | 30 | 40193 | Stem packing nut |
| 33 503147 Valve body 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket | | | |
| 34 40189 Cap gasket 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder | | | |
| 35 42042 Seat washer 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40047 Screw 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 58 503148 Cap | | | |
| 36 40049 Seat nut washer 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 | | | 1.5 |
| 37 40043 Hand knob 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 < | | | |
| 38 40044 Hand knob screw 39 40048 Seat nut 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle | | | |
| 40 40045 Stem 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring | | | |
| 41 40047 Screw 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar Oring 62 580898 Feed yoke 64 50133 Washer 65 7 | 39 | 40048 | Seat nut |
| 42 40195 Gate arm 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar or-ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 | 40 | 40045 | Stem |
| 43 40203 Gate screw washer 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw | | | |
| 44 580967 Boring bar assembly 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar or-ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 797 | | | |
| 45 62501 Tool retaining screw 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 <td< td=""><td></td><td></td><td></td></td<> | | | |
| 46 40200 Seat washer screw 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring | | | |
| 47 40197 Gate washer 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 69 305006 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 < | | | ę |
| 48 40198 Seat washer 49 40196 Gate 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw <t< td=""><td></td><td></td><td></td></t<> | | | |
| 50 40013 Stem set screw 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 51 40202 Gate-to-arm screw 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | 49 | 40196 | Gate |
| 52 40023 Yoke retaining pin 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | Stem set screw |
| 53 40229 Small saddle gasket 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 54 40230 Large saddle gasket 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 55 58093 Cylinder 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 56 56694 Retaining pin 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 57 40015 Drift pin 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 58 503148 Cap 59 40020 Handle 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 60 501273 Boring bar wiper ring 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | • |
| 61 51458 Boring bar O-ring 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 62 580610 Friction collar 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | 60 | 501273 | |
| 63 580898 Feed yoke 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 64 50133 Washer 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 65 79745 Retaining screw 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 66 500851 Detent 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 67 59810 Detent spring 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 68 40139 Stud 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 69 305006 Detent screw 70 40138 Bolt* 71 80111 Handle bar | | | |
| 70 40138 Bolt* 71 80111 Handle bar | | | |
| | | | |
| 72 46255 Nut* | | | |
| | 72 | 46255 | Nut* |



Storage Chest not shown

*Order both parts when replacing either one.

NOTE: These illustrations are for parts identification only. DO NOT use these illustrations for assembly or disassembly of machine. Mueller Co. offers a machine repair service. Contact Mueller Customer Service Center for details.

TO ORDER SPECIFY QUANTITY, PART NUMBER AND PART NAME (include catalog number and model number of machine)





www.muellergas.com • moreinfo@muellercompany.com