



Parts List for DCF886B Type 1

Item Number	Part Number	Description	Qty Required
1	N162627	HOUSING SET	1
2	N236600	MOTOR & SWITCH ASSY.	1
3	N112877	RING GEAR	1
4	N075339	O-RING	1
5	N236619	MECHANISM ASSY	1
6	N236639	NOSE CONE ASSY.	1
7	642883-00	WASHER - URETHANE	1
8	N114621	ANVIL ASSY.	1
9	N165504	LIGHT RING ASSEMBLY	1
11	N079835	FWD/REV BUTTON	1
12	N078434	SPRING	1
13	N089668	STEEL BALL	1
14	N019351	COMPRESSION SPRING	1
15	N078437	SLEEVE	1
16	N016823	PLAIN WASHER	1
17	N053863	HOG RING	1
18	682211-00	SCREW,TORX	8
19	N268241	BELT HOOK KIT	1
20	N042665	MACHINE SCREW	1
24	N238179	WARNING LABEL	1
25	N200855	RATING LABEL	1
800	286436-00	GREASE	1
800	284778-00	GREASE,MOLYKOTE	1
836	233945-00	SERVICE TOOL	1
861	N197072	KITBOX	1
866	DCB203	BATTERY PACK	2
871	DCB101	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.