


Parts Assembly *Temptrol Shower & Tub-Shower Control Valves*

- S-86-1-BODYShower valve
- S-86-2-BODYTub-Shower valve
- S-86-1-BODY-X ...Shower valve w/stops
- S-86-2-BODY-X ...Tub-Shower valve w/stops



Temptrol Valve Replacement Parts and Optional Tools

Symmons Part Number	Valve Body Type		Description
	S-86-1-BODY S-86-2-BODY	S-86-1-BODY-X S-86-2-BODY-X	
TA-4	√	√	HOT & COLD seat repair kit.....(<i>optional tool p/n T-35A/B</i>)
TA-9	√	√	Control spindle washer repair kit
TA-10	√	√	Control spindle.....(<i>includes p/n TA-9 & T-16 components</i>)
T-12A	√	√	Cap assembly
T-16	√	√	Cap washer repair kit
TA-25A	S-86-2-BODY	S-86-2-BODY-X	Diverter spindle kit(<i>white appearance</i>)
TA-25B	S-86-1-BODY	S-86-1-BODY-X	Volume control spindle kit.....(<i>black or gray appearance</i>)
T-35A/B	√	√	HOT seat removal tool, T-35A & COLD seat removal tool, T-35B
T-52		√	Service stop spindle & retainer
T-55C		√	Service stop spindle, retainer & removal tool
T-108	√	√	Reverse seat & tool kit (<i>valve HOT & COLD supply inputs are reversed</i>)