


# FAUCET CONNECTOR

## CONECTOR PARA GRIFO

EASY TO INSTALL / FÁCIL DE INSTALAR

No cutting, flaring or bending required.  
No requiere cortar, ensanchar o doblar.



### INSTALLATION INSTRUCTIONS

1. Turn off water supply at shutoff valve.
2. Remove old supply connector and clean all connector threads.
3. Prior to threading the 3/8" Click Seal nut to shutoff valve, turn nut counter-clockwise until threads align. Turn Click Seal nut clockwise and **HAND-TIGHTEN** until nut clicks. "The click lets you know it's sealed."™
4. Prior to threading the 1/2" black Click Seal nut to the faucet, turn nut counter-clockwise until threads align. Turn Click Seal nut clockwise and **HAND-TIGHTEN** until nut clicks. "The click lets you know it's sealed."™ (continued)

## CLICK SEAL® FAUCET CONNECTOR CONECTOR PARA GRIFO

Also available in  
12", 20" & 30" lengths

Disponibles también  
en largos de  
12", 20" y 30"



**5 YEAR WARRANTY**  
5 AÑOS DE GARANTÍA

WARRANTY: This Fluidmaster® product has a limited warranty for a period of 5 years. For complete warranty details, please visit our website at [www.fluidmaster.com](http://www.fluidmaster.com).

GARANTÍA: Este producto Fluidmaster® tiene garantía limitada por un período de 5 años. Para consultar los detalles completos de la garantía, por favor visite nuestro sitio web [www.fluidmaster.com](http://www.fluidmaster.com).

(Installation Instructions continued)

5. Slowly turn on water at the shutoff valve.
6. Carefully check for leaks at shutoff valve.

### INSTRUCCIONES DE INSTALACIÓN

1. Corte el suministro de agua con la llave de paso.
2. Quite el conector de suministro viejo y limpie todas las rosas de conexión.
3. Antes de enroscar la tuerca de encaje para sellar de 3/8" en la válvula de cierre, gire la tuerca en dirección contraria a las manecillas del reloj hasta que las rosas se alineen. Gire la tuerca de encaje para sellar en dirección de las manecillas del reloj y **APIRIETE A MANO** hasta que la tuerca haga clic. "The click lets you know it's sealed."™
4. Antes de enroscar la tuerca de encaje para sellar negra de 1/2" en el grifo, gire la tuerca en dirección contraria a las manecillas del reloj hasta que las rosas se alineen. Gire la tuerca de encaje para sellar en dirección de las manecillas del reloj y **APIRIETE A MANO** hasta que la tuerca haga clic. "The click lets you know it's sealed."™
5. Abra lentamente el suministro de agua con la llave de paso.
6. Revise con cuidado que no haya filtraciones en la válvula de cierre.