

# Replacement Parts


## Geberit Cover Plates, Sigma for Use with Flush Buttons

115.764 115.766 115.768 Actuator Dimensions: 9.7" x 6.5" (24.6 cm x 16.4 cm)



Item	Model No.	Description	List Price
1	1	Actuator rod set to screw together (Until the end of 2007)	\$12.00
2	2	Fastening for cover plate UP300 set-2	16.00
3	3	Conversion set for tool-free installation	27.00
3.1	3.1	Actuator rod set mount w/o tool (From 2008)	11.00
3.2	3.2	Mounting frame tool-free (From 2008)	15.00
4	4	Screw for Twist, Tango, Mambo set-2. For tool-free mounting frame.	49.00
5	5	Extension set for C/C UP200/UP300	22.00

< 2008



> 2008

