





PARTS & SERVICE DEPARTMENT
Nashville, Tennessee
615-889-8900 • Fax: 615-882-2918
parts_team@lochinvar.com
www.Lochinvar.com

Replacement Parts List


Armor Wall Mount Water Heaters WA 125 thru 200




HEAT EXCHANGER



GAS TRAIN



CONTROL PANEL



ITEM NO.	PART NO.	DESCRIPTION	MODEL
HEAT EXCHANGER ASSEMBLY			
1	HEX30076	HEAT EXCHANGER	WA125
1	HEX30077	HEAT EXCHANGER	WA200
CONTROLS			
2	RLY20063	LOW VOLTAGE CONNECTION BOARD	ALL
3	RLY30047	INTEGRATED CONTROL	ALL
3	RLY30051	HIGH ALTITUDE INTEGRATED CONTROL	ALL
4	RLY20058	USER INTERFACE CONTROL	ALL
-	LBL20318	USER INTERFACE OVERLAY	ALL
5	TST20037	INLET SENSOR	ALL
6	TST20038	OUTLET SENSOR/ HIGH LIMIT	ALL
7	RLV30000	AIR VENT VALVE	ALL
8	FAN3030	FAN ASSEMBLY	WA125
8	FAN3032	FAN ASSEMBLY	WA200
9	GKT2456	BLOWER GASKET	WA125
9	GKT2436	BLOWER GASKET	WA200
GAS VALVES			
10	VAL30070	GAS VALVE ASSEMBLY	WA125
10	VAL3211	GAS VALVE ASSEMBLY	WA200
11	GKT2443	GASKET, VENTURI	ALL
12	MSC3006	AIR INLET KIT	ALL
13	MSC2233	GAS VALVE SWITCH	ALL
PILOT & BURNER ASSEMBLIES			
14	PLT3022	FLAME SENSOR W/ GASKET	ALL
15	GKT2450	GASKET, FLAME SENSOR	ALL
16	PLT3021	IGNITER W/ GASKET	ALL
17	GKT2449	GASKET, IGNITER	ALL
18	BNR30019	BURNER W/ GASKET	WA125
18	BNR3427	BURNER W/ GASKET	WA200
19	GKT2451	GASKET, BURNER	ALL
20	WTR3077	GAS/AIR ARM ASSEMBLY W/GASKET	WA125
20	WTR3078	GAS/AIR ARM ASSEMBLY W/GASKET	WA200
21	GKT2454	GASKET, GAS/AIR ARM ASSEMBLY	ALL
22	WTR30002	HEAT EXCHANGER ACCESS DOOR	ALL
MISCELLANEOUS			
23	MSC3180	SIGHT GLASS	ALL
24	GKT2453	GASKET, SIGHT GLASS	ALL
25	FIB2167	DIVIDER PLATE, INSULATION BAFFLE	ALL
26	FIB2291	BURNER PLATE, INSULATION, DOOR	ALL
27	MSC20306	DISPLAY BEZEL	ALL
28	RLV20024	RELIEF VALVE 150 PSI	ALL
29	TST20007	FLUE SENSOR	ALL
30	PVC2048	FLUE CONNECTION 3"	WA125
31	TRF20000	TRANSFORMER, 24V, 40VA	ALL
32	PRS20016	PRESSURE SWITCH	WA125
32	PRS20017	PRESSURE SWITCH	WA200
33	CPG2059	COUPLING, AIR INLET 3"	ALL
33	CPG2061	COUPLING, AIR INLET 2"	ALL
34	MSC20123	KNOB, FLUTED W/ SKIRT	ALL
35	GKT2455	GASKET, DOOR, RUBBER	ALL
PLEASE HAVE MODEL AND SERIAL NUMBER WHEN ORDERING PARTS			

ITEM NO.	PART NO.	DESCRIPTION	MODEL
MISCELLANEOUS (CONTINUED)			
-	TST2044	BULBWELL, 1/4	ALL
-	TST2032	TANK SENSOR	ALL
-	JKB2011	WALL MOUNT BRACKET	ALL
-	FUS20001	0.8 AMP	ALL
-	FUS2001	3.15 AMP	ALL
-	FUS2002	5 AMP	ALL
-	WTR2040	FLOW SWITCH	ALL
-	SWT2011	BLOCKED DRAIN SWITCH	ALL
-	TST30018	WATER HEATER SENSOR KIT	ALL
-	WTR20009	MRLWCO WITH TEST	ALL
-	KIT3087	NEUTRALIZER KIT	ALL
-	KIT30112	ALARM BELL	ALL
-	LPK30016	LP CONVERSION KIT	WA125
-	LPK3947	LP CONVERSION KIT	WA200
-	MSC20009	CONDENSATE TRAP ASSEMBLY	ALL
-	KIT30062	HEAT EXCHANGER CLEANING KIT	WA125
-	KIT30063	HEAT EXCHANGER CLEANING KIT	WA200
-	WRE20064	HARNESS, CONNECTION BOARD	ALL
-	WRE20066	HARNESS, RELAY	ALL
-	WRE20093	HARNESS, UNIT	ALL
-	WRE20177	HARNESS, POWER	ALL
-	WRE2203	CABLE, RIBBON	ALL
-	WRE2209	HARNESS, SPARK ELECTRODE	ALL
-	WRE2211	HARNESS, FLAME SENSE ELECTRODE	ALL
PUMPS			
-	PUM3010	PUMP	ALL
JACKET ASSEMBLY			
36	JKB60449	JACKET, TOP	WA125
36	JKB60437	JACKET, TOP	WA200
37	JKB30091	JACKET, FRONT	ALL
38	JKB60448	JACKET, LEFT SIDE	WA125
38	JKB60436	JACKET, LEFT SIDE	WA200
39	JKB40175	JACKET, RIGHT SIDE	WA125
39	JKB40171	JACKET, RIGHT SIDE	WA200
PLEASE HAVE MODEL AND SERIAL NUMBER WHEN ORDERING PARTS			