

# DOOR KNOCKER

### **BEFORE INSTALLING**


Read entire door knocker installation instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the door have been completed.

## INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your door knocker contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the door or for personal injury during installation.

## **TOOLS AND MATERIALS:**



#### INSTALLATION

- 1. Hold the door knocker against the front of the door in the desired mounting position. Mark the center of the door knocker.
- 2. Measure and mark the locations of the bolt holes on the door. Use the level to make sure the marks are even.
- 3. If drilling through the door, drill holes in the marked location with a  $\frac{1}{4}$ " drill bit. Take care to drill the holes as straight as possible. For surface mount door knockers, move on to step 5.
- 4. Hold the door knocker in place on the front of the door. Insert the bolts through the back of the door, and tighten the nuts with a screwdriver and/or wrench.

Note: It is recommended that you apply thread sealant to the threads of the bolts prior to installation. This will ensure the bolts will not loosen over time.

- 5. If drilling into the surface of the door, drill holes in the marked locations of the appropriate size and depth for the mounting hardware.
- 6. Hold the door knocker in place on the outside of the door. Insert the screws and tighten firmly with a screwdriver.

Note: If necessary, the provided mounting bolts can be trimmed to the appropriate length with a hacksaw. If installing a surface mount door knocker on a metal door, metal screws may need to be purchased at your local hardware store.

Thread Sealant