KICHLER

NOTE: Height of fixture must be adjusted before fixture is mounted to ceiling.

- To adjust the length of the cord to achieve the desired height of the mounted fixture: Loosen threaded stud on strain relief on canopy. Carefully pull cord up into canopy to shorten the height of fixture or carefully pull cord down to lengthen the height of fixture. When desired height is achieved, tighten threaded stud on strain relief.
- 2) TURN OFF POWER.
 - **IMPORTANT:** Before you start, NEVER attempt any work without shutting off the electricity until the work is done.
 - a) Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
 - b) Unscrew the fuse(s), or switch "OFF" the circuit breaker switch(s), that control the power to the fixture or room that you are working on.
 - c) Place the wall switch in the "OFF" position. If the fixture to be replaced has a switch or pull chain, place those in the "OFF" position.
- Find the appropriate threaded holes on mounting strap. Assemble mounting screws into threaded holes.
- Attach mounting strap to outlet box. (Screws not provided). Mounting strap can be adjusted to suit position of fixture.
 Grounding instructions: (See Illus, A or B).
 - Grounding instructions: (See Illus. A or B).A) On fixtures where mounting strap is provided with a hole and two raised dimples. Wrap ground wire from
 - a) outlet box around green ground screw, and thread into hole.B) On fixtures where a cupped washer is provided. Attach
 - ground wire from outlet box under cupped washer and green ground screw, and thread into mounting strap. If fixture is provided with ground wire. Connect fixture ground wire to outlet box ground wire with wire connector. (Not provided.) After following the above steps. Never connect ground wire to black or white power supply wires.



6) Make wire connections (connectors not provided.) Reference chart below for correct connections and wire accordingly.

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor
*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in	

7) Push fixture to ceiling, carefully passing mounting screws through holes in canopy.

Neutral Wire

shape or smooth (see illus.)

- Thread knurl knobs onto mounting screws. Tighten knurl knobs to secure fixture to ceiling.
- 9) Raise shade up to fixture. Pass hole in shade over socket.
- 10) Thread socket ring onto socket. Tighten socket ring to secure shade in place. (DO NOT over tighten.)



SEE OTHER SIDE FOR SPANISH TRANSLATIONS. VEA EL OTRO LADO DE TRADUCCIONES AL ESPAÑOL.