




PRODUCT:


AIR BAG BLOWERS

PART NUMBER:


**9535-08, 9535-08L (8" AC)
 9535-08DC, 9535-08LDC (8" DC)
 9535-12, 9535-12L (12" AC)
 9535-12DC, 9535-12LDC (12" DC)**



**9535-08 & 9535-08L
 9535-12 & 9535-12L**



9535-08DC & 9535-08LDC



9535-12DC & 9535-12LDC

KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION
	9535-08	AC Air Bag 8 (15' Ducting)	4	9535-08G	Grill (Air Bag 8)		9534-05	Fan (Air Bag 8DC/LDC)
	9535-08L	AC Air Bag 8 (25' Ducting)		9535-12G	Grill (Air Bag 12)		9509-06	Fan (Air Bag 12DC/LDC)
	9535-08DC	DC Air Bag 8 (15' Ducting)		9534-02	Grill (Air Bag 8DC/LDC)	8	9535-08F	Rubber Feet, Set of 4 (Air Bag 8)
	9535-08LDC	DC Air Bag 8 (25' Ducting)		9509-02	Grill (Air Bag 12DC/LDC)		9535-12F	Rubber Feet, Set of 4 (Air Bag 12)
	9535-12	AC Air Bag 12 (15' Ducting)	5	9535-08H	Handle w/ Cord (Switch and screws included) (Air Bag 8)		9505-06	Rubber Feet, Set of 4 (Air Bag 8DC/LDC & Air Bag 12DC/LDC)
	9535-12L	AC Air Bag 12 (25' Ducting)		9535-12H	Handle w/ Cord (Switch and screws included) (Air Bag 12)	9	9506-11	Fuse, 30 Amp (Air Bag 8DC/LDC & Air Bag 12DC/LDC)
	9535-12DC	DC Air Bag 12 (15' Ducting)		9513-07	Handle (Air Bag 8DC/LDC & Air Bag 12DC/LDC)	10	9534-04	Chassis (Air Bag 8DC/LDC)
	9535-12LDC	DC Air Bag 12 (25' Ducting)		9535-08M	Motor (Air Bag 8)		9509-05	Chassis (Air Bag 12DC/LDC)
1	9535-08D	15' Ducting (Air Bag 8)	6	9535-12M	Motor (Air Bag 12)	11	9506-40	Cord w/ Battery Clamps (Air Bag 8 DC/LDC & Air Bag 12DC/LDC)
	9535-12D	15' Ducting (Air Bag 12)		9506-10	Motor (Air Bag 8DC/LDC & Air Bag 12DC/LDC)	12	9513-09	Motor Clamp (Air Bag 8DC/LDC)
	9535-08DL	25' Ducting (Air Bag 8)		9535-08E	Fan (Air Bag 8)			
	9535-12DL	25' Ducting (Air Bag 12)		9535-12E	Fan (Air Bag 12)			
2	9514-01B	Duct Clamp (Air Bag 8 DC/LDC)	7					
	9535-12CP	Duct Clamp (Air Bag 12 DC/LDC)						
3	9535-08C	Blower Bag (Air Bag 8)						
	9535-12C	Blower Bag (Air Bag 12)						