



PIPE TOOLS & VISES
SINCE 1896

RS7290 Ratchet Shears Instructions

#04182

- CUTS PE, ABS, PEX, PP, AND SIMILAR SOFT PLASTICS & RUBBER MATERIAL.
- DOES NOT CUT METAL OR REINFORCED TUBING.
- CORTA PE, ABS, PEX, PP, Y MATERIALES SIMILARES DE PLÁSTICO BLANDO Y GOMA.
- NO CORTA METAL NI TUBERÍA REFORZADA.

OPERATION:

Pull the handles apart fully to open blade. Place material squarely against the cradle, and squeeze handles together completely. Relax the handles to engage next ratchet tooth; squeeze handles again. Repeat until blade is through the pipe.

HELPFUL HINTS:

To prevent cracking of cold pipe - warm pipe (no direct flame) and use slow, even strokes. Apply light oil on mechanism to prevent rusting and reduce friction. Rotate shears slightly around very flexible thin pipe or tubing to assist in cutting.

REPLACE BLADE:

Fully open handles. Remove nut and blade pivot bolt using screwdriver and wrench. Pull blade out of body to expose blade pin and retaining ring. CAUTION: Blade is very sharp. Remove ring and pin. Reassemble in reverse order. Check the replacement blade for straight cuts. (See RESHARPEN BLADE).


RESHARPEN BLADE:

Sharpen with fine, hard whetstone held at 30-degree angle to blade. Sharpen evenly on both sides of cutting edge so tool cuts easily. If blade cuts crooked, sharpen side toward which blade deflects. Draw stone into blade, not away.



CAUTION:

Wear eye protection when cutting cold or brittle plastics. Pipe can crack or shatter causing possible eye injury. Keep fingers clear when cutting. Blade is sharp! Pick up and hold tool by the handles. When not using shears, leave blade in the fully advanced (closed) position to prevent damage to blade and hands.



Replacement Blade: RS7290B #94555

Reed Manufacturing Company
1425 West 8th Street
Erie, PA 16502 USA



Phone: 800-666-3691 or 814-452-3691
Fax: 800-456-1697 or 814-455-1697
www.reedmfgco.com

1017-54182



PIPE TOOLS & VISES
SINCE 1896

RS7290 Ratchet Shears Instructions

#04182

- CUTS PE, ABS, PEX, PP, AND SIMILAR SOFT PLASTICS & RUBBER MATERIAL.
- DOES NOT CUT METAL OR REINFORCED TUBING.
- CORTA PE, ABS, PEX, PP, Y MATERIALES SIMILARES DE PLÁSTICO BLANDO Y GOMA.
- NO CORTA METAL NI TUBERÍA REFORZADA.

OPERATION:

Pull the handles apart fully to open blade. Place material squarely against the cradle, and squeeze handles together completely. Relax the handles to engage next ratchet tooth; squeeze handles again. Repeat until blade is through the pipe.

HELPFUL HINTS:

To prevent cracking of cold pipe - warm pipe (no direct flame) and use slow, even strokes. Apply light oil on mechanism to prevent rusting and reduce friction. Rotate shears slightly around very flexible thin pipe or tubing to assist in cutting.

REPLACE BLADE:

Fully open handles. Remove nut and blade pivot bolt using screwdriver and wrench. Pull blade out of body to expose blade pin and retaining ring. CAUTION: Blade is very sharp. Remove ring and pin. Reassemble in reverse order. Check the replacement blade for straight cuts. (See RESHARPEN BLADE).


RESHARPEN BLADE:

Sharpen with fine, hard whetstone held at 30-degree angle to blade. Sharpen evenly on both sides of cutting edge so tool cuts easily. If blade cuts crooked, sharpen side toward which blade deflects. Draw stone into blade, not away.



CAUTION:

Wear eye protection when cutting cold or brittle plastics. Pipe can crack or shatter causing possible eye injury. Keep fingers clear when cutting. Blade is sharp! Pick up and hold tool by the handles. When not using shears, leave blade in the fully advanced (closed) position to prevent damage to blade and hands.



Replacement Blade: RS7290B #94555

Reed Manufacturing Company
1425 West 8th Street
Erie, PA 16502 USA



Phone: 800-666-3691 or 814-452-3691
Fax: 800-456-1697 or 814-455-1697
www.reedmfgco.com

1017-54182