SYMPTOMS	CORRECTIVE ACTION	PARTIAL SERVICE PARTS
1. Poor flush.	 A. Adjust tank water level to match the waterline. B. Fully open water supply shut-off valve. C. Clear obstruction in trapway, jet, or bowl rim holes. D. Clear obstruction in soil pipe or vent pipe. 	1034693** (LH) 1036058** (RH) Trip Lever Kit 78132 1 colorate 56094 51261 Clip
2. No flush.	 A. Reconnect the flapper chain to trip lever or flush valve. B. Adjust flapper chain assembly to remove excessive slack. 	1034694 Seal Waterline
 Fill valve turns on/off by itself without toilet being flushed, or runs allowing water to enter tank. 	 A. Adjust flapper chain for proper slack so flapper isn't held off flush valve seat. B. Clean or replace flapper if flapper is worn, dirty, or misaligned with flush valve seat or flush valve seat is damaged. Replace flush valve seal or flush valve. C. Remove tank and tighten flush valve nut if flush valve gasket is leaking. Do not overtighten. If leakage continues, replace gasket. D. Clean fill valve seat/seat washer of debris, or replace piston/seat washer assembly. E. Replace fill valve if valve float sinks. F. Adjust tank water level if too high. 	Valve 85307 Washer 84678 Locknut 42398 Washer Seal Valve
4. Long tank fill cycle.	 Fully open water supply shut-off valve. B. Clean fill valve inlet, valve head, or supply line. Flush lines. 	42397 Nut 1018165-A
5. Noisy tank fill cycle.	 A. Partially close the water supply shut-off valve if water pressure to the toilet is too high. Check toilet performance following any such adjustment. B. Remove dirt or obstruction in valve head, flush line. 	Gasket 1014065 Attachment Plate
WARNING: Use only genuine	Kohler parts as shown to avoid property damage.	**Finish/color code required.
If unable to correct the problem, contact Customer Service: 1-800-4-KOHLER (USA), 1-800-964-5590 (Canada), or www.kohler.com.		

1020805-6-**B**

©2004 Kohler Co.