# SPEAKMAN®

# S-2530 Shower Arm Installation, Maintenance & Operation **Instructions**

### **DESCRIPTION**

Speakman polished chrome plated brass curved shower arm.

## **SPECIFICATIONS**

1/2" NPT MALE INLET 1/2" NPT MALE OUTLET SHIPPING WEIGHT: 1.6 LBS.


### **INSTALLATION**

Speakman recommends the use of a qualified plumber to properly install the cast brass shower arm and to size(L) The ½"-14 NPT threaded nipple. Make sure the shower arm is tightened completely to prevent leaks. Speakman does not supply threaded nipple due to different wall constructions.

### **MAINTENANCE**

The gleaming finish of your SPEAKMAN S-2530 shower arm can be cleaned by using mild soap and warm water. Dry immediately with a soft, clean cloth for best results.

### **ROUGH-IN MEASUREMENTS**



- UTES:

  1) SPEAKMAN RECOMMENDS THE USE OF A QUALIFIED PLUMBER TO PROPERLY INSTALL THE CAST BRASS SHOWER ARM AND TO SIZE

  THE 1/2-14 NPT THREADED NIPPLE. MAKE SURE THE SHOWER ARM IS TIGHTENED COMPLETELY TO PREVENT LEAKS.
- 2) ALL BEHIND WALL PIPING NOT SUPPLIED
- 3) MUST HAVE 8" OF CLEARANCE 360" AROUND CENTERLINE OF SHOWER ARM FOR PROPER INSTALLATION.
- 4) ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS DTHERWISE SPECIFIED AND ARE SUBJECT TO CHANGE WITHOUT NOTICE.

Fax: 800-977-2747 92-S-2530-R2