



Optima Plus® EBF-85



| PARTS LIST—EBF-85 FAUCET | | | |
|--------------------------|----------|------------|---|
| Item No. | Code No. | Part No. | Description |
| 1. | 3315016 | EBF-10-A | Faucet and Sensor Assembly (EBF-85) |
| _ | 3315122 | EBF-1009-A | Fiber Optic Sensor Cable Assembly Only (replaces EBF-12-A and EBF-179-A includes lens holder) |
| 2. | 3365091 | ETF-1021-A | 0.5 gpm (1.9 Lpm) Spray Head with Key (female thread) |
| _ | 3365090 | ETF-1022-A | 2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (female thread) |
| _ | 3365161 | ETF-1028-A | 1.5 gpm (5.7 Lpm) Laminar Flow Spray Head with Key (female thread) |
| _ | 3365755 | ETF-1038-A | 0.35 gpm (1.3 Lpm) Multi-Lam Spray Head VR |
| | 0305927 | ETF-435 | Replacement Key ONLY |
| 3A. | 3365466 | ETF-295-A | 4" (102 mm) Centerset Trim Plate Kit for Faucet (Faucet Only) includes two (2) Nuts, two (2) Hex Screws, two (2) Flat Washers, Single Hole Cover Plate, and CP Base Plate |
| 3B. | 3365467 | ETF-299-A | 4" (102 mm) Centerset Trim Plate Kit for Faucet with Optional Mixing Valve includes two (2) Nuts, two (2) Hex Screws, two (2) Flat Washers, Dual Hole Cover Plate, and CP Base Plate |
| 4. | 0305626 | ETF-290-A | Faucet Mounting Kit includes Rubber Gasket, Mounting Washer, Mounting Nut, and Compression Fitting Connector |
| 5. | 0305736 | ETF-297 | 1/4" to 3/8" Compression Fitting Connector |
| 6. | 3315111 | EBF-11-A | Solenoid Valve Module Assembly includes Solenoid Enclosure, Solenoid Body, and Filter Cap |
| _ | 3315009 | EBF-1001-A | Solenoid Filter Replacement Kit for old solenoid includes Filter Screen Assembly and O-ring |
| _ | 3315028 | EBF-1004-A | Solenoid Filter Replacement Kit for current solenoid includes Filter Screen Assembly and O-ring |
| _ | 3315051 | EBF-1005-A | Filter Cap Assembly for old solenoid includes metal Filter Cover and O-ring — OBSOLETE |
| 7. | 3315001 | EBF-16-A | Single Supply Solenoid Kit with Ferrule Compression Nut |
| 8. | 3315014 | EBF-25-A | Mounting Bracket Kit includes Base Plate, Wall Bracket Base, Wall Bracket, Mounting Screw, Self- tapping Screw, two (2) Wood Screws plus Washers and Plastic Anchors, two (2) Screws plus Washers and Toggle Nuts, two (2) Screws plus Washers and Hollow Wall Anchors |
| 9. | 3365461 | ETF-617-A | Bak-Chek® "T" Assembly |
| 10. | 0315004 | EBF-17 | 3/8" to 1/4" Compression Fitting Connector |





SOLENOID VALVE CHANGES

The current solenoid (in production since May 1998; part 7 shown on the left) has MALE inlet and outlet connections. The current style filter plug has a metal filter cap that can be removed with a 5/8" wrench.

The older solenoid valve (shown on the left) can be identified by FEMALE inlet and outlet connections. These require EBF-17 compression fittings (part 10 shown on the left).

This older style solenoid has either a plastic or a replacement brass filter cap. Remove the older brass filter cap with a 7/16" or 1/2" hex wrench. Replace the old style filter cap.