
## **Control Stop**

## CONTROL STOP AND REPLACEMENT PARTS FOR OLDER CONTROL STOPS

		Code No.	Part No.	Description	
H-10-A 1" Screwdriver An	gle Stop, (also fits H-15-A 1" Screwdr	iver Straight Stop	) — used	from 1920's through 1940's	
		5308077	H-12	Packing only – 12 per package	
-			_	Bonnet no longer available	

H-10-A 1" Wheel Handle Angle Stop (also fits H-15-A 1" Wheel Handle Straight Stop) — Used from 1920's through 1940's






5308077	H-12	Packing only – 12 per package
_	—	Bonnet no longer available

H-20-A 1/2" and 3/4" Screwdriver Angle Stop (also fits H-30-A Screwdriver Straight Stop) — Used from 1920's through 1950's






5308077	H-12	Packing only – 12 per package
_	_	Bonnet no longer available

H-20-A 1/2" and 3/4" Wheel Handle Angle Stop (also fits H-30-A Wheel Handle Straight Stop) — Used from 1920's through 1950's






of fianale of algine otop)			
	5308077	H-12	Packing only – 12 per package
			Bonnet no longer available

H-40-A 3/4" and 1" Screwdriver Angle Stop (also fits H-45-A Screwdriver Straight Stop) — Used from 1930's through 1960's






3308277	H-47-A-5D	retaining ring, screw assembly, and packing
0308176	H-39-A-SD	Bonnet assembly repair kit includes a bonnet assembled with packing ring, key socket, retaining ring, screw assembly, and packing plus our H-37 Vandal Resistant Stop Cap that replaces the lock shield
5308077	H-12	Packing only – 12 per package
0308167	H-39	Bonnet Only

Densis life includes realized day, how eachest look shield

~~~~==

11 47





| anule Straight Stop) — Used from 1950'S through 1960'S |           |                                                                                                                                                                                               |  |
|--------------------------------------------------------|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| 3308278                                                | H-47-A-WH | Repair kit includes packing ring, screw, wheel handle,<br>key stem, gland for wheel handle, retaining gland, screw<br>assembly, washer and packing                                            |  |
| 0308175                                                | H-39-A-WH | Bonnet assembly repair kit includes a bonnet assembled<br>with packing ring, screw, wheel handle, key stem, gland<br>for wheel handle, retaining gland, screw assembly,<br>washer and packing |  |
| 5308077                                                | H-12      | Packing only – 12 per package                                                                                                                                                                 |  |
| 0308170                                                | H-39      | Bonnet Only                                                                                                                                                                                   |  |
|                                                        |           |                                                                                                                                                                                               |  |