


Model: 062830 062860 **Top :** 308031 308061
 062836 062872 308037 308073
 062848 308049

Note : For installing under counter sink with counter top

Step 1 : Apply adhesive caulking around the topside of rim near the edge, Carefully raise sink in place, align, and press firmly

See Figure 1.


Figure 1.



Step 2 : Attach 4 undermount-clips to hold lavatory in place


See Figure 2.

Figure 3.



Step 3 : Secure top & back splash to cabinet by using adhesive caulk

See Figure 3.



Model: 062830 062860 **Top :** 308031 308061
 062836 062872 308037 308073
 062848 308049

Note : For installing under counter sink with WideAppeal Top

Step 1 : DO NOT DISCARD WOODEN INSTALLATION BRACKET!

- Make sure wooden installation bracket is safely secure
- Install under counter sink by following specific sink installation

See Figure 1.

Figure 1.





Figure 2.




- Step 2 :**
- For best results, clean the mounting surfaces with a dry cleaning cloth
 - To prevent over flow of adhesive, use masking tape to tape off the edges of the cabinet and the counter top

Step 3 : Apply adhesive on wood bracket and mounting surfaces of the cabinet

See Figure 2.

Figure 3.



Step 4 : Carefully place countertop on to the cabinet, align, and press firmly

See Figure 3.