Introduction


This Wet/Dry Vac is intended for household use. It may be used for vacuuming wet or dry media and may be used as a blower. Read this owner's manual to familiarize yourself with the product features and to understand the specific usage of your new Vac.

Unpacking and Checking Carton Contents —

Remove contents of carton. Check each item against the Carton Contents List. Call 1-800-4-RIDGID (1-800-474-3443) from the US and Canada, 01-800-701-9811 from Mexico, or E-mail us at info@ridgid.com if any parts are damaged or missing.


Carton Contents List

Key	Description	Qty
А	Wet/Dry Vac	1
В	Pro-Hose	1
С	Casters	4
D	Caster Foot w/Storage	4
Е	Car Nozzle	1
F	Utility Nozzle	1
G	Wet Nozzle	1
Н	Extension Wands	2
1	Owner's Manual	1



Caster/Caster Foot Assembly

- 1. Turn the dust drum upside down on the floor.
- Insert the caster feet into the bottom of drum, as shown (4 places).
- 3. Push on the caster foot until the foot is flush with bottom of the dust drum.
- Insert the caster stem into the socket of the caster foot, as shown (4 places).
- 5. Push on the caster until the ball on the caster stem is inserted all the way into the socket. You will hear the ball snap into the socket and the caster will swivel easily when positioning is correct.



6. Turn the drum upright.

Wet/Dry Vac Assembly

- 1. Line up front of power head assembly with vacuum port located on the front of the drum, as shown.
- 2. Place power head assembly on top of drum.
- 3. Be sure lid completely covers the top of the drum so leakage does not occur.
- areas to cause the flexible locking tabs to hook onto the drum channel.
- 5. Make sure that the locking tabs are snapped in place to prevent the lid from coming off. (See inset).

Your new Wet/Dry Vac is ready for use.

Out Drum Flexible

Locking Tab

4. Push down on top of the drum latch

Insert Hose

Insert the push button end of the prohose into the inlet of the Vac. The hose should snap into place.

To remove the hose from the Vac, press the release button in the hose assembly and pull the hose out of the Vac inlet, as shown.

