

Sunstruck®

5.5' Bath **K-6368**



Features

- Wide ledge on one side is ideal for deck-mount faucet and/or handshower.
- 17" soaking depth.
- Center drain.
- Integral lumbar support.
- Textured bottom surface.
- 65-1/2" (1664 mm) x 35-1/2" (902 mm) x 24-1/2" (622)

Material

Acrylic.

Installation

- Freestanding
- PureFlo drains are not recommended for a deck-mount faucet installation

Recommended Accessories

K-7213 27" Cable Bath Drain

K- 7265 Clearflo Bath Drain

K- 37380 30" Rough-in Cable Bath Drain

K- 37383 30" Rough-in Cable Bath Drain

K- 37386 30" Rough-in Cable Bath Drain

K- 24916 Wireless Music Kit

Codes/Standards

CSA B45.5/IAPMO Z124 Greenguard UL 2818 - Gold

KOHLER® One-Year Limited Warranty

See website for detailed warranty information.

Available Color/Finishes

Color tiles intended for reference only.

Color	Code	Description
	0	White
	96	Biscuit





Sunstruck®

4"

8-7/16"

8"

(214 mm)

(203 mm)

KOHLER

5.5' Bath K-6368

(102 mm)


3-5/8"

1/2" (13 mm)

(59 mm) Subfloor Relief

(92 mm)

No change in measurements if connected with drain illustrated. (K-37385) Faucet area.



Floor

* Allow for appropriate relief in subfloor for drain clearance. Note: Horizontal PVC pipe and tee shown, not included.

Technical Information

All product dimensions are nominal. Installation: Freestanding

Drain location: Center

45-3/4" x 24-7/8" (1162 mm x 632 mm) Basin area, bottom: 54-7/8" x 29-3/16" (1394 mm x 741 mm) Basin area, top:

Weight: 91 lbs (41.3 kg)

Minimum floor load: 40.4 lbs/ft² (197.3 kg/m²)

1-1/2" Bath Drain

Water depth: 16" (406 mm) Water capacity: 72.6 gal (274.8 L)

Footprint, 1244408-7, not required, not Template:

included

Notes

3-15/16"

(100 mm)

* 1-7/8"

(48 mm)

Measure your actual product for rough-in details. Install this product according to the installation instructions.

2-5/16"

The hot water supply should be 70% of the capacity of the bath or greater. Installations will vary.

Do not support the load weight of the bath by the

If installing a rim-mount faucet, make sure there is no interference with drain overflow before drilling any holes. Consult local and national codes for minimum air gap requirements if installing a spout on the faucet deck.

