

# PAGOSA SINGLE HOLE FAUCET INSTALLATION

## BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, sink, counter top, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the faucet for damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

## TOOLS AND MATERIALS:



Plumbers Tape



Thread Sealant



Adjustable Wrench



Phillips  
Screwdriver



Small Bucket



Basin Wrench

## GETTING STARTED


- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

# PAGOSA SINGLE HOLE FAUCET INSTALLATION


## Installation

1. Ensure that the water supply below your sink is completely shut off by turning the shutoff valves all the way to the right.


**Tip:** Place a small bucket below your workspace to catch any water that may drip during the installation process.




2. Attach the provided braided water lines to the faucet body by hand tightening them. Finish tightening them by using an adjustable wrench, but be careful not to overtighten. One 1/4 turn should suffice.




3. Remove the brass lock nuts from the mounting posts, and attach the threaded mounting posts to the faucet body using a Philips screwdriver. Set the brass lock nuts aside for now.



4. Slide the decorative escutcheon onto the braided water lines and up to the faucet body. From above the counter top, set the faucet into its prepared mounting hole.




5. From beneath the sink, slide the rubber gasket onto the mounting posts, followed by the metal washer. Ensure that each post passes through its designated hole. Hold in place.




# PAGOSA SINGLE HOLE FAUCET INSTALLATION


6. Secure the faucet by reattaching the brass lock nuts that were removed in step 3. Hand tighten and adjust the faucet until it is properly aligned. Once aligned, use the provided wrench to finish tightening the lock nuts.




7. Apply plumber's tape or thread sealant to the threading on each braided water line. Attach the water lines to your main water supply lines. Ensure that you are connecting the hot and cold lines appropriately.



8. Once installation is complete, turn the main water supply back on from underneath your sink. Check for any leaks underneath.



9. Turn the faucet on and ensure that there are no leaks. Check to ensure that both hot and cold water are running properly. Allow the water to flow for approximately 60 seconds to remove any dust or sediment within the water lines.




# PAGOSA SINGLE HOLE FAUCET INSTALLATION

## DRAIN INSTALLATION

1. Disassemble the drain assembly and lay the parts aside, in the same order they were removed. See the illustration below as a reference if needed.

Pop-Up Drain Flange




Flat Rubber Gasket




Tapered Rubber Gasket




Plastic Friction Washer




Lock Nut




Tailpiece



2. Apply plumber's tape to the threading on the tailpiece, then reattach the tail piece to the pop-up drain flange.




3. Slide the flat rubber gasket up the tailpiece until it meets the lip of the pop-up drain flange.




# PAGOSA SINGLE HOLE FAUCET INSTALLATION

4. Insert the drain flange and tailpiece through the top of your sink's drain hole.



6. Thread the lock nut onto the drain flange. Hand tighten until secure, then finish tightening with a basin wrench once the drain is properly aligned.

**Important:** Be careful not to overtighten, which could crack a porcelain sink or stone countertop.



5. From under your counter, slide the tapered rubber gasket followed by the plastic friction washer onto the tailpiece until they meet your sink or countertop. Be sure that the tapered side of the rubber washer is facing up.

