



LORENZ KITCHEN FAUCET INSTALLATION

BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, sink, counter top, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the faucet for shipping damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

TOOLS AND MATERIALS:



Plumbers
Tape*



Thread
Sealant*



Phillips
Screwdriver*



Adjustable
Wrench*



Small
Bucket*

*not included


Installation

1. Ensure that the water supply below your sink is completely shut off by turning the shutoff valves all the way to the right.

Tip: Place a small bucket below your workspace to catch any water that may drip during the installation process.



2. If the braided water lines came attached to the faucet, remove them by unthreading them from the copper supply tubes. Remove the lock nut, metal washer, and rubber washer from the faucet as well.






LORENZ KITCHEN FAUCET INSTALLATION


3. Insert the faucet into its mounting hole. From beneath the counter, slide the rubber gasket back onto the faucet body followed by the metal washer. Thread the locknut back onto the faucet body until hand tight. Finish securing the faucet by tightening the two screws attached to the lock nut with a Phillip's screwdriver.

Important: The faucet is meant to be mounted so that the handle is on the left-hand side while facing the faucet. If you would like the handle to be on the right-hand side, the water lines as well as the hot/cold indicator on the handle will need to be reversed.




4. Attach the provided braided water lines to the copper supply tubes on the faucet. Apply plumber's tape or thread sealant to the threads before tightening. Ensure that you are connecting the hot and cold lines appropriately. Hand tighten the connections, then finish tightening with a ¼ turn using an adjustable wrench.

Important: If you have mounted the faucet so that the handle is on the left-hand side, attach the water lines as they are labeled (hot/red and cold/blue). If you have mounted the faucet so that the handle is on the right-hand side, reverse the hot and cold lines from how they are labeled (hot/blue and cold/red).




5. Attach the main supply lines to the braided water lines on the faucet. The hot supply line should connect to the red water line, and the cold to blue. Apply plumber's tape or thread sealant to the threads before tightening. Hand tighten the connections, then finish tightening with a ¼ turn using an adjustable wrench.





LORENZ KITCHEN FAUCET INSTALLATION


6. Disassemble the provided hand shower hose weight by removing the two screws with a Phillip's screwdriver. From beneath the counter, measure 15" down the hose from the faucet body. The weight will need to be mounted at this location. Clamp the two sides of the weight together and tighten the screws to secure.



7. Connect the hand shower hose to its copper supply tube on the faucet, as shown. Insert the rubber O-ring into the lock nut before attaching. Apply a bit of thread sealant or plumber's tape to the threads before tightening. Hand tighten the connection, then finish tightening with a ¼ turn using an adjustable wrench.



8. Once installation is complete, turn the main water supply back on from underneath your sink. Check for any leaks underneath.



9. Remove the sprayer nozzle from the faucet by unthreading it from the hose. Turn the faucet on for approximately 60 seconds to remove any dust or loose sediment within the water lines, and to ensure that there are no leaks. Ensure that both hot and cold water are functioning properly. Reattach the sprayer nozzle and divert the water to the sprayer to ensure functionality.

